



PART NUMBER	DESCRIPTION
SEDL-OC2R	TORQUE INDICATOR
SEL-OC19EG	INTERTURBINE TEMP IND.
SLZ9244	IVSI
SLZ9247	IVSI
SLZ9464A	IVSI
WCS8194374-804	MAXIMUM ALLOWABLE AIRSPEED
WL1401AMMS3	SERVO ALTIMETER
WL1403AMMS1	SERVO ALTIMETER
WL1609AM3	COUNTER POINTER ALTIMETER
066-03020-0008	FLIGHT COMMAND IND.
066-3024-05	PICTORIAL NAVIGATION INDICATOR
777-1026-003	HSI
787-6173-006	FLIGHT DIRECTOR IND.
787-6173-011	FLIGHT DIRECTOR IND.
787-6173-012	FLIGHT DIRECTOR IND.
792-6348-001	A/P CONTROLLER
8040	AIRSPEED INDICATOR
8040B-LX	ENCODING ALTIMETER
8047-700-1	2-INCH ALTIMETER
8047-700-5	2-INCH ALTIMETER
8047/10	2-INCH ALTIMETER
8059-2BFJ	AIRSPEED
8140B-35	ENCODING ALTIMETER
8220	MAX ALLOWABLE AIRSPEED
8240	MAX ALLOWABLE AIRSPEED INDICATOR
FAU751A-4	SMOKE DETECTOR
RD-AM8303	COCKPIT SPEAKER
518-28007-922	ENCODING ALTIMETER
519-28702-016	ENCODING ALTIMETER
519-28702-021	ENCODING ALTIMETER
519-28702-054	ENCODING ALTIMETER
519-28702-066	ENCODING ALTIMETER
519-28702-505	ENCODING ALTIMETER
519-28702-506	ENCODING ALTIMETER
519-28702-555	ENCODING ALTIMETER
519-28702-565	ENCODING ALTIMETER
519-28702-574	ENCODING ALTIMETER
519-28704-B4001	ENCODING ALTIMETER
522-2447-050	CONTROL UNIT
522-2447-225	CONTROL UNIT
61111-30	RPM INDICATOR
61121-04	PERCENT TORQUE IND.
61121-05	PERCENT TORQUE IND.
55050-0146	CABIN ALT/DIFF PRES IND.
5506-SG53-Y	ENCODING ALTIMETER
5506L-S	ALTITUDE ALERTER
5506L-S5	ALTITUDE ALERTER
5506L-SG	ALTITUDE ALERTER



570-24929-012	ENCODING ALTIMETER
622-0142-001	REMOTE HEADING AND COURSE SELECTOR
622-0224-001	ATTITUDE DIRECTOR IND.
622-1204-004	RADIO ALTITUDE IND.
622-2938-004	RADIO ALTITUDE IND.
622-3343-001	ATTITUDE DIRECTOR INDICATOR
622-4151-015	COURSE INDICATOR
622-4151-018	COURSE INDICATOR
622-4160-005	DIGITAL RADIO ALTITUDE INDICATOR
622-4160-007	DIGITAL RADIO ALTITUDE INDICATOR
622-4176-010	HSI
720-186	TRIM INDICATOR
64111-950-1	ALTIMETER
671CPX-10-051	SENSITIVE ALTIMETER
69-46114-11	ENGINE START MODULE ASSEMBLY
7000466-945	ATT. DIR. INDICATOR
7000469-916	HSI
7000469-923	HSI
7000836-922	ATT. DIR. INDICATOR
7000839-906	RADIO ALTIMETER INDICATOR
7001179-914	HORIZONTAL SITUATION INDICATOR
7001179-964	HSI
7002493-902	HSI
7002493-910	HSI
7003897-903	A/P CONTROLLER
7003897-907	A/P CONTROLLER
7003897-910	A/P CONTROLLER
7003897-918	A/P CONTROLLER
7003938-909	MS-400 MODE SELECTOR
772-5006-009	FLIGHT DIRECTOR IND
065-00053-0004	ALTITUDE SELECTOR/ALERter
066-03062-0011	ENCODING ALTIMETER
066-3042-01	RMI
066-3046-04	PICTORIAL NAVIGATION INDICATOR
066-3062-01	ENCODING ALTIMETER
101420-01249	PRESSURE REPORTING ALTIMETER
101627-01343	REPORTING ALTIMETER
101627-01696	REPORTING ALTIMETER
101635-11380	REPORTING ALTIMETER
101735-01723	ALTIMETER
101735-01727	ALTIMETER
128941-001	RELAY
152BL722	THERMOCOUPLE TEMPERATURE INDICATOR
15900-110	CABIN ALT/RATE/DIFF IND.
16007-311	ENCODING ALTIMETER
16007-B41	ENCODING ALTIMETER
16007-B45	ENCODING ALTIMETER
1611AM15	ALTIMETER
162BL709	ELECTRICAL RESISTANCE THERMOMETER



20040-11223	AIRSPED INDICATOR
20130-11276	MAX ALLOWABLE AIRSPEED
20130-11412	MAX ALLOW AIRSPEED
201530-11343	MAX ALLOWABLE AIRSPEED
24929-932	ENCODING ALTIMETER
25100-012	ALTITUDE ALERTER
25100-131	ALTITUDE ALERTER
214C50-2	ALTITUDE PRESSURE SWITCH
22702-013	ENCODING ALTIMETER
22702-032	ENCODING ALTIMETER
22702-041	ENCODING ALTIMETER
22702-122	ENCODING ALTIMETER
22719-002	VERTICAL SPEED IND.
22722-016	ALTITUDE ALERTER
23932-004	ALTIMETER
24929-003	ENCODING ALTIMETER
24929-025	ENCODING ALTIMETER
24929-105	ENCODING ALTIMETER
24929-413	ENCODING ALTIMETER
25850-630	MAAS/MACH INDICATOR
28702-584	ENCODING ALTIMETER
28702-951	ENCODING ALTIMETER
28702-955	ENCODING ALTIMETER
28704-003	ENCODING ALTIMETER
26465-860	MAAS/MACH INDICATOR
27-19121-3	HDRAULIC PRESSURE INDICATOR
27-19123-7	OXYGEN CYLINDER PRESSURE INDICATOR
27-19193-3	AIRSPED INDICATOR
28007-002	ENCODING ALTIMETER
28007-019	ENCODING ALTIMETER
28007-204	ENCODING ALTIMETER
28007-265	ENCODING ALTIMETER
28702-076	ENCODING ALTIMETER
28702-525	ENCODING ALTIMETER
28702-534	ENCODING ALTIMETER
28702-575	ENCODING ALTIMETER
29007-214	ENCODING ALTIMETER
29007-4095	ENCODING ALTIMETER
29007-4105	ENCODING ALTIMETER
29007-4111	ENCODING ALTIMETER
29007-4119	ENCODING ALTIMETER
29007-4131	ENCODING ALTIMETER
29007-4134	ENCODING ALTIMETER
29007-4207	ENCODING ALTIMETER
29007-4210	ENCODING ALTIMETER
29007-706	ENCODING ALTIMETER
29007-708	ENCODING ALTIMETER
29007-720	ENCODING ALTIMETER
29702-011	ENCODING ALTIMETER



29702-031	ENCODING ALTIMETER
29702-055	ENCODING ALTIMETER
29702-071	ENCODING ALTIMETER
29702-533	ENCODING ALTIMETER
29702-561	ENCODING ALTIMETER
29702-585	ENCODING ALTIMETER
29702-651	ENCODING ALTIMETER
30510-126	SDC/SAT/TAS COMPUTER
30980-135	SAT/TAS COMPUTER
3117LB64C	RMI
31400-002	PNEUMATIC ALTIMETER
31400-007	PNEUMATIC ALTIMETER
31400-012	PNEUMATIC ALTIMETER
31400-017	PNEUMATIC ALTIMETER
31400-115	PNEUMATIC ALTIMETER
35060-1175	VERTICAL SPEED
36148-1AJ25A1	RAD MAG COMP IND
36155-1AJ25A1	RAD MAG COMP IND.
38399-330	AIRSPEED INDICATOR
38399-AD-M	AIRSPEED INDICATOR
39948-E2903	MAX ALLOWABLE A/S
518-28007-024	ENCODING ALTIMETER
518-28007-204	ENCODING ALTIMETER
518-28007-302	ENCODING ALTIMETER
45100-D4111	ALTITUDE ALERTER
482-0011-020	RADIO MAGNETIC HEADING
49707-003	SERVO-PNEU ALT.
49707-102	SERVO-PNEU ALT.
49707-301	SERVO-PNEU ALT.
49707-304	SERVO-PNEU ALT.
5035P-P59	ENCODING ALTIMETER
519-28702-805	ENCODING ALTIMETER
518-28007-907	ENCODING ALTIMETER
3A43.32.50F.05.1.AB	2-INCH ALTIMETER
3A43.42.50F.05.1.DE	2-INCH ALTIMETER
422-18152-102	SDC MODULE
422-18152-107	SDC MODULE
422-18152-113	SDC MODULE
422-18152-121	SDC MODULE
422-18152-318	SDC MODULE
422-18152-334	SDC MODULE
422-18152-335	SDC MODULE
422-18152-812	SDC MODULE
422-18152-824	SDC MODULE
422-18152-842	SDC MODULE
422-18152-908	SDC MODULE
422-18152-938	SDC MODULE
422-18152-939	SDC MODULE
422-18152-946	SDC MODULE



422-23080-006	SDC MODULE
422-23080-010	SDC MODULE
422-23080-014	SDC MODULE
422-23080-015	SDC MODULE
422-23080-031	SDC MODULE
422-23080-032	SDC MODULE
422-23080-104	SDC MODULE
422-30510-152	SDC/SAT/TAS COMPUTER
422-30510-238	SDC MODULE
4010657-464	ATTITUDE DIRECTOR IND.
23080-007	SDC MODULE
23080-012	SDC MODULE
23080-020	SDC MODULE
23080-027	SDC MODULE
25850-203	MAAS/MACH INDICATOR
25850-205	MAAS/MACH INDICATOR
25850-214	MAAS/MACH INDICATOR
2591411-244	ATTITUDE DIRECTOR IND.
27-19116-5	VOLT/AMMETER
27-19133-005	PITCH TRIM INDICATOR
27-19139-1	RATE OF CLIMB
27-19157-003	PERCENT RPM INDICATOR
30510-142	SDCM/SAT/TAS COMPUTER
30510-147	SDCM/SAT/TAS COMPUTER
30980-164	SAT/TAS COMPUTER
30980-342	SAT/TAS COMPUTER
31500-494	MAX ALLOWABLE IND.
16007-136	ENCODING ALTIMETER
18152-124	SDC MODULE
520-5160-007	COURSE SELECTOR INDICATOR
521-29007-098	ENCODING ALTIMETER
521-29007-4024	ENCODING ALTIMETER
521-29007-4102	ENCODING ALTIMETER
521-29007-4112	ENCODING ALTIMETER
521-29007-4202	ENCODING ALTIMETER
521-29007-4211	ENCODING ALTIMETER
521-29007-4232	ENCODING ALTIMETER
521-29007-4800	ENCODING ALTIMETER
521-29007-714	ENCODING ALTIMETER
521-29007-804	ENCODING ALTIMETER
522-2447-552	RADIO SET CONTROL
523-29702-004	ENCODING ALTIMETER
523-29702-033	ENCODING ALTIMETER
523-29702-052	ENCODING ALTIMETER
523-29702-061	ENCODING ALTIMETER
523-29702-071	ENCODING ALTIMETER
523-29702-081	ENCODING ALTIMETER
523-29702-162	ENCODING ALTIMETER
523-29702-166	ENCODING ALTIMETER



523-29702-184	ENCODING ALTIMETER
523-29702-506	ENCODING ALTIMETER
523-29702-515	ENCODING ALTIMETER
523-29702-516	ENCODING ALTIMETER
523-29702-563	ENCODING ALTIMETER
523-29702-583	ENCODING ALTIMETER
523-29702-615	ENCODING ALTIMETER
523-29702-632	ENCODING ALTIMETER
523-29702-671	ENCODING ALTIMETER
523-29702-672	ENCODING ALTIMETER
523-29702-806	ENCODING ALTIMETER
523-29702-954	ENCODING ALTIMETER
523-29702-956	ENCODING ALTIMETER
527-48707-213	ALTITUDE
622-2313-070	FLIGHT GUIDANCE PANEL
622-2313-071	FLIGHT GUIDANCE PANEL
622-2313-072	FLIGHT GUIDANCE PANEL
540-23989-512	ALTITUDE ALERT
540-25100-033	ALTITUDE ALERTER
540-45100-C4010	ALTITUDE ALERTER
540-45100-D2010	ALTITUDE ALERTER
563-267	IND, DUAL PROP AMP
570-23932-013	PNEUMATIC ALTIMETER
570-24929-521	ENCODING ALTIMETER
570-24929-530	ENCODING ALTIMETER
571-25005-022	PNEUMATIC ENCODING ALTIMETER
571-25005-041	PNEUMATIC ENCODING ALTIMETER
571-25005-301	PNEUMATIC ENCODING ALTIMETER
571-25005-321	PNEUMATIC ENCODING ALTIMETER
575-25850-209	MAAS/MACH INDICATOR
575-25850-261	MAAS/MACH INDICATOR
575-25850-269	MAAS/MACH AIRSPEED
575-25850-272	MAAS/MACH AIRSPEED
575-25850-328	MAAS/MACH INDICATOR
575-25850-336	AIRSPEED IND
7018341-909	MODE SELECTOR
575-35250-301	MAAS/DIGITAL MACH INDICATOR
575-35250-303	MAAS/DIGITAL MACH INDICATOR
575-35900-701	MAX ALLOWABLE/MACH AIRSPEED IND.
622-2313-078	FLIGHT GUIDANCE PANEL
7000466-912	ATT. DIR. INDICATOR
622-6521-005	CONTROL NAV
422-30510-242	SDC MODULE
422-30510-253	SDC MODULE
422-30510-260	SDC MODULE
518-16007-132	ENCODING ALTIMETER
518-16007-348	ENCODING ALTIMETER
518-16007-701	ENCODING ALTIMETER
518-16007-715	ENCODING ALTIMETER



518-16007-814	ENCODING ALTIMETER
518-16007-815	ENCODING ALTIMETER
518-16007-816	ENCODING ALTIMETER
518-16007-817	ENCODING ALTIMETER
518-16007-983	ENCODING ALTIMETER
518-16007-B217	ENCODING ALTIMETER
518-16007-B42	ENCODING ALTIMETER
518-16007-B43	ENCODING ALTIMETER
518-16007-B45	ENCODING ALTIMETER
519-22702-012	ENCODING ALTIMETER
519-22702-023	ENCODING ALTIMETER
519-22702-031	ENCODING ALTIMETER
519-28702-926	ENCODING ALTIMETER
10280N01T00	ITT INDICATOR
522686	ITT INDICATOR
521875	ITT INDICATOR
065-0046-03	ALTITUDE SELECTOR
066-03046-0004	PICTORIAL NAVIGATION INDICATOR
066-03046-0008	PICTORIAL NAVIGATION INDICATOR
066-3042-02	RMI
066-3046-00	PICTORIAL NAVIGATION INDICATOR
066-3046-06	PICTORIAL NAVIGATION INDICATOR
101420-01223	PRESSURE REPORTING ALTIMETER
101720-01546	ALTIMETER
101720-01547	ALTIMETER
101720-11384	ALTIMETER
101720-11810	ALTIMETER
822-1120-004	CONTROL COM
822-1120-007	CONTROL COM
28007-272	ENCODING ALTIMETER
28007-348	ENCODING ALTIMETER
28702-005	ENCODING ALTIMETER
28702-021	ENCODING ALTIMETER
28702-026	ENCODING ALTIMETER
28702-065	ENCODING ALTIMETER
28702-504	ENCODING ALTIMETER
29007-212	ENCODING ALTIMETER
29007-4006	ENCODING ALTIMETER
29007-4011	ENCODING ALTIMETER
29007-4107	ENCODING ALTIMETER
29007-4116	ENCODING ALTIMETER
29007-4129	ENCODING ALTIMETER
29007-4133	ENCODING ALTIMETER
29007-4205	ENCODING ALTIMETER
29007-4304	ENCODING ALTIMETER
29007-4323	ENCODING ALTIMETER
29007-717	ENCODING ALTIMETER
29007-806	ENCODING ALTIMETER
29007-811	ENCODING ALTIMETER



29702-006	ENCODING ALTIMETER
29702-026	ENCODING ALTIMETER
29702-063	ENCODING ALTIMETER
29702-072	ENCODING ALTIMETER
29702-086	ENCODING ALTIMETER
29702-106	ENCODING ALTIMETER
4002531-903	ADI
4016341-905	BAROMETRIC ALTITUDE IND.
4016341-906	BAROMETRIC ALTITUDE IND.
4018368-914	MODE SELECTOR
4018368-921	MODE SELECTOR
518-28007-020	ENCODING ALTIMETER
518-28007-211	ENCODING ALTIMETER
518-28007-265	ENCODING ALTIMETER
518-28007-268	ENCODING ALTIMETER
518-28007-311	ENCODING ALTIMETER
518-28007-312	ENCODING ALTIMETER
518-28007-348	ENCODING ALTIMETER
5035P-P24	ENCODING ALTIMETER
518-28007-018	ENCODING ALTIMETER
519-28702-585	ENCODING ALTIMETER
519-28702-073	ENCODING ALTIMETER
519-28702-501	ENCODING ALTIMETER
519-28702-512	ENCODING ALTIMETER
522-2447-015	CONTROL UNIT
522-2447-053	CONTROL UNIT
522-2447-058	CONTROL UNIT
522-2447-269	CONTROL UNIT
522-2644-013	SLAVING ACCESSORY
522-3487-001	FLIGHT DIRECTOR IND.
522-4114-003	RADIO ALTITUDE INDICATOR
5506-S-4	ENCODING ALTIMETER
5506-S3-4	ENCODING ALTIMETER
563-010	CABIN AIR TEMPERATURE INDICATOR
563-083	ELECTRICAL LOAD IND.
570-24929-013	ENCODING ALTIMETER
570-24929-014	ENCODING ALTIMETER
622-0836-003	FLIGHT DIRECTOR INDICATOR
622-0944-006	FLIGHT MODE SELECTOR
622-0945-007	FLIGHT MODE SELECTOR
622-1205-002	RADIO ALTITUDE IND.
622-1352-007	FLIGHT DIRECTOR INDICATOR
570-24929-018	ENCODING ALTIMETER
570-24929-022	ENCODING ALTIMETER
570-24929-203	ENCODING ALTIMETER
570-24929-402	ENCODING ALTIMETER
570-31400-001	PNEUMATIC ALTIMETER
570-31400-115	PNEUMATIC ALTIMETER
622-3594-006	FLIGHT DIRECTOR IND.



622-3702-001	BEARING DISTANCE INDICATOR
622-4151-011	COURSE INDICATOR
622-4151-016	COURSE INDICATOR
622-4176-011	HSI
622-4938-004	RMI-30
720-295	TRIM INDICATOR
622-4938-027	RMI-30
64111-953-1	ALTIMETER
7000466-918	ATT. DIR. INDICATOR
7000466-936	ATT. DIR. INDICATOR
7000469-904	HSI
7000469-919	HSI
7000469-920	HSI
7000605-902	MOEDE SELECTOR
7000605-905	MODE SELECTOR
7000605-909	MODE SELECTOR
7000836-902	ADI
7000839-903	RADIO ALTIMETER INDICATOR
7001179-901	HORIZONTAL SITUATION INDICATOR
7001179-912	HORIZONTAL SITUATION IND.
7001182-917	ATTITUDE DIRECTOR INDICATOR
7003938-902	MODE SELECTOR
7003938-904	MS-400 MODE SELECTOR
772-5005-007	FLIGHT DIRECTOR INDICATOR
772-5006-006	FLIGHT DIRECTOR IND
772-5006-011	FLIGHT DIRECTOR IND
787-6173-013	FLIGHT DIRECTOR IND.
787-6173-202	FLIGHT DIRECTOR IND.
787-6173-203	FLIGHT DIRECTOR IND.
792-6091-008	HSI
792-6091-016	HSI
792-6348-101	A/P CONTROLLER
792-6348-102	A/P CONTROLLER
792-6703-002	FLIGHT COMPUTER
8047/20	2-INCH ALTIMETER
820-600	INDICATOR
820-643	INDICATOR
820-661	TRI-UNIT IND.
9813-25-12	DUAL TORQUE INDICATOR
A218-862240-00	ENGINE FIRE SHUT-OFF SWITCH
A50-MA-4	PRESSURE ALTIMETER
FAU751A-3	SMOKE DETECTOR
JG873A4	MASTER TAS IND
SEL-OC19D	EGT INDICATOR
16007-1312	ENCODING ALTIMETER
16007-137	ENCODING ALTIMETER
SLZ9190	IVSI
WL1150AMMS1	SERVO ALTIMETER
WL1350AMMS2	COUNTER/POINTER ALTIMETER



WL1404AMMS2	SERVO ALTIMETER
066-03064-0005	ENCODING ALTIMETER
066-3024-32	PICTORIAL NAVIGATION INDICATOR
066-3024-41	PICTORIAL NAVIGATION INDICATOR
101730-11388	ALTIMETER
124.115-3	DUAL TEMP/PRESS IND
124.115-5	DUAL TEMP/PRESS IND
15900-1410	CABIN ALT/RATE/DIFF IND.
16007-762	ENCODING ALTIMETER
1611AM10	ALTIMETER
1611AM14	ALTIMETER
162BL709A	ELECTRICAL RESISTANCE THERMOMETER
1784460-656	GYROSYN COMPASS IND
20040-11231	AIRSPEED INDICATOR
20130-11225	MAX ALLOWABLE AIRSPEED
25005-012	PNEUMATIC ENC. ALTIMETER
25100-003	ALTITUDE ALERTER
25100-133	ALTITUDE ALERTER
29702-132	ENCODING ALTIMETER
29702-155	ENCODING ALTIMETER
29702-172	ENCODING ALTIMETER
29702-175	ENCODING ALTIMETER
29702-516	ENCODING ALTIMETER
29702-523	ENCODING ALTIMETER
29702-551	ENCODING ALTIMETER
29702-576	ENCODING ALTIMETER
29702-632	ENCODING ALTIMETER
29846-205	MAX ALLOWABLE AIRSPEED MACH IND.
30260-1166	VERTICAL SPEED IND.
3137LB64C	RMI
35250-201	MAXIMUM ALLOWABLE AIRSPEED
35250-451	MAXIMUM ALLOWABLE AIRSPEED
35900-502	MAX ALLOWABLE A/S
36148-1AJ25A2	RAD MAG COMP IND
37230-008	MAXIMUM ALLOWABLE AIRSPEED/MACH IND
38399-AC-M	AIRSPEED INDICATOR
39380-103	AIR DATA UNIT
224-902-002	IND, N1 PERCENT RPM
22719-001	VERTICAL SPEED IND.
22722-002	ALTITUDE ALERTER
22722-015	ALTITUDE ALERTER
22722-017	ALTITUDE ALERTER
22722-019	ALTITUDE ALERTER
233T4222-26	INTER/JACK PANEL ASSY.
23932-981	PNEUMATIC ALTIMETER
24929-028	ENCODING ALTIMETER
24929-204	ENCODING ALTIMETER
28704-012	ENCODING ALTIMETER
29007-023	ENCODING ALTIMETER



29007-102	ENCODING ALTIMETER
270-2436-070	CONTROL UNIT
28007-022	ENCODING ALTIMETER
28007-029	ENCODING ALTIMETER
28007-233	ENCODING ALTIMETER
28007-234	ENCODING ALTIMETER
233T4222-7	INTER/JACK PANEL ASSY.
25005-121	PNEUMATIC ENCODING ALTIMETER
25850-219	MAAS/MACH INDICATOR
25850-319	MAAS/MACH INDICATOR
27-19124-003	DEICE PRESSURE INDICATOR
27-19160-5	OIL TEMPERATURE PRESSURE INDICATOR
622-2937-011	RADIO ALTITUDE IND
285T0022-36	AUDIO SELECTOR PANEL
422-18152-119	SDC MODULE
422-18152-313	SDC MODULE
422-18152-333	SDC MODULE
422-18152-802	SDC MODULE
422-18152-811	SDC MODULE
422-18152-821	SDC MODULE
422-18152-823	SDC MODULE
422-18152-835	SDC MODULE
422-18152-840	SDC MODULE
422-23080-002	SDC MODULE
422-23080-005	SDC MODULE
422-23080-013	SDC MODULE
422-23080-030	SDC MODULE
422-23080-033	SDC MODULE
422-23080-116	SDC MODULE
422-23080-137	SDC MODULE
422-30510-102	SDC/SAT/TAS COMPUTER
422-30510-107	SDC/SAT/TAS COMPUTER
422-30510-129	SDC/SAT/TAS COMPUTER
422-30510-132	SDC/SAT/TAS COMPUTER
422-30510-138	SDC/SAT/TAS COMPUTER
422-30510-207	SDC MODULE
422-30510-251	SDC MODULE
422-30510-267	SDC MODULE
29007-4235	ENCODING ALTIMETER
518-16007-B48	ENCODING ALTIMETER
519-22702-022	ENCODING ALTIMETER
519-22702-122	ENCODING ALTIMETER
521-29007-017	ENCODING ALTIMETER
521-29007-018	ENCODING ALTIMETER
521-29007-108	ENCODING ALTIMETER
521-29007-4096	ENCODING ALTIMETER
521-29007-4108	ENCODING ALTIMETER
521-29007-4117	ENCODING ALTIMETER
521-29007-4125	ENCODING ALTIMETER



521-29007-4131	ENCODING ALTIMETER
521-29007-4228	ENCODING ALTIMETER
521-29007-4230	ENCODING ALTIMETER
521-29007-4302	ENCODING ALTIMETER
521-29007-4324	ENCODING ALTIMETER
521-29007-807	ENCODING ALTIMETER
521-29007-808	ENCODING ALTIMETER
521-29007-815	ENCODING ALTIMETER
521-29007-816	ENCODING ALTIMETER
521-29007-818	ENCODING ALTIMETER
30510-117	SDCM/SAT/TAS COMPUTER
30980-364	SAT/TAS COMPUTER
522-3617-503	RADIO CONTROL SET
522-3700-004	FLIGHT DIRECTOR IND.
523-29702-006	ENCODING ALTIMETER
523-29702-012	ENCODING ALTIMETER
523-29702-062	ENCODING ALTIMETER
523-29702-064	ENCODING ALTIMETER
523-29702-112	ENCODING ALTIMETER
523-29702-131	ENCODING ALTIMETER
523-29702-181	ENCODING ALTIMETER
523-29702-686	ENCODING ALTIMETER
3A43.42.35F.05.1.AB	2-INCH ALTIMETER
527-48707-201	ALTIMETER
527-48707-203	ALTIMETER
518-16007-413	ENCODING ALTIMETER
518-16007-501	ENCODING ALTIMETER
518-16007-813	ENCODING ALTIMETER
518-16007-984	ENCODING ALTIMETER
18152-123	SDC MODULE
18152-313	SDC MODULE
622-2265-058	FLIGHT GUIDANCE PANEL
622-3702-005	BEARING DISTANCE INDICATOR
622-3702-006	BEARING DISTANCE INDICATOR
622-3702-012	BEARING DISTANCE INDICATOR
622-6522-002	CONTROL ADF
7000466-953	ATT. DIR. INDICATOR
527-48707-214	ALTIMETER
540-22722-935	ALTITUDE ALERTER
540-23989-004	ALTITUDE ALERTER
540-23989-011	ALTITUDE ALERTER
540-25100-011	ALTITUDE ALERTER
540-25100-032	ALTITUDE ALERTER
622-0141-004	CONTROL, AUTO PILOT
570-23932-011	PNEUMATIC ALTIMETER
570-23932-012	PNEUMATIC ALTIMETER
570-23932-053	PNEUMATIC ALTIMETER
570-23932-401	PNEUMATIC ALTIMETER
570-24929-520	ENCODING ALTIMETER



570-44929-013	ALTIMETER
571-25005-202	PNEUMATIC ENCODING ALTIMETER
571-29020-412	ALTIMETER
575-25850-329	MAAS/MACH INDICATOR
575-25850-630	MAAS/MACH INDICATOR
575-29846-308	MAX ALLOW/MACH AIRSPEED IND
575-35250-403	MAAS/DIGITAL MACH INDICATOR
575-35250-515	MACH AIRSPEED INDICATOR
B0063-81103	ALTIMETER
B0063-81108	ALTIMETER
065-00053-0006	ALTITUDE SELECTOR/ALERTER
066-3024-09	PICTORIAL NAV IND.
066-3024-17	PICTORIAL NAV IND.
066-3046-08	PICTORIAL NAVIGATION IND.
066-3062-08	ENCODING ALTIMETER
101435-01262	PRESSURE REPORTING ALTIMETER
101450-01280	PRESSURE REPORTING ALTIMETER
101617-11374	REPORTING ALTIMETER
101627-11376	REPORTING ALTIMETER
101720-01355	ALTIMETER
101720-111007	ALTIMETER
101730-01387	ALTIMETER
152BL702D	THERMOCOUPLE TEMPERATURE INDICATOR
16007-162	ENCODING ALTIMETER
16007-167	ENCODING ALTIMETER
16007-178	ENCODING ALTIMETER
1611AM13	ALTIMETER
20018-11308	AIRSPEED INDICATOR
20020-11241	AIRSPEED INDICATOR
20130-11227	MAX ALLOWABLE AIRSPEED
20130-11358	MAX/ALLOW AIRSPEED
25100-002	ALTITUDE ALERTER
22702-011	ENCODING ALTIMETER
22702-341	ENCODING ALTIMETER
22722-001	ALTITUDE ALERTER
23932-303	ALTIMETER
23989-005	ALTITUDE ALERTER
24929-214	ENCODING ALTIMETER
24929-520	ENCODING ALTIMETER
24929-530	ENCODING ALTIMETER
24929-920	ENCODING ALTIMETER
28702-583	ENCODING ALTIMETER
28702-805	ENCODING ALTIMETER
2684147-804	MACH AIRSPEED IND
27-19137-23	AIRSPEED INDICATOR
270-2436-030	CONTROL UNIT
276AS1	MAX/ALLOW AIRSPEED
519-28702-072	ENCODING ALTIMETER
519-28702-075	ENCODING ALTIMETER



519-28702-085	ENCODING ALTIMETER
519-28702-523	ENCODING ALTIMETER
519-28702-571	ENCODING ALTIMETER
519-28702-958	ENCODING ALTIMETER
519-28704-011	ENCODING ALTIMETER
519-28704-A4001	ENCODING ALTIMETER
522-2447-046	CONTROL UNIT
522-2447-215	CONTROL UNIT
5934PAD-1	PRESSURE ALTIMETER
522-3487-002	FLIGHT DIRECTOR IND.
5506-S5-Y	ENCODING ALTIMETER
5506-SG53-Y4	ENCODING ALTIMETER
5506L-S51	ALTITUDE ALERTER
5506L-SG52	ALTITUDE ALERTER
622-0142-002	REMOTE HEADING AND COURSE SELECTOR
622-0945-017	FLIGHT MODE SELECTOR
622-1204-001	RADIO ALTITUDE IND.
622-1205-003	RADIO ALTITUDE IND.
622-1406-001	REMOTE HDG/CRS SEL
622-2506-004	RADIO MAGNETIC IND.
622-2937-001	RADIO ALTITUDE IND.
570-24929-015	ENCODING ALTIMETER
570-24929-026	ENCODING ALTIMETER
570-24929-201	ENCODING ALTIMETER
570-24929-301	ENCODING ALTIMETER
570-24929-303	ENCODING ALTIMETER
570-31400-012	PNEUMATIC ALTIMETER
622-3343-002	ATTITUDE DIRECTOR INDICATOR
622-3594-003	FLIGHT DIRECTOR IND.
622-4151-004	HORIZONTAL SITUATION INDICAT
622-4151-008	COURSE INDICATOR
622-4160-004	DIGITAL RADIO ALTITUDE INDICATOR
622-4808-002	ATTITUDE DIRECTOR IND.
622-4808-008	ATTITUDE DIRECTOR IND.
7160	IVSI
622-4938-026	RMI-30
64111-952-1	ALTIMETER
64141-370-1	ALTIMETER
64141-372-1	ALTIMETER
64141-530-1	COUNTER/POINTER ALTIMETER
64141-590-1	ALTIMETER
7000466-935	ATT. DIR. INDICATOR
7000469-907	HSI
7000469-912	HSI
7000836-907	ADI
7000836-915	ATTITUDE REFERENCE INDICATOR
7000836-918	ATTITUDE DIRECTOR INDICATOR
7001182-911	ATTITUDE DIRECTOR INDICATOR
7001182-916	ATTITUDE DIRECTOR INDICATOR



7001182-919	ATTITUDE DIRECTOR INDICATOR
7002493-906	HSI
7003897-904	A/P CONTROLLER
7003938-913	MS-400 MODE SELECTOR
7030B	VSI/IVSI
7100	VSI/IVSI
7100B	VSI/IVSI
28007-023	ENCODING ALTIMETER
28007-177	ENCODING ALTIMETER
28007-211	ENCODING ALTIMETER
28007-227	ENCODING ALTIMETER
28007-302	ENCODING ALTIMETER
28702-064	ENCODING ALTIMETER
28702-081	ENCODING ALTIMETER
28702-506	ENCODING ALTIMETER
29007-211	ENCODING ALTIMETER
29007-4019	ENCODING ALTIMETER
29007-4097	ENCODING ALTIMETER
29007-4098	ENCODING ALTIMETER
29007-4108	ENCODING ALTIMETER
29007-4118	ENCODING ALTIMETER
29007-4215	ENCODING ALTIMETER
29007-4719	ENCODING ALTIMETER
29007-701	ENCODING ALTIMETER
29007-802	ENCODING ALTIMETER
29702-004	ENCODING ALTIMETER
29702-036	ENCODING ALTIMETER
29702-053	ENCODING ALTIMETER
29702-084	ENCODING ALTIMETER
29702-162	ENCODING ALTIMETER
29702-164	ENCODING ALTIMETER
29702-174	ENCODING ALTIMETER
29702-183	ENCODING ALTIMETER
29702-184	ENCODING ALTIMETER
29702-501	ENCODING ALTIMETER
29702-565	ENCODING ALTIMETER
29702-573	ENCODING ALTIMETER
29702-604	ENCODING ALTIMETER
29702-631	ENCODING ALTIMETER
29702-676	ENCODING ALTIMETER
30510-135	SDCM/SAT/TAS COMPUTER
31400-117	PNEUMATIC ALTIMETER
38399-330-02	AIRSPEED INDICATOR
3A43.22.20F.05.1.AL	2 INCH ALTIMETER
4018368-904	MODE SELECTOR
4018368-913	MODE SELECTOR
518-28007-027	ENCODING ALTIMETER
518-28007-172	ENCODING ALTIMETER
518-28007-215	ENCODING ALTIMETER



518-28007-216	ENCODING ALTIMETER
518-28007-235	ENCODING ALTIMETER
518-28007-272	ENCODING ALTIMETER
518-28007-347	ENCODING ALTIMETER
4018639-931	AUTO PILOT CONTROL
4027170-901	HSI
4029529-902	HSI
45100-C1010	ALTITUDE ALERTER
45100-D4010	ALTITUDE ALERTER
501-1228-07	EMERGENCY POWER SPLY
5035P2-P42	ENCODING ALTIMETER
51-4226-A1	BATTERY TEMP IND
519-28702-002	ENCODING ALTIMETER
519-28702-036	ENCODING ALTIMETER
519-28702-052	ENCODING ALTIMETER
519-28702-065	ENCODING ALTIMETER
172934-001	SELECTOR SWITCH
WL102AMS3	STANDBY INDICATOR
WL1150AMMS4	SERVO ALTIMETER
WL1381AMMS4	COUNTER/POINTER ALTIMETER
WL1403AMMS2	SERVO ALTIMETER
WL1605AM5	COUNTER POINTER ALTIMETER
WL1609AM2	COUNTER POINTER ALTIMETER
066-03020-0002	FLIGHT COMMAND IND.
066-03020-0012	FLIGHT COMMAND IND.
066-03044-0003	RADAR ALTIMETER INDICATOR
066-3020-03	FLIGHT COMMAND IND.
16007-133	ENCODING ALTIMETER
066-3024-38	PICTORIAL NAVIGATION INDICATOR
066-3024-48	PICTORIAL NAVIGATION INDICATOR
23080-004	SDC MODULE
23080-010	SDC MODULE
25005-052	PNEUMATIC ENCODING ALTIMETER
25005-201	PNEUMATIC ENCODING ALTIMETER
25850-213	MAAS/MACH INDICATOR
25850-305	MAAS/MACH INDICATOR
25850-315	MAAS/MACH INDICATOR
25850-336	MAAS/MACH INDICATOR
25850-343	MAAS/MACH INDICATOR
2591411-265	ATTITUDE DIRECTOR INDICATOR
18152-105	SDC MODULE
18152-108	SDC MODULE
18152-110	SDC MODULE
18152-115	SDC MODULE
18152-120	SDC MODULE
18152-321	SDC MODULE
114-380004-7	ITT INDICATOR
20040-11217	AIRSPED INDICATOR
772-5006-003	FLIGHT DIRECTOR IND



772-5006-007	FLIGHT DIRECTOR IND
772-5370-002	COURSE INDICATOR
787-6173-004	FLIGHT DIRECTOR IND.
787-6173-208	FLIGHT DIRECTOR IND.
792-6091-013	HSI
792-6348-005	A/P CONTROLLER
792-6703-001	FLIGHT COMPUTER
820-644	INDICATOR
8502-900-1	MAXIMUM ALLOWABLE AIRSPEED IND.
MML-OC19AT	LIGHTED EGT IND. W/DIGITAL READOUT
RD-AM8303-01	COCKPIT SPEAKER
SEL-O19BW	TOT INDICATOR
SLZ7011A	IVSI
SLZ9123	IVSI
SLZ9127	IVSI
SLZ9141	IVSI
SLZ9157-1	IVSI
B0200-81110	AIRSPEEDDATA
B0200-81111	AIRSPEEDDATA
285T0022-40	AUDIO SELECTOR PANEL
3A67.32.20F.05.1.KR	ENCODING ALTIMETER
523-29702-021	ENCODING ALTIMETER
523-29702-063	ENCODING ALTIMETER
523-29702-074	ENCODING ALTIMETER
523-29702-084	ENCODING ALTIMETER
523-29702-103	ENCODING ALTIMETER
523-29702-124	ENCODING ALTIMETER
523-29702-154	ENCODING ALTIMETER
523-29702-634	ENCODING ALTIMETER
523-29702-801	ENCODING ALTIMETER
523-29702-907	ENCODING ALTIMETER
540-22722-035	ALTITUDE ALERTER
540-25100-005	ALTITUDE ALERTER
540-25100-013	ALTITUDE ALERTER
540-25100-022	ALTITUDE ALERTER
540-45100-C1010	ALTITUDE ALERTER
540-45100-D4111	ALTITUDE ALERTER
570-23932-034	PNEUMATIC ALTIMETER
570-24929-519	ENCODING ALTIMETER
570-31400-018	PNEUMATIC ALTIMETER
622-2313-053	FLIGHT GUIDANCE PANEL
422-18152-120	SDC MODULE
422-18152-134	SDC MODULE
422-18152-138	SDC MODULE
422-18152-302	SDC MODULE
422-18152-304	SDC MODULE
422-18152-308	SDC MODULE
422-18152-314	SDC MODULE
422-18152-328	SDC MODULE



422-18152-339	SDC MODULE
422-18152-349	SDC MODULE
422-18152-803	SDC MODULE
422-18152-805	SDC MODULE
422-18152-818	SDC MODULE
422-18152-829	SDC MODULE
422-18152-831	SDC MODULE
422-18152-848	SDC MODULE
422-18152-911	SDC MODULE
422-18152-915	SDC MODULE
422-18152-918	SDC MODULE
422-18152-925	SDC MODULE
422-23080-018	SDC MODULE
422-23080-043	SDC MODULE
422-30510-117	SDC/SAT/TAS COMPUTER
422-30510-151	SDC/SAT/TAS COMPUTER
422-30510-169	SDC/SAT/TAS COMPUTER
422-30510-170	SDC/SAT/TAS COMPUTER
422-30510-240	SDC MODULE
622-3702-003	BEARING DISTANCE INDICATOR
422-30510-244	SDC MODULE
422-30510-264	SDC MODULE
570-31400-031	PNEUMATIC ALTIMETER
570-31400-033	PNEUMATIC ALTIMETER
570-44929-935	ENCODING ALTIMETER
571-25005-101	PNEUMATIC ENCODING ALTIMETER
575-25850-235	MAAS/MACH INDICATOR
575-25850-302	MAAS/MACH AIRSPEED
575-25850-304	MAAS/MACH INIDICATOR
575-26465-911	MAAS/MACH INDICATOR
575-29846-301	MACH AIRSPEED INDICATOR
575-35250-501	MAAS/DIGITAL MACH INDICATOR
575-35250-551	MAAS/DIGITAL MACH INDICATOR
575-35900-502	MAX ALLOWABLE/MACH AIRSPEED IND.
575-35900-512	MACH AIRSPEED INDICATOR
575-35900-602	MAX ALLOWABLE/MACH AIRSPEED IND.
518-16007-312	ENCODING ALTIMETER
518-16007-338	ENCODING ALTIMETER
518-16007-347	ENCODING ALTIMETER
518-16007-702	ENCODING ALTIMETER
518-16007-703	ENCODING ALTIMETER
518-16007-808	ENCODING ALTIMETER
518-28007-244	ENCODING ALTIMETER
518-28007-925	ENCODING ALTIMETER
519-22702-043	ENCODING ALTIMETER
519-22702-341	ENCODING ALTIMETER
519-22702-543	ENCODING ALTIMETER
519-28704-F2101	ENCODING ALTIMETER
521-29007-104	ENCODING ALTIMETER



521-29007-207	ENCODING ALTIMETER
521-29007-4027	ALTIMETER
521-29007-709	ENCODING ALTIMETER
521-29007-805	ENCODING ALTIMETER
2592920-044	RADIO DEVIATION IND.
30510-127	SDCM/SAT/TAS COMPUTER
30510-136	SDCM/SAT/TAS COMPUTER
30510-138	SDCM/SAT/TAS COMPUTER
30980-105	SAT/TAS COMPUTER
30980-130	SAT/TAS COMPUTER
30980-138	SAT/TAS COMPUTER
30980-327	SAT/TAS COMPUTER
27-19133-5	PITCH TRIM INDICATOR
7000466-907	ATTITUDE DIRECTOR INDICATOR
7000466-914	ATT. DIR. INDICATOR
622-6521-015	CONTROL NAV
622-6521-025	CONTROL NAV
622-6522-013	CONTROL ADF
622-6523-204	CONTROL TRANS
3A43.22.50F.05.1.EN	2 INCH ALTIMETER
3A43.22.50F.05.1.AB	2 INCH ALTIMETER
3A42.22.15M.05.1.BB	2 INCH ALTIMETER
3A43.22.35F.28.1.FU	2 INCH ALTIMETER
3A43.22.35F.05.1.HL	2 INCH ALTIMETER
6223	FUEL PRESSURE GAGE
4018368-910	MODE SELECTOR
4018368-917	MODE SELECTOR
4018639-906	AUTOPILOT CONTROL
518-28007-171	ENCODING ALTIMETER
518-28007-223	ENCODING ALTIMETER
518-28007-229	ENCODING ALTIMETER
518-28007-317	ENCODING ALTIMETER
518-28007-341	ENCODING ALTIMETER
518-28007-345	ENCODING ALTIMETER
45100-D2012	ALTITUDE ALERTER
49707-002	SERVO-PNEU ALT.
501-1075-02	EMERGENCY POWER SUPPLY
501-1075-13	EMERGENCY POWER SUPPLY
5035P-P46	ENCODING ALTIMETER
518-28007-017	ENCODING ALTIMETER
519-28702-802	ENCODING ALTIMETER
519-28702-024	ENCODING ALTIMETER
519-28702-031	ENCODING ALTIMETER
519-28702-513	ENCODING ALTIMETER
519-28702-516	ENCODING ALTIMETER
519-28702-533	ENCODING ALTIMETER
519-28702-575	ENCODING ALTIMETER
519-28704-001	ENCODING ALTIMETER
522-2447-005	CONTROL UNIT



522-2447-035	CONTROL UNIT
522-2638-008	COURSE INDICATOR
522-2782-034	COURSE INDICATOR
5934D-3	PRESSURE ALTIMETER
6122	MANIFOLD PRESSURE GAGE
522-3487-004	FLIGHT DIRECTOR IND.
522-3867-001	FLIGHT DIRECTOR IND.
5506-SG5-Y	ENCODING ALTIMETER
563-070	OXYGEN CYLINDER PRESSURE INDICATOR
570-24929-003	ENCODING ALTIMETER
570-24929-004	ENCODING ALTIMETER
570-24929-008	ENCODING ALTIMETER
622-0555-005	RADIO MAGNETIC IND.
622-0555-008	RADIO MAGNETIC IND.
622-0555-010	RADIO MAGNETIC IND.
SEDL-OC29J	NH/NL%RPM INDICATOR
SEL-OC19EA	T6 ITT INDICATOR
SEL019BD	TOT INDICATOR
16650-1142	STANDBY ALTIMETER
SLZ9158	IVSI
WL102AMS1	STANDBY INDICATOR
WL1404AMMS4	SERVO ALTIMETER
065-00053-0008	ALTITUDE SELECTOR/ALERter
065-0053-00	ALTITUDE SELECTOR/ALERter
065-0053-01	ALTITUDE SELECTOR/ALERter
066-03042-0000	RMI
066-03046-0010	PICTORIAL NAVIGATION INDICATOR
066-3020-11	FLIGHT COMMAND IND.
066-3024-12	PICTORIAL NAV INC.
066-3024-47	PICTORIAL NAV IND.
066-3042-00	RMI
10035-11244	ALTIMETER
101435-01268	PRESSURE REPORTING ALTIMETER
101450-01217	PRESSURE REPORTING ALTIMETER
101450-01218	PRESSURE REPORTING ALTIMETER
152BL702E	THERMOCOUPLE TEMPERATURE INDICATOR
152BL704	THERMOCOUPLE TEMPERATURE INDICATOR
152BL802B	THERMOCOUPLE TEMPERATURE INDICATOR
152BL803C	THERMOCOUPLE TEMPERATURE INDICATOR
162BL710	ELECTRICAL RESISTANCE THERMOMETER
20130-11228	MAX ALLOWABLE AIRSPEED
25100-022	ALTITUDE ALERter
25100-023	ALTITUDE ALERter
22702-543	ENCODING ALTIMETER
22719-004	VERTICAL SPEED IND.
229-9016-010	AIRSPEED SENSOR
233T3239-302	CARGO HAT PANEL
23932-106	ALTIMETER
23932-402	ALTIMETER



23932-901	ALTIMETER
23989-312	ALTITUDE ALERTER
23989-501	ALTITUDE ALERTER
24929-011	ENCODING ALTIMETER
622-1204-007	RADIO ALTITUDE IND.
622-2937-004	RADIO ALTITUDE IND
622-2937-006	RADIO ALTITUDE INDICATOR
570-24929-213	ENCODING ALTIMETER
622-4151-007	COURSE INDICATOR
622-4507-001	ATTITUDE DIRECTION INDICATOR
622-4938-003	RMI-30
7200	VSI/IVSI
671CPX-10-05	SENSITIVE ALTIMETER
7000466-902	ATT. DIR. INDICATOR
7000469-905	HSI
7000469-908	HSI
7000469-913	HSI
7000836-901	ADI
7000836-919	ATTITUDE DIRECTOR INDICATOR
7000839-901	RADIO ALTIMETER INDICATOR
7001179-905	HORIZONTAL SITUATION INDICATOR
7001179-951	HSI
7001179-958	HSI
7001182-902	ATTITUDE DIRECTOR IND.
7001182-909	ATTITUDE DIRECTOR IND.
24929-013	ENCODING ALTIMETER
24929-014	ENCODING ALTIMETER
24929-016	ENCODING ALTIMETER
24929-023	ENCODING ALTIMETER
24929-027	ENCODING ALTIMETER
24929-304	ENCODING ALTIMETER
24929-314	ENCODING ALTIMETER
24929-922	ENCODING ALTIMETER
28702-904	ENCODING ALTIMETER
28704-A4001	ENCODING ALTIMETER
29007-018	ENCODING ALTIMETER
4018639-907	AUTOPILOT CONTROL
27-19144-7	ALCOHOL WATER INJECTION QTY. IND.
27-19193-27	AIRSPEED INDICATOR
270-2436-010	CONTROL UNIT
28007-018	ENCODING ALTIMETER
28007-027	ENCODING ALTIMETER
28007-203	ENCODING ALTIMETER
28007-210	ENCODING ALTIMETER
28007-212	ENCODING ALTIMETER
28007-213	ENCODING ALTIMETER
28007-228	ENCODING ALTIMETER
28007-267	ENCODING ALTIMETER
28007-431	ENCODING ALTIMETER



7003897-913	A/P CONTROLLER
7003897-917	A/P CONTROLLER
7003938-905	MS-400 MODE SELECTOR
7003938-906	MODE SELECTOR
7003938-926	MS-400 MODE SELECTOR
7060	VSI/IVSI
7120	VSI/IVSI
787-6173-017	FLIGHT DIRECTOR IND.
787-6173-213	FLIGHT DIRECTOR IND.
792-6221-002	REMOTE HDG/CRS SEL
792-6221-005	REMOTE HDG/CRS SEL
792-6356-003	COURSE INDICATOR
8000T	AIRSPED INDICATOR
8040B-MB-LX	ENCODING ALTIMETER
820-647	INDICATOR
8230L	MAX ALLOWABLE AIRSPEED INDICATOR
28007-921	ENCODING ALTIMETER
28007-922	ENCODING ALTIMETER
28702-016	ENCODING ALTIMETER
28702-074	ENCODING ALTIMETER
28702-082	ENCODING ALTIMETER
28702-084	ENCODING ALTIMETER
28702-531	ENCODING ALTIMETER
28702-576	ENCODING ALTIMETER
29007-203	ENCODING ALTIMETER
29007-210	ENCODING ALTIMETER
29007-4024	ENCODING ALTIMETER
29007-4104	ENCODING ALTIMETER
29007-4212	ENCODING ALTIMETER
29007-4706	ENCODING ALTIMETER
29007-4820	ENCODING ALTIMETER
29007-703	ENCODING ALTIMETER
29007-807	ENCODING ALTIMETER
29020-012	PNEUMATIC ALTIMETER
29702-001	ENCODING ALTIMETER
29702-133	ENCODING ALTIMETER
29702-136	ENCODING ALTIMETER
29702-152	ENCODING ALTIMETER
29702-166	ENCODING ALTIMETER
29702-185	ENCODING ALTIMETER
29702-513	ENCODING ALTIMETER
9813-25-07	DUAL TORQUE INDICATOR
29702-524	ENCODING ALTIMETER
29702-556	ENCODING ALTIMETER
29702-575	ENCODING ALTIMETER
29702-601	ENCODING ALTIMETER
29702-605	ENCODING ALTIMETER
29702-625	ENCODING ALTIMETER
29846-305	MAX ALLOWABLE AIRSPEED/MACH IND.



30-1521-5	REAR-POSITION NAVIGATION LIGHT
30230-1174	VERTICAL SPEED
30980-124	SAT/TAS COMPUTER
3117LB21C	RMI
31400-104	PNEUMATIC ALTIMETER
31500-495	MAX ALLOWABLE IND.
35250-351	MAXIMUM ALLOWABLE AIRSPEED
35250-402	MAX ALLOWABLE AIRSPEED
37230-007	MAX. ALLOWABLE AIRSPEED IND.
114-380009-5	OIL TEMP & PRESS IND
218-901-002	N2 INDICATOR
622-9851-003	CONTROL NAV
622-9851-004	CONTROL NAV
622-9851-005	CONTROL NAV
622-9851-006	CONTROL NAV
30510-152	SDCM/SAT/TAS COMPUTER
30980-133	SAT/TAS COMPUTER
30980-341	SAT/TAS COMPUTER
30980-367	SAT/TAS COMPUTER
18152-112	SDC MODULE
18152-117	SDC MODULE
23080-002	SDC MODULE
25850-210	MAAS/MACH INDICATOR
25850-334	MAAS/MACH INDICATOR
25850-361	MAAS/MACH INDICATOR
25850-369	MAAS/MACH INDICATOR
20040-11173	AIRSPEED INDICATOR
20040-11175	AIRSPEED INDICATOR
20040-11224	AIRSPEED INDICATOR
27-19123-007	OXYGEN CYLINDER PRESSURE INDICATOR
066-03031-0003	RADAR ALTIMETER INDICATOR
066-03064-0002	Encoding Altimeter
066-3024-02	PICTORIAL NAVIGATION INDICATOR
3A42.32.15M.28.3.AB	2-INCH ALTIMETER
422-18152-050	SDC MODULE
422-18152-109	SDC MODULE
422-18152-110	SDC MODULE
422-18152-124	SDC MODULE
422-18152-127	SDC MODULE
422-18152-130	SDC MODULE
422-18152-305	SDC MODULE
422-18152-310	SDC MODULE
422-18152-348	SDC MODULE
422-18152-809	SDC MODULE
422-18152-827	SDC MODULE
422-18152-903	SDC MODULE
422-18152-909	SDC MODULE
422-18152-937	SDC MODULE
422-23080-012	SDC MODULE



422-23080-020	SDC MODULE
422-23080-023	SDC MODULE
422-23080-119	SDC MODULE
422-23080-128	SDC MODULE
422-30510-124	SDC/SAT/TAS/COMPUTER
422-30510-125	SDC/SAT/TAS COMPUTER
422-30510-225	SDC MODULE
422-30510-261	SDC MODULE
622-0837-002	FLIGHT DIRECTOR INDICATOR
518-16007-136	ENCODING ALTIMETER
518-16007-245	ENCODING ALTIMETER
518-16007-332	ENCODING ALTIMETER
518-16007-402	ENCODING ALTIMETER
518-16007-410	ENCODING ALTIMETER
518-16007-420	ENCODING ALTIMETER
518-16007-508	ENCODING ALTIMETER
518-16007-706	ENCODING ALTIMETER
518-16007-708	ENCODING ALTIMETER
518-16007-761	ENCODING ALTIMETER
518-16007-7B	ENCODING ALTIMETER
518-16007-811	ENCODING ALTIMETER
518-28007-429	ENCODIGN ALTIMETER
518-28007-923	ENCODING ALTIMETER
519-22702-001	ENCODING ALTIMETER
519-28704-C4001	ENCODING ALTIMETER
521-29007-019	ENCODING ALTIMETER
521-29007-206	ENCODING ALTIMETER
521-29007-217	ENCODING ALTIMETER
521-29007-218	ENCODING ALTIMETER
521-29007-4106	ENCODING ALTIMETER
521-29007-4109	ENCODING ALTIMETER
521-29007-4132	ENCODING ALTIMETER
521-29007-4226	ENCODING ALTIMETER
521-29007-4322	ENCODING ALTIMETER
521-29007-4806	ENCODING ALTIMETER
521-29007-710	ENCODING ALTIMETER
521-29007-716	ENCODING ALTIMETER
521-29007-718	ENCODING ALTIMETER
521-29007-813	ENCODING ALTIMETER
521-29007-819	ENCODING ALTIMETER
522-3700-009	FLIGHT DIRECTOR IND.
523-29702-001	ENCODING ALTIMETER
523-29702-032	ENCODING ALTIMETER
523-29702-053	ENCODING ALTIMETER
523-29702-065	ENCODING ALTIMETER
523-29702-111	ENCODING ALTIMETER
523-29702-153	ENCODING ALTIMETER
523-29702-524	ENCODING ALTIMETER
523-29702-621	ENCODING ALTIMETER



523-29702-633	ENCODING ALTIMETER
523-29702-654	ENCODING ALTIMETER
523-29702-664	ENCODING ALTIMETER
523-29702-684	ENCODING ALTIMETER
523-29702-903	ENCODING ALTIMETER
523-29702-905	ENCODING ALTIMETER
523-29702-959	ENCODING ALTIMETER
622-2265-060	FLIGHT GUIDANCE PANEL
622-3702-008	BEARING DISTANCE INDICATOR
540-22722-002	ALTITUDE ALERTER
540-25100-031	ALTITUDE ALERTER
540-25100-134	ALTITUDE ALERTER
540-45100-E2111	ALTITUDE ALERTER
570-23932-003	PNEUMATIC ALTIMETER
570-23932-005	PNEUMATIC ALTIMETER
570-23932-008	PNEUMATIC ALTIMETER
570-23932-302	PNEUMATIC ALTIMETER
570-23932-402	PNEUMATIC ALTIMETER
570-24929-406	ENCODING ALTIMETER
571-25005-011	PNEUMATIC ENCODING ALTIMETER
571-25005-032	PNEUMATIC ENCODING ALTIMETER
571-25005-222	PNEUMATIC ENCODING ALTIMETER
571-25005-302	PNEUMATIC ENCODING ALTIMETER
571-29020-214	ALTIMETER
575-25850-213	MACH AIRSPEED
575-25850-271	MACH AIRSPEED INDICATOR
575-25850-309	MACH AIRSPEED
575-25850-335	MAAS/MACH INDICATOR
575-25850-361	MAAS/MACH INDICATOR
575-25850-759	MACH AIRSPEED IND
622-6520-001	CONTROL COM
622-6520-005	CONTROL COM
622-6522-005	CONTROL ADF
622-6523-008	CONTROL TRANS
575-29846-305	MAX ALLOW/MACH AIRSPEED IND
575-35250-252	MAAS/DIGITAL MACH INDICATOR
35900-512	MACH AIRSPEED INDICATOR
7018341-803	MODE SELECTOR
C14129AA	ALTIMETER
SRL-C2K	INDICATOR-TORQUE, LIGHTED
16650-1151	ALTIMETER
065-0053-09	ALTITUDE SELECTOR/ALERter
066-03046-05	PICTORIAL NAVIGATION INDICATOR
066-3042-03	RMI
066-3042-04	RMI
066-3044-01	RADAR ALTIMETER INDICATOR
066-3044-03	RADAR ALTIMETER INDICATOR
101450-11952	ENCODING ALTIMETER
101617-11372	REPORTING ALTIMETER



101720-01461	ALTIMETER
7001179-961	HSI
7002493-907	HSI
7002493-909	HSI
7003897-919	A/P CONTROLLER
7003938-907	MODE SELECTOR
7020B	VSI/IVSI
7040	VSI/IVSI
777-1224-004	FLIGHT DIRECTOR IND.
787-6173-016	FLIGHT DIRECTOR IND.
787-6173-205	FLIGHT DIRECTOR IND.
792-6091-001	HSI
792-6221-003	REMOTE HDG/CRS SEL
8030	AIRSPED INDICATOR
8047/10DH	2-INCH ALTIMETER
8140B-35MB-LX	ENCODING ALTIMETER
820-645	INDICATOR
9813-25-15	DUAL TORQUE INDICATOR
101720-01562	ALTIMETER
101730-11389	ALTIMETER
101735-11799	ALTIMETER
101750-01710	ALTIMETER
10420-11968E	REPORTING PRESSURE ALTIMETER
111303-4	ATTITUDE DIRECTOR IND
113540	ATTITUDE DIRECTOR IND.
152BL801B	THERMOCOUPLE TEMPERATURE INDICATOR
1611AM11	ALTIMETER
162BL709C	ELECTRICAL RESISTANCE THERMOMETER
20015-11187	AIRSPED INDICATOR
20018-11332	AIRSPED INDICATOR
20020-11293	AIRSPED INDICATOR
20130-11236	MAX ALLOWABLE AIRSPEED
B0200-81926	AIRSPEDDATA
25100-021	ALTITUDE ALERTER
22702-001	ENCODING ALTIMETER
22702-016	ENCODING ALTIMETER
22702-321	ENCODING ALTIMETER
22702-502	ENCODING ALTIMETER
22719-003	VERTICAL SPEED IND.
22722-934	ALTITUDE ALERTER
23080-133	SDC MODULE
233T4222-12	INTER/JACK PANEL ASSY.
233T4222-20	INTER/JACK PHONE ASSY.
23932-214	ALTIMETER
24929-401	ENCODING ALTIMETER
24929-411	ENCODING ALTIMETER
24929-414	ENCODING ALTIMETER
24929-521	ENCODING ALTIMETER
28702-926	ENCODING ALTIMETER



28704-F2101	ENCODING ALTIMETER
29007-006	ENCODING ALTIMETER
29007-101	ENCODING ALTIMETER
263-1	150VA DIMMING CONTROL
27-19118-9	TRI-UNIT IND.
27-19193-5	AIRSPED INDICATOR
270-2196-030	AIRSPED SENSOR
270-2436-040	CONTROL UNIT
28007-003	ENCODING ALTIMETER
28007-006	ENCODING ALTIMETER
28007-017	ENCODING ALTIMETER
28007-024	ENCODING ALTIMETER
28007-209	ENCODING ALTIMETER
28007-224	ENCODING ALTIMETER
28007-264	ENCODING ALTIMETER
28007-312	ENCODING ALTIMETER
28007-344	ENCODING ALTIMETER
28007-427	ENCODING ALTIMETER
28007-907	ENCODING ALTIMETER
28702-004	ENCODING ALTIMETER
28702-025	ENCODING ALTIMETER
28702-071	ENCODING ALTIMETER
28702-515	ENCODING ALTIMETER
28702-526	ENCODING ALTIMETER
28702-536	ENCODING ALTIMETER
28702-552	ENCODING ALTIMETER
28702-556	ENCODING ALTIMETER
28702-562	ENCODING ALTIMETER
066-03031-0000	RADAR ALTIMETER INDICATOR
066-3020-05	FLIGHT COMMAND IND.
066-3024-18	PICTORIAL NAVIGATION INDICATOR
29007-108	ENCODING ALTIMETER
29007-4008	ENCODING ALTIMETER
29007-4115	ENCODING ALTIMETER
29007-4117	ENCODING ALTIMETER
29007-4130	ENCODING ALTIMETER
29007-4222	ENCODING ALTIMETER
29007-4226	ENCODING ALTIMETER
29007-4700	ENCODING ALTIMETER
29007-4800	ENCODING ALTIMETER
29007-810	ENCODING ALTIMETER
29702-005	ENCODING ALTIMETER
29702-051	ENCODING ALTIMETER
29702-065	ENCODING ALTIMETER
29702-081	ENCODING ALTIMETER
29702-123	ENCODING ALTIMETER
29702-154	ENCODING ALTIMETER
29702-161	ENCODING ALTIMETER
29702-171	ENCODING ALTIMETER



29702-535	ENCODING ALTIMETER
29702-673	ENCODING ALTIMETER
29702-674	ENCODING ALTIMETER
29702-682	ENCODING ALTIMETER
29702-684	ENCODING ALTIMETER
29702-685	ENCODING ALTIMETER
29702-801	ENCODING ALTIMETER
30230-1176	VERTICAL SPEED
30510-226	SDCM/SAT/TAS COMPUTER
3137LB31C	RMI
3337L-B-2-1-G	RMI
35250-203	MAXIMUM ALLOWABLE AIRSPEED
35250-352	MAXIMUM ALLOWABLE AIRSPEED
35900-501	MAX ALLOWABLE A/S
3A43.22.20F.05.1.FU	2 INCH ALTIMETER
4018639-904	AUTOPILOT CONTROL
518-28007-173	ENCODING ALTIMETER
518-28007-201	ENCODING ALTIMETER
518-28007-208	ENCODING ALTIMETER
518-28007-263	ENCODING ALTIMETER
4018639-929	AUTOPILOT CONTROL
40400-101	PNEUMATIC ALTIMETER
49707-104	SERVO-PNEU ALT.
5035P-P41	ENCODING ALTIMETER
5035P2-P14	ENCODING ALTIMETER
51-4226-2	BATTERY TEMP IND
518-28007-007	ENCODING ALTIMETER
518-28007-012	ENCODING ALTIMETER
519-28702-806	ENCODING ALTIMETER
519-28702-013	ENCODING ALTIMETER
519-28702-026	ENCODING ALTIMETER
519-28702-035	ENCODING ALTIMETER
519-28702-061	ENCODING ALTIMETER
519-28702-081	ENCODING ALTIMETER
519-28702-532	ENCODING ALTIMETER
519-28702-573	ENCODING ALTIMETER
519-28702-582	ENCODING ALTIMETER
519-28702-905	ENCODING ALTIMETER
522-0690-003	DISTANCE-HEADING IND
522-2447-270	CONTROL UNIT
SEDL-OC4BE	OIL TEMP/PRESSUE IND.
SLZ9200	IVSI
WL1103AMMS4	SERVO ALTIMETER
WL1401AMMS2	SERVO ALTIMETER
WL1404AMMS8	SERVO ALTIMETER
WL1609AM1	COUNTER POINTER ALTIMETER
522-2638-000	COURSE INDICATOR
522-3122-005	FLIGHT DIRECTOR IND.
61104-03	EGT



522-3487-007	FLIGHT DIRECTOR IND.
522-3487-010	FLIGHT DIRECTOR IND.
522-3667-001	FLIGHT DIRECTOR IND.
529-20	NAVIGATION LIGHT
5506-S53-Y4	ENCODING ALTIMETER
5506-SG-Y4	ENCODING ALTIMETER
5506L-SG1	ALTITUDE ALERTER
563-032	FUEL PRESSURE IND
570-24929-001	ENCODING ALTIMETER
622-0142-003	REMOTE HEADING AND COURSE SELECTOR
622-0224-004	ATTITUDE DIRECTOR IND.
622-1204-002	RADIO ALTITUDE IND.
622-2937-003	RADIO ALTITUDE IND.
570-31400-007	PNEUMATIC ALTIMETER
570-31400-014	PNEUMATIC ALTIMETER
35900-503	MAX ALLOW AIRSPEED
622-3344-002	ATTITUDE DIRECTOR INDICATOR
622-3374-002	ATTITUDE DIRECTOR INDICATOR
622-3594-002	FLIGHT DIRECTOR IND.
622-3594-013	FLIGHT DIRECTOR IND.
622-3594-014	FLIGHT DIRECTOR IND.
622-3594-015	FLIGHT DIRECTOR IND.
622-4151-012	COURSE INDICATOR
622-4160-015	DIGITAL RADIO ALTITUDE INDICATOR
622-4176-008	HSI
622-4808-006	ATTITUDE DIRECTOR IND.
622-4938-002	RMI-30
720-185	TRIM INDICATOR
64141-360-1	ALTIMETER
7000466-915	ATT. DIR. INDICATOR
7000466-966	ATT. DIR. INDICATOR
7000469-906	HSI
7000469-915	HSI
7000836-906	ADI
7001179-953	HSI
25005-202	PNEUMATIC ENCODING ALTIMETER
16007-135	ENCODING ALTIMETER
25005-301	PNEUMATIC ENCODING ALTIMETER
25850-228	MAAS/MACH INDICATOR
25850-314	MAAS/MACH INDICATOR
25850-371	MAAS/MACH INDICATOR
163BL507B	TEMP IND
18152-103	SDC MODULE
18152-118	SDC MODULE
30980-330	SAT/TAS COMPUTER
30980-336	SAT/TAS COMPUTER
30980-339	SAT/TAS COMPUTER
30980-365	SAT/TAS COMPUTER
30980-368	SAT/TAS COMPUTER



31500-543	MAX ALLOWABLE IND.
18152-302	SDC MODULE
18152-310	SDC MODULE
18152-320	SDC MODULE
18152-322	SDC MODULE
2591411-902	ATTITUDE DIRECTOR IND.
27-19117-1	VOLTMETER
27-19160-1	OIL TEMPERATURE PRESSURE INDICATOR
27-19177-1	FUEL PRESSURE L/R INDICATOR
23080-009	SDC MODULE
23080-036	SDC MODULE
30980-123	SAT/TAS COMPUTER
30980-132	SAT/TAS COMPUTER
30980-152	SAT/TAS COMPUTER
30980-155	SAT/TAS COMPUTER
30980-167	SAT/TAS COMPUTER
5035P2-P15	ENCODING ALTIMETER
518-16007-1312	ENCODING ALTIMETER
518-16007-162	ENCODING ALTIMETER
518-16007-163	ENCODING ALTIMETER
518-16007-164	ENCODING ALTIMETER
518-16007-313	ENCODING ALTIMETER
518-16007-414	ENCODING ALTIMETER
518-16007-507	ENCODING ALTIMETER
518-16007-6B	ENCODING ALTIMETER
518-16007-714	ENCODING ALTIMETER
518-16007-717	ENCODING ALTIMETER
518-16007-B216	ENCODING ALTIMETER
519-22702-002	ENCODING ALTIMETER
519-22702-033	ENCODING ALTIMETER
519-22702-042	ENCODING ALTIMETER
520-5160-012	COURSE SELECTOR INDICATOR
521-29007-004	ENCODING ALTIMETER
521-29007-016	RAD ALT ALTIMETER
521-29007-021	ENCODING ALTIMETER
521-29007-107	ENCODING ALTIMETER
521-29007-209	ENCODING ALTIMETER
521-29007-212	ENCODING ALTIMETER
521-29007-4019	ENCODING ALTIMETER
521-29007-4091	ALTIMETER
521-29007-4104	ENCODING ALTIMETER
521-29007-4111	ENCODING ALTIMETER
521-29007-4215	ENCODING ALTIMETER
622-3702-007	BEARING DISTANCE INDICATOR
521-29007-4233	ENCODING ALTIMETER
521-29007-4234	ENCODING ALTIMETER
521-29007-702	ENCODING ALTIMETER
521-29007-704	ENCODING ALTIMETER
522-2447-564	RADIO SET CONTROL



522-3616-502	RADIO SET CONTROL
522780	ITT INDICATOR
523-29702-031	ENCODING ALTIMETER
523-29702-054	ENCODING ALTIMETER
523-29702-072	ENCODING ALTIMETER
523-29702-073	ENCODING ALTIMETER
523-29702-075	ENCODING ALTIMETER
523-29702-164	ENCODING ALTIMETER
523-29702-175	ENCODING ALTIMETER
523-29702-522	ENCODING ALTIMETER
523-29702-575	ENCODING ALTIMETER
523-29702-611	ENCODING ALTIMETER
523-29702-613	ENCODING ALTIMETER
523-29702-656	ENCODING ALTIMETER
523-29702-802	ENCODING ALTIMETER
6608217-12	STAB TRIM INDICATOR
540-22722-016	ALTITUDE ALERTER
540-23989-312	ALTITUDE ALERTER
540-25100-004	ALTITUDE ALERTER
540-25100-012	ALTITUDE ALERTER
540-25100-021	ALTITUDE ALERTER
7000466-911	ATT. DIR. INDICATOR
570-23932-106	ALTIMETER - ENCODER
570-23932-213	PNEUMATIC ALTIMETER
570-23932-981	ALTIMETER
570-31400-006	ALTIMETER
571-25005-052	PNEUMATIC ENCODING ALTIMETER
571-25005-221	PNEUMATIC ENCODING ALTIMETER
575-25850-245	MAAS/MACH INDICATOR
575-25850-340	MAAS/MACH INDICATOR
575-25850-372	MAAS/MACH INDICATOR
575-26465-833	MAAS/MACH INDICATOR
575-26465-933	MACH AIRSPEED
575-29846-306	MAX ALLOW/MACH AIRPSEED IND
575-35250-502	MAAS/DIGITAL MACH INDICATOR
575-35900-501	MAX ALLOWABLE/MACH AIRSPEED IND.
6222	FUEL PRESSURE GAGE
64111-900-1	ALTIMETER
622-2313-054	FLIGHT GUIDANCE PANEL
422-18152-105	SDC MODULE
422-18152-115	SDC MODULE
422-18152-125	SDC MODULE
422-18152-126	SDC MODULE
422-18152-301	SDC MODULE
422-18152-322	SDC MODULE
422-18152-323	SDC MODULE
422-18152-810	SDC MODULE
422-18152-813	SDC MODULE
422-18152-819	SDC MODULE



422-18152-902	SDC MODULE
422-18152-913	SDC MODULE
3A43.42.50F.05.1.EG	2-INCH ALTIMETER
3A43.42.50F.05.1.GA	2-INCH ALTIMETER
422-18152-914	SDC MODULE
422-18152-917	SDC MODULE
422-18152-921	SDC MODULE
422-18152-926	SDC MODULE
422-23080-003	SDC MODULE
422-23080-034	SDC MODULE
422-23080-101	SDC MODULE
422-23080-102	SDC MODULE
422-23080-112	SDC MODULE
422-23080-114	SDC MODULE
422-30510-105	SDC/SAT/TAS COMPUTER
422-30510-136	SDC/SAT/TAS COMPUTER
422-30510-142	SDC/SAT/TAS COMPUTER
422-30510-160	SDC/SAT/TAS COMPUTER
422-30510-163	SDC/SAT/TAS COMPUTER
422-30510-165	SDC/SAT/TAS COMPUTER
422-30510-232	SDC MODULE
5934AM-3D	PRESSURE ALTIMETER
5934M-3D	PRESSURE ALTIMETER
5934P-1D	PRESSURE ALTIMETER
820-581	TEMP IND, WING TIP
822-1120-009	CONTROL COM
822-1121-002	COMM/NAV CONTROL
7018341-907	MODE SELECTOR
24929-931	ENCODING ALTIMETER
25100-001	ALTITUDE ALERTER
6113	MANIFOLD PRESSURE GAGE
22702-023	ENCODING ALTIMETER
22702-331	ENCODING ALTIMETER
22702-513	ENCODING ALTIMETER
22722-003	ALTITUDE ALERTER
22722-021	ALTITUDE ALERTER
22722-035	ALTITUDE ALERTER
23080-024	SDC MODULE
233T3239-1	CARGO HEAT PANEL
23932-012	ALTIMETER
23932-213	ALTIMETER
23989-002	ALTITUDE ALERTER
23989-004	ALTITUDE ALERTER
24929-032	ENCODING ALTIMETER
24929-104	ENCODING ALTIMETER
24929-311	ENCODING ALTIMETER
2591411-444	ATTITUDE DIRECTOR IND.
28702-806	ENCODING ALTIMETER
28704-002	ENCODING ALTIMETER



28704-D1001	ENCODING ALTIMETER
29007-005	ENCODING ALTIMETER
27-19171-1	ANGLE OF ATTACK IND.
27-19193-11	AIRSPED INDICATOR
27-19193-19	AIRSPED INDICATOR
270-2436-060	CONTROL UNIT
28007-020	ENCODING ALTIMETER
28007-202	ENCODING ALTIMETER
28007-231	ENCODING ALTIMETER
28007-313	ENCODING ALTIMETER
28007-342	ENCODING ALTIMETER
28007-906	ENCODING ALTIMETER
28702-011	ENCODING ALTIMETER
28702-023	ENCODING ALTIMETER
28702-024	ENCODING ALTIMETER
28702-055	ENCODING ALTIMETER
28702-503	ENCODING ALTIMETER
28702-513	ENCODING ALTIMETER
28702-533	ENCODING ALTIMETER
28702-551	ENCODING ALTIMETER
28702-554	ENCODING ALTIMETER
28702-564	ENCODING ALTIMETER
29007-4001	ENCODING ALTIMETER
29007-4003	ENCODING ALTIMETER
29007-4127	ENCODING ALTIMETER
29007-4203	ENCODING ALTIMETER
29007-4208	ENCODING ALTIMETER
29007-4234	ENCODING ALTIMETER
29007-710	ENCODING ALTIMETER
29020-214	PNEUMATIC ALTIMETER
29702-013	ENCODING ALTIMETER
29702-021	ENCODING ALTIMETER
29702-024	ENCODING ALTIMETER
29702-056	ENCODING ALTIMETER
29702-083	ENCODING ALTIMETER
29702-502	ENCODING ALTIMETER
29702-522	ENCODING ALTIMETER
29702-621	ENCODING ALTIMETER
29702-633	ENCODING ALTIMETER
29702-634	ENCODING ALTIMETER
29702-635	ENCODING ALTIMETER
29702-906	ENCODING ALTIMETER
30980-156	SAT/TAS COMPUTER
3117LB24C	RMI
31400-004	PNEUMATIC ALTIMETER
31400-018	PNEUMATIC ALTIMETER
3252013-1401	ENCODING ALTIMETER
35900-402	MAX ALLOWABLE A/S
35900-601	MAX ALLOWABLE A/S



4002531-454	ADI
4018368-908	MODE SELECTOR
518-28007-177	ENCODING ALTIMETER
518-28007-207	ENCODING ALTIMETER
518-28007-234	ENCODING ALTIMETER
518-28007-266	ENCODING ALTIMETER
518-28007-314	ENCODING ALTIMETER
518-28007-344	ENCODING ALTIMETER
518-28007-346	ENCODING ALTIMETER
4018639-925	AUTOPILOT CONTROL
44929-013	ALTIMETER
44929-412	ENCODING ALTIMETER
45100-D1010	ALTITUDE ALERTER
482-0011-010	RADIO MAGNETIC HEADING
501-1075-16	EMERGENCY POWER SUPPLY
501-1228-01	EMERGENCY POWER SUPPLY
51-4226-3	BATTERY TEMP IND
519-28702-903	ENCODING ALTIMETER
518-28007-863	ENCODING ALTIMETER
519-28702-004	ENCODING ALTIMETER
519-28702-015	ENCODING ALTIMETER
519-28702-034	ENCODING ALTIMETER
519-28702-076	ENCODING ALTIMETER
519-28702-524	ENCODING ALTIMETER
519-28702-556	ENCODING ALTIMETER
522-2447-048	CONTROL UNIT
522-2447-055	CONTROL UNIT
522-2447-250	CONTROL UNIT
522-3122-007	FLIGHT DIRECTOR IND.
5934A-3	PRESSURE ALTIMETER
5934PM-1	PRESSURE ALTIMETER
066-3024-01	PICTORIAL NAVIGATION INDICATOR
066-3024-03	PICTORIAL NAVIGATION INDICATOR
066-3024-20	PICTORIAL NAVIGATION INDICATOR
522-3487-009	FLIGHT DIRECTOR IND.
522-3877-002	FLIGHT DIRECTOR IND.
522-3908-001	FLIGHT DIRECTOR IND.
522-4114-012	RADIO ALTITUDE INDICATOR
55050-0121	CABIN ALT/DIFF PRES IND.
5506-SG3-Y	ENCODING ALTIMETER
5506-SG3-Y4	ENCODING ALTIMETER
5506-SG5	ENCODING ALTIMETER
622-0555-011	RADIO MAGNETIC IND.
622-0835-002	FLIGHT DIRECTOR INDICATOR
622-0945-008	FLIGHT MODE SELECTOR
622-1204-003	RADIO ALTITUDE IND.
622-2937-008	RADIO ALTITUDE IND.
570-24929-027	ENCODING ALTIMETER
570-24929-031	ENCODING ALTIMETER



570-24929-105	ENCODING ALTIMETER
570-24929-106	ENCODING ALTIMETER
570-24929-304	ENCODING ALTIMETER
570-24929-314	ENCODING ALTIMETER
570-24929-413	ENCODING ALTIMETER
570-31400-113	PNEUMATIC ALTIMETER
622-3594-008	FLIGHT DIRECTOR IND.
622-3594-017	FLIGHT DIRECTOR IND.
622-3594-018	FLIGHT DIRECTOR IND.
622-4160-018	DIGITAL RADIO ALT. IND.
720-192	TRIM INDICATOR
720-318	TRIM INDICATOR
69-46114-10	ENGINE START MODULE ASSEMBLY
7000466-901	ATT. DIR. INDICATOR
7000466-910	ATT. DIR. INDICATOR
7000466-917	ATT. DIR. INDICATOR
7000469-902	HSI
7000469-909	HSI
7000469-910	HSI
7000469-925	HSI
7000469-938	HORIZONTAL SITUATION INDICATOR
7000836-912	ATTITUDE DIRECTOR INDICATOR
7000836-913	ADI
7001179-916	HSI
7001182-910	ATTITUDE DIRECTOR IND.
7003897-925	A/P CONTROLLER
7003938-914	MS-400 MODE SELECTOR
772-5005-003	FLIGHT DIRECTOR INDICATOR
772-5005-011	FLIGHT DIRECTOR INDICATOR
772-5006-005	FLIGHT DIRECTOR IND
787-6173-201	FLIGHT DIRECTOR IND.
787-6385-006	COURSE INDICATOR
792-6091-002	HSI
792-6091-006	HSI
792-6091-009	HSI
792-6703-003	FLIGHT COMPUTER
8140B-35MB	ENCODING ALTIMETER
8140B-20LW-MB	ENCODING ALTIMETER
820-646	INDICATOR
820-671	TRI-UNIT IND.
820-674	TRI-UNIT IND.
820-678	TRI-UNIT IND.
JG872A4	MASTER SAT IND
SEL-OC19G	EGT INDICATOR
SLZ9832A	IVSI
WL1101AMMS8	SERVO ALTIMETER
WL1401AMMS1	SERVO ALTIMETER
WL1403AMMS3	SERVO ALTIMETER
WL1404AMMS5	SERVO ALTIMETER



172936-001	SELECTOR ROTARY HOUSED ASSEMBLY
065-0046-01	ALTITUDE SELECTOR
065-0053-06	ALTITUDE SELECTOR/ALERTER
065-0053-08	ALTITUDE SELECTOR/ALERTER
066-3024-04	PICTORIAL NAV IND.
066-3044-00	RADAR ALTIMETER INDICATOR
066-3062-11	ENCODING ALTIMETER
101735-011002	ALTIMETER
101750-111030	ALTIMETER
101750-111058	ALTIMETER
152BL702C	THERMOCOUPLE TEMPERATURE INDICATOR
152BL708	THERMOCOUPLE TEMPERTAURE INDICATOR
152BL708H	THERMOCOUPLE TEMPERATURE INDICATOR
152BL709	THERMOCOUPLE TEMPERATURE INDICATOR
16007-336	ENCODING ALTIMETER
16007-984	ENCODING ALTIMETER
16007-B42	ENCODING ALITMETER
16007-B46	ENCODING ALTIMETER
1611AM8	STANDBY COUNTER/POINTER ALTIMETER
20130-11226	MAX ALLOWABLE AIRSPEED
20130-11237	MAX ALLOWABLE AIRSPEED
20130-11274	MAX ALLOWABLE AIRSPEED
18152-106	SDC MODULE
18152-109	SDC MODULE
30510-156	SDCM/SAT/TAS COMPUTER
30980-118	SAT/TAS COMPUTER
30980-142	SAT/TAS COMPUTER
30980-151	SAT/TAS COMPUTER
30980-154	SAT/TAS COMPUTER
209-070-262-101	DUAL TEMPERATURE PRESSURE INDICATOR
23080-006	SDC MODULE
23080-008	SDC MODULE
23080-040	SDC MODULE
422-18152-123	SDC MODULE
422-18152-135	SDC MODULE
422-18152-834	SDC MODULE
422-18152-843	SDC MODULE
422-23080-022	SDC MODULE
25005-021	PNEUMATIC ENCODING ALTIMETER
25005-042	PNEUMATIC ENCODING ALTIMETER
25005-302	PNEUMATIC ENCODING ALTIMETER
422-23080-026	SDC MODULE
422-23080-028	SDC MODULE
422-23080-108	SDC MODULE
422-23080-124	SDC MODULE
422-30510-120	SDC/SAT/TAS COMPUTER
422-30510-127	SDC/SAT/TAS COMPUTER
422-30510-154	SDC/SAT/TAS COMPUTER
422-30510-158	SDC/SAT/TAS COMPUTER



422-30510-235	SDC MODULE
422-30510-265	SDC MODULE
422-30510-326	SDC/SAT/TAS COMPUTER
25005-312	PNEUMATIC ENCODING ALTIMETER
25850-204	MAAS/MACH INDICATOR
25850-209	MAAS/MACH INDICATOR
25850-234	MAAS/MACH INDICATOR
25850-332	MAAS/MACH INDICATOR
2591411-910	ATTITUDE DIRECTOR INDICATOR
27-19132-001	CABIN ALTIMETER PRESSURE INDICATOR
27-19160-005	OIL TEMPERATURE PRESSURE INDICATOR
3A43.32.51F.28.1.GM	2-INCH ALTIMETER
29007-4218	ENCODING ALTIMETER
15900-215	CABIN ALTITUDE,RATE & DPI
5035P-P50	ENCODING ALTIMETER
518-16007-133	ENCODING ALTIMETER
518-16007-134	ENCODING ALTIMETER
523-29702-024	ENCODING ALTIMETER
523-29702-102	ENCODING ALTIMETER
523-29702-136	ENCODING ALTIMETER
523-29702-504	ENCODING ALTIMETER
523-29702-512	ENCODING ALTIMETER
523-29702-566	ENCODING ALTIMETER
523-29702-584	ENCODING ALTIMETER
523-29702-585	ENCODING ALTIMETER
523-29702-614	ENCODING ALTIMETER
523-29702-631	ENCODING ALTIMETER
523-29702-904	ENCODING ALTIMETER
523-29702-952	ENCODING ALTIMETER
523-29702-957	ENCODING ALTIMETER
540-22722-001	ALTITUDE ALERTER
540-22722-004	ALTITUDE ALERTER
540-22722-054	ALTITUDE ALERTER
540-23989-311	ALTITUDE ALERTER
540-25100-024	ALTITUDE ALERTER
540-45100-C2010	ALTITUDE ALERTER
540-45100-D2012	ALTITUDE ALERTER
570-23932-303	PNEUMATIC ALTIMETER
570-23932-411	PNEUMATIC ALTIMETER
570-24929-522	ENCODING ALTIMETER
570-24929-921	ENCODING ALTIMETER
570-24929-929	ENCODING ALTIMETER
571-25005-001	PNEUMATIC ENCODING ALTIMETER
571-25005-121	PNEUMATIC ENCODING ALTIMETER
575-25850-204	MAAS/MACH INDICATOR
575-25850-219	MAAS/MACH INDICATOR
575-25850-315	MAAS/MACH INDICATOR
575-25850-369	MAAS/MACH INDICATOR
575-35250-452	MAAS/MACH DIGITAL INDICATOR



575-35900-752	AIRSPED INDICATOR
61121-06	TORQUE INDICATOR
6211	FUEL PRESSURE GAGE
6213	FUEL PRESSURE GAGE
622-3702-010	BEARING DISTANCE INDICATOR
622-6522-004	CONTROL ADF
6224	FUEL PRESSURE GAGE
518-16007-138	ENCODING ALTIMETER
518-16007-165	ENCODING ALTIMETER
518-16007-246	ENCODING ALTIMETER
518-16007-333	ENCODING ALTIMETER
518-16007-341	ENCODING ALTIMETER
518-16007-505	ENCODING ALTIMETER
518-16007-61	ENCODING ALTIMETER
518-16007-804	ENCODING ALTIMETER
518-16007-805	ENCODING ALTIMETER
518-16007-809	ENCODING ALTIMETER
518-16007-812	ENCODING ALTIMETER
518-16007-B41	ENCODING ALTIMETER
519-22702-501	ENCODING ALTIMETER
519-22702-502	ENCODING ALTIMETER
520-5160-003	COURSE SELECTOR INDICATOR
520-5160-005	COURSE SELECTOR INDICATOR
521-29007-008	ENCODING ALTIMETER
521-29007-097	ENCODING ALTIMETER
521-29007-4023	ENCODING ALTIMETER
521-29007-4097	ENCODING ALTIMETER
521-29007-4103	ENCODING ALTIMETER
521-29007-4110	ENCODING ALTIMETER
521-29007-4303	ENCODING ALTIMETER
521-29007-4720	ENCODING ALTIMETER
521-29007-705	ENCODING ALTIMETER
521-29007-715	ENCODING ALTIMETER
C14129BA	ALTIMETER
C14130AA	ALTIMETER
16650-1150	ALTIMETER
066-03046-0000	PICTORIAL NAVIGATION INDICATOR
066-03046-0001	PICTORIAL NAVIGATION INDICATOR
066-03062-0003	ENCODING ALTIMETER
066-3024-40	PICTORIAL NAV IND.
RC30VIL	IVSI
822-1121-001	COMM/NAV CONTROL
22702-501	ENCODING ALTIMETER
22722-004	ALTITUDE ALERTER
233T3239-15	CARGO HEAT PANEL
23932-023	ALTIMETER
23932-032	ALTIMETER
23932-304	ALTIMETER
23989-003	ALTITUDE ALERTER



24929-006	ENCODING ALTIMETER
24929-012	ENCODING ALTIMETER
24929-026	ENCODING ALTIMETER
24929-029	ENCODING ALTIMETER
2591411-024	ATT. REF. INDICATOR
28702-581	ENCODING ALTIMETER
28702-902	ENCODING ALTIMETER
28702-903	ENCODING ALTIMETER
29007-007	ENCODING ALTIMETER
29007-008	ENCODING ALTIMETER
29007-024	ENCODING ALTIMETER
27-19193-15	AIRSPED INDICATOR
27-19193-21	AIRSPED INDICATOR
4018368-916	MODE SELECTOR
4018368-924	MODE SELECTOR
518-28007-022	ENCODING ALTIMETER
518-28007-031	ENCODING ALTIMETER
518-28007-202	ENCODING ALTIMETER
518-28007-212	ENCODING ALTIMETER
518-28007-231	ENCODING ALTIMETER
518-28007-267	ENCODING ALTIMETER
4018639-927	AUTOPILOT CONTROL
4027170-904	HSI
49707-303	SERVO-PNEU ALT.
501-1075-07	EMERGENCY POWER SUPPLY
501-1075-08	EMERGENCY POWER SUPPLY
5035P-P47	ENCODING ALTIMETER
5035P2-P27	ENCODING ALTIMETER
519-28702-801	ENCODING ALTIMETER
519-28702-901	ENCODING ALTIMETER
519-28702-003	ENCODING ALTIMETER
519-28702-082	ENCODING ALTIMETER
519-28702-083	ENCODING ALTIMETER
519-28702-526	ENCODING ALTIMETER
519-28702-535	ENCODING ALTIMETER
522-2447-268	CONTROL UNIT
55035-1138	CABIN ALT/ DIFF IND
55050-0149	CABIN ALT/DIF. PRE. IND.
5506-S-Y4	ENCODING ALTIMETER
5506-S53-4	ENCODING ALTIMETER
5506-SG53-4	ENCODING ALTIMETER
5506L-S512	ALTITUDE ALERTER
5506L-SG51	ALTITUDE ALERTER
570-24929-002	ENCODING ALTIMETER
622-0944-007	FLIGHT MODE SELECTOR
622-0950-002	FLIGHT MODE SELECTOR
622-2506-104	RADIO MAGNETIC INDICATOR
570-24929-204	ENCODING ALTIMETER
570-24929-215	ENCODING ALTIMETER



570-31400-003	PNEUMATIC ALTIMETER
570-31400-013	PNEUMATIC ALTIMETER
622-2938-003	RADIO ALTITUDE IND.
622-4151-001	COURSE INDICATOR
622-4151-006	COURSE INDICATOR
622-4160-016	DIGITAL RADIO ALTITUDE INDICATOR
622-4808-007	ATTITUDE DIRECTOR IND.
622-4938-001	RMI-30
7130	VSI/IVSI
622-4938-021	RMI-30
64141-520-1	COUNTER/POINTER ALT.
7000466-959	ATT. DIR. INDICATOR
7000469-924	HSI
7000605-903	MODE SELECTOR
7000836-914	ADI
7000836-924	ATTITUDE DIRECTOR IND.
7000839-902	RADIO ALTIMETER IND.
7000839-923	RADIO ALTIMETER INDICATOR
7001179-907	HORIZONTAL SITUATION INDICATOR
7001179-909	HORIZONTAL SITUATION INDICATOR
7060B	VSI/IVSI
7120B	VSI/IVSI
777-1026-002	HSI
787-6173-212	FLIGHT DIRECTOR IND.
792-6091-020	HSI
792-6091-022	HSI
792-6357-009	ATTITUDE DIRECTOR IND.
8047-700-11	2-INCH ALTIMETER
8059-2	AIRSPPEED
8140B-20LX	ENCODING ALTIMETER
8140B-20MB	ENCODING ALTIMETER
8140B-35LX	ENCODING ALTIMETER
A8/A-10-4	PRESSURE ALTIMETER
B0200-81123	AIRSPPEEDATA
B0200-81129	AIRSPPEEDATA
JG873A1	MASTER TAS IND
SLZ9140	IVSI
SLZ9464A-1	IVSI
WL101AMS2	ALTIMETER/AIRSPPEED IND.
WL102AMS6	STANDBY INDICATOR
WL1401AMMS4	SERVO ALTIMETER
WL1605AM2	COUNTER POINTER ALT.
18152-113	SDC MODULE
18152-116	SDC MODULE
18152-121	SDC MODULE
18152-318	SDC MODULE
066-03044-0000	RADAR ALTIMETER INDICATOR
066-3020-12	FLIGHT COMMAND IND.
066-3024-19	PICTORIAL NAVIGATION INDICATOR



10035-11326	PRESSURE ALTIMETER
101420-01255	PRESSURE REPORTING ALTIMETER
101435-01229	PRESSURE REPORTING ALTIMETER
101435-01261	PRESSURE REPORTING ALTIMETER
101450-01273	PRESSURE REPORTING ALTIMETER
101627	REPORTING ALTIMETER
101730-11390	ALTIMETER
101735-111008	ALTIMETER
152BL709A	THERMOCOUPLE TEMPERATURE INDICATOR
152LC208H	THERMOCOUPLE TEMP IND
27-19193-23	AIRSPEED INDICATOR
27-19193-29	AIRSPEED INDICATOR
28007-175	ENCODING ALTIMETER
28007-215	ENCODING ALTIMETER
28007-235	ENCODING ALTIMETER
28007-343	ENCODING ALTIMETER
28007-345	ENCODING ALTIMETER
28702-036	ENCODING ALTIMETER
28702-511	ENCODING ALTIMETER
28702-512	ENCODING ALTIMETER
28702-571	ENCODING ALTIMETER
29007-215	ENCODING ALTIMETER
29007-216	ENCODING ALTIMETER
29007-4005	ENCODING ALTIMETER
29007-4007	ENCODING ALTIMETER
29007-4102	ENCODING ALTIMETER
29007-4125	ENCODING ALTIMETER
29007-4132	ENCODING ALTIMETER
29007-4204	ENCODING ALTIMETER
29007-4206	ENCODING ALTIMETER
29007-4228	ENCODING ALTIMETER
29007-4231	ENCODING ALTIMETER
29007-813	ENCODING ALTIMETER
29007-818	ENCODING ALTIMETER
29702-052	ENCODING ALTIMETER
16007-164	ENCODING ALTIMETER
16007-174	ENCODING ALTIMETER
16007-235	ENCODING ALTIMETER
16007-331	ENCODING ALTIMETER
16007-334	ENCODING ALTIMETER
16007-344	ENCODING ALTIMETER
16007-61	ENCODING ALTIMETER
162BL708	ELECTRICAL RESISTANCE THERMOMETER
162BL709B	ELECTRICAL RESISTANCE THERMOMETER
1784460-655	GYROSYN COMPASS IND
20130-11238	MAX ALLOWABLE AIRSPEED
24929-951	ENCODING ALT.
22702-003	ENCODING ALTIMETER
22702-042	ENCODING ALTIMETER



22702-301	ENCODING ALTIMETER
29702-061	ENCODING ALTIMETER
29702-526	ENCODING ALTIMETER
29702-571	ENCODING ALTIMETER
29702-574	ENCODING ALTIMETER
29702-582	ENCODING ALTIMETER
29702-586	ENCODING ALTIMETER
29702-602	ENCODING ALTIMETER
29702-661	ENCODING ALTIMETER
29702-907	ENCODING ALTIMETER
29846-306	MAX ALLOWABLE AIRSPEED/MACH IND.
31400-113	PNEUMATIC ALTIMETER
31400-114	PNEUMATIC ALTIMETER
37277-525	MAX ALLOW A/S MACH IND
38399-490-02	AIRSPEED INDICATOR
4016341-904	BAROMETRIC ALTITUDE IND.
4018368-903	MODE SELECTOR
206-375-009-101	TOT INDICATOR
23080-021	SDC MODULE
25005-101	PNEUMATIC ENCODING ALTIMETER
25850-235	MAAS/MACH INDICATOR
25850-303	MAAS/MACH INDICATOR
26107-391	AIRSPEED IND
27-19137-1	AIRSPEED INDICATOR
422-18152-111	SDC MODULE
422-18152-312	SDC MODULE
422-18152-315	SDC MODULE
422-18152-836	SDC MODULE
422-18152-845	SDC MODULE
422-18152-891	SDC MODULE
422-18152-912	SDC MODULE
422-18152-924	SDC MODULE
422-23080-017	SDC MODULE
422-23080-025	SDC MODULE
422-23080-036	SDC MODULE
521-29007-4005	ENCODING ALTIMETER
521-29007-4017	ENCODING ALTIMETER
521-29007-4092	ALTIMETER
521-29007-4095	ENCODING ALTIMETER
521-29007-4121	ENCODING ALTIMETER
521-29007-4124	ENCODING ALTIMETER
521-29007-4227	ENCODING ALTIMETER
521-29007-812	ENCODING ALTIMETER
522-2448-255	CONTROL NAV/COM
522-2448-274	CONTROL, NAV/COM
30510-107	SDCM/SAT/TAS COMPUTER
30510-124	SDCM/SAT/TAS COMPUTER
30510-144	SDCM/SAT/TAS COMPUTER
30980-333	SAT/TAS COMPUTER



30980-351	SAT/TAS COMPUTER
30980-361	SAT/TAS COMPUTER
522-3614-500	VHF COMM
523-29702-022	ENCODING ALTIMETER
523-29702-034	ENCODING ALTIMETER
523-29702-082	ENCODING ALTIMETER
523-29702-173	ENCODING ALTIMETER
523-29702-185	ENCODING ALTIMETER
523-29702-503	ENCODING ALTIMETER
523-29702-521	ENCODING ALTIMETER
523-29702-602	ENCODING ALTIMETER
523-29702-612	ENCODING ALTIMETER
523-29702-624	ENCODING ALTIMETER
523-29702-682	ENCODING ALTIMETER
540-23989-301	ALT ALERTER
540-25100-131	ALTITUDE ALERTER
540-25100-200	ALTITUDE ALERTER
540-25100-400	ALTITUDE ALERTER
422-23080-103	SDC MODULE
422-23080-107	SDC MODULE
422-23080-113	SDC MODULE
422-23080-129	SDC MODULE
422-23080-131	SDC MODULE
422-23080-134	SDC MODULE
422-30510-144	SDC/SAT/TAS COMPUTER
422-30510-168	SDC/SAT/TAS COMPUTER
422-30510-230	SDC MODULE
422-30510-236	SDC MODULE
422-30510-237	SDC MODULE
422-30510-280	SDC MODULE
3A43.32.35F.05.1.AB	2-INCH ALTIMETER
3A43.32.50F.05.1.AU	2-INCH ALTIMETER
3A43.42.50F.05.1.FT	2-INCH ALTIMETER
3A43.42.51F.28.1.GM	2-INCH ALTIMETER
5035P-P28	ENCODING ALTIMETER
518-16007-131	ENCODING ALTIMETER
518-16007-215	ENCODING ALTIMETER
518-16007-234	ENCODING ALTIMETER
518-16007-263	ENCODING ALTIMETER
518-16007-314	ENCODING ALTIMETER
518-16007-806	ENCODING ALTIMETER
518-16007-807	ENCODING ALTIMETER
518-16007-818	ENCODING ALTIMETER
518-28007-433	ENCODING ALTIMETER
521-29007-006	ENCODING ALTIMETER
521-29007-4002	ENCODING ALTIMETER
521-29007-4004	ENCODING ALTIMETER
622-6520-016	CONTROL COM
622-6521-007	CONTROL NAV



622-6522-016	CONTROL ADF
622-6523-213	CONTROL TRANS
6311A	MANIF/FUEL PRESSURE GAGE
820-575	STB TEMP IND
7000466-904	ATT. DIR. INDICATOR
822-1120-006	CONTROL COM
570-23932-203	PNEUMATIC ALTIMETER
570-23932-214	PNEUMATIC ALTIMETER
570-23932-403	PNEUMATIC ALTIMETER
570-31400-005	ALTIMETER
571-25005-012	PNEUMATIC ENCODING ALTIMETER
571-25005-412	PNEUMATIC ENCODING ALTIMETER
575-25850-2126	Mach A/S Indicator
575-25850-214	MAAS/MACH INDICATOR
575-25850-228	MAAS/MACH INDICATOR
575-25850-305	MAAS/MACH INDICATOR
575-25850-314	MAAS/MACH INDICATOR
575-25850-319	MAAS/MACH INDICATOR
575-25850-370	MAAS/MACH INDICATOR
575-25850-A2283	A/S Mach Ind.
575-26465-960	MAAS/MACH INDICATOR
622-4449-054	FLIGHT GUIDANCE PANEL
101435-11720	PRESS. REPORTING ALT.
101450-01235	PRESSURE REPORTING ALTIMETER
101735-01455	ALTIMETER
101735-111010	ALTIMETER
10450-11110	PRESSURE ALTIMETER
124.115	DUAL TEMP/PRESS IND
1301-2001	PRESSURE ALTIMETER
152BL801C	THERMOCOUPLE TEMPERATURE INDICATOR
152BL802D	THERMOCOUPLE TEMPERATURE INDICATOR
16007-161	ENCODING ALTIMETER
16007-166	ENCODING ALTIMETER
16007-348	ENCODING ALTIMETER
16007-761	ENCODING ALTIMETER
16007-764	ENCODING ALTIMETER
20020-11212	AIRSPED INDICATOR
24929-933	ENCODING ALTIMETER
24982-001	ALTITUDE ALERTER
25100-011	ALTITUDE ALERTER
25100-033	ALTITUDE ALERTER
23080-033	SDC MODULE
233T3239-12	CARGO HEAT PANEL
233T4222-31	INTER/JACK PANEL ASSY.
23932-003	ALTIMETER
23932-005	ALTIMETER
23989-511	ALTITUDE ALERTER
24929-102	ENCODING ALTIMETER
24929-201	ENCODING ALTIMETER



24929-502	ENCODING ALTIMETER
24929-522	ENCODING ALTIMETER
24929-921	ENCODING ALTIMETER
24929-924	ENCODING ALTIMETER
563-280	OIL TEMP/PRES IND
622-0555-007	RADIO MAGNETIC IND.
622-1352-004	FLIGHT DIRECTOR INDICATOR
622-2937-005	RADIO ALTITUDE IND.
570-24929-021	ENCODING ALTIMETER
570-24929-025	ENCODING ALTIMETER
570-24929-032	ENCODING ALTIMETER
570-24929-104	ENCODING ALTIMETER
570-24929-202	ENCODING ALTIMETER
570-24929-501	ENCODING ALTIMETER
570-31400-116	PNEUMATIC ALTIMETER
5934A-1	PRESSURE ALTIMETER
622-3594-004	FLIGHT DIRECTOR IND.
622-3594-011	FLIGHT DIRECTOR IND.
622-4151-005	COURSE INDICATOR
622-4176-006	HSI
622-4423-002	ATTITUDE DIRECTOR IND.
622-4808-003	ATTITUDE DIRECTOR IND.
622-4808-013	ATTITUDE DIRECTOR IND.
622-4938-006	RMI-30
720-301	TRIM INDICATOR
622-4938-022	RMI-30
6634208002-003	AIRSPEED INDICATOR
7001179-906	HORIZONTAL SITUATION INDICATOR
7001179-957	HSI
7001179-959	HSI
7001179-965	HSI
7001182-904	ATTITUDE DIRECTOR IND.
7003897-911	A/P CONTROLLER
7003938-915	MS-400 MODE SELECTOR
772-5005-002	FLIGHT DIRECTOR INDICATOR
772-5005-005	FLIGHT DIRECTOR INDICATOR
787-6173-204	FLIGHT DIRECTOR IND.
792-6091-011	HSI
792-6348-105	A/P CONTROLLER
792-6357-001	ATTITUDE DIRECTOR IND.
792-6357-003	ATTITUDE DIRECTOR IND.
792-6357-005	ATTITUDE DIRECTOR IND.
8040B-MB	ENCODING ALTIMETER
8047-700-9	2-INCH ALTIMETER
8059-2B	AIRSPEED
8140B-20	ENCODING ALTIMETER
8140B-30LX	ENCODING ALTIMETER
820-597	INDICATOR
820-649	INDICATOR



9813-25-18	DUAL TORQUE INDICATOR
2591411-24	ATT. REF. INDICATOR
28702-582	ENCODING ALTIMETER
28702-905	ENCODING ALTIMETER
27-19118-11	TRI-UNIT IND.
27-19193-9	AIRSPED INDICATOR
270-2436-050	CONTROL UNIT
270-2436-100	CONTROL UNIT
28007-012	ENCODING ALTIMETER
28007-206	ENCODING ALTIMETER
28007-208	ENCODING ALTIMETER
28007-341	ENCODING ALTIMETER
28702-003	ENCODING ALTIMETER
28702-563	ENCODING ALTIMETER
28702-572	ENCODING ALTIMETER
29007-105	ENCODING ALTIMETER
29007-106	ENCODING ALTIMETER
29007-107	ENCODING ALTIMETER
29007-209	ENCODING ALTIMETER
29007-4017	ENCODING ALTIMETER
29007-4020	ENCODING ALTIMETER
29007-4103	ENCODING ALTIMETER
29007-4225	ENCODING ALTIMETER
29007-4720	ENCODING ALTIMETER
29007-709	ENCODING ALTIMETER
29007-712	ENCODING ALTIMETER
29007-801	ENCODING ALTIMETER
29007-805	ENCODING ALTIMETER
29007-902	ENCODING ALTIMETER
29020-412	ALTIMETER
29702-012	ENCODING ALTIMETER
29702-034	ENCODING ALTIMETER
29702-066	ENCODING ALTIMETER
29702-102	ENCODING ALTIMETER
29702-103	ENCODING ALTIMETER
29702-105	ENCODING ALTIMETER
29702-114	ENCODING ALTIMETER
29702-165	ENCODING ALTIMETER
29702-186	ENCODING ALTIMETER
29702-521	ENCODING ALTIMETER
29702-532	ENCODING ALTIMETER
29702-555	ENCODING ALTIMETER
29702-613	ENCODING ALTIMETER
29702-662	ENCODING ALTIMETER
29702-803	ENCODING ALTIMETER
29846-206	MAX ALLOWABLE AIRSPEED/MACH IND.
30510-141	SDC/SAT/TAS COMPUTER
3117LB61C	RMI
3137LB61C	RMI



33075-541	MAX ALLOW/MACH AIRSPEED IND.
35250-501	MAXIMUM ALLOWABLE AIRSPEED
35250-552	MAXIMUM ALLOWABLE AIRSPEED
3571251-9119	MGT INDICATOR
3571251-9121	MEAS GAS TEMP IND
36155-1AF25A1	RAD MAG COMP IND
38399-AB-M	AIRSPEED INDICATOR
4002531-902	ADI
4018368-901	MODE SELECTOR
4018368-918	MODE SELECTOR
518-28007-262	ENCODING ALTIMETER
518-28007-301	ENCODING ALTIMETER
065-00053-0001	ALTITUDE SELECTOR/ALERter
066-03062-0002	ENCODING ALTIMETER
066-3046-02	PICTORIAL NAVIGATION INDICATOR
066-3046-12	PICTORIAL NAVIGATION INDICATOR
5035P-P45	ENCODING ALTIMETER
518-28007-002	ENCODING ALTIMETER
518-28007-006	ENCODING ALTIMETER
519-28702-584	ENCODING ALTIMETER
519-28702-804	ENCODING ALTIMETER
519-28702-056	ENCODING ALTIMETER
519-28702-503	ENCODING ALTIMETER
519-28702-534	ENCODING ALTIMETER
519-28702-552	ENCODING ALTIMETER
519-28702-954	ENCODING ALTIMETER
519-28702-957	ENCODING ALTIMETER
522-2447-261	CONTROL UNIT
522-2447-263	CONTROL UNIT
522-3122-004	FLIGHT DIRECTOR IND.
5934M-3	PRESSURE ALTIMETER
5934PA-3	PRESSURE ALTIMETER
5934PM-A57	ALTIMETER
522-3867-002	FLIGHT DIRECTOR IND.
5506-SG-4	ENCODING ALTIMETER
066-3024-30	PICTORIAL NAVIGATION INDICATOR
18152-119	SDC MODULE
18152-210	SDC MODULE
18152-314	SDC MODULE
23080-029	SDC MODULE
23080-034	SDC MODULE
25005-102	PNEUMATIC ENCODING ALTIMETER
25850-232	MAAS/MACH INDICATOR
25850-236	MAAS/MACH INDICATOR
25850-261	MAAS/MACH INDICATOR
25850-310	MAAS/MACH INDICATOR
25850-370	MAAS/MACH INDICATOR
20040-11220	AIRSPEED INDICATOR
B0200-81105	AIRSPEEDDATA



B0200-81909	AIRSPPEEDDATA
SEDL-OC29M	NH/NL% RPM INDICATOR
SLZ9145	IVSI
SLZ9157	IVSI
WL1103AMMS19	SERVO ALTIMETER
WL1404AMMS1	SERVO ALTIMETER
WL1404AMMS3	SERVO ALTIMETER
066-03020-0005	FLIGHT COMMAND IND.
066-03020-0006	FLIGHT COMMAND IND.
066-03020-0007	FLIGHT COMMAND IND.
066-03031-0002	RADAR ALTIMETER INDICATOR
066-03044-0002	RADAR ALTIMETER INDICATOR
285T0022-39	AUDIO SELECTOR PANEL
29007-4224	ENCODING ALTIMETER
30980-141	SAT/TAS COMPUTER
30980-337	SAT/TAS COMPUTER
31500-430	MAX ALLOWABLE IND.
518-16007-137	ENCODING ALTIMETER
518-16007-166	ENCODING ALTIMETER
518-16007-174	ENCODING ALTIMETER
518-16007-252	ENCODING ALTIMETER
518-16007-344	ENCODING ALTIMETER
518-16007-404	ENCODING ALTIMETER
518-16007-510	ENCODING ALTIMETER
518-16007-713	ENCODING ALTIMETER
518-16007-716	ENCODING ALTIMETER
518-16007-764	ENCODING ALTIMETER
518-16007-820	ENCODING ALTIMETER
518-16007-B214	ENCODING ALTIMETER
518-16007-B44	ENCODING ALTIMETER
518-28007-427	ENCODING ALTIMETER
519-22702-014	ENCODING ALTIMETER
519-22702-021	ENCODING ALTIMETER
521-29007-005	ENCODING ALTIMETER
521-29007-4021	ENCODING ALTIMETER
3A43.22.20F.05.4.DM	2 INCH ALTIMETER
3A43.22.35F.28.1.GN	ALTIMETER
575-25850-203	MAAS/MACH INDICATOR
575-25850-205	MAX AIR SPEED
575-25850-232	MAAS/MACH INDICATOR
575-25850-234	MAAS/MACH INDICATOR
575-26465-860	MAAS/MACH INDICATOR
575-35250-352	MAAS/DIGITAL MACH INDICATOR
575-35900-702	MAX ALLOWABLE/MACH AIRSPEED IND.
622-0141-017	AUTOPILOT CONTROL
422-18152-106	SDC MODULE
422-18152-108	SDC MODULE
422-18152-116	SDC MODULE
521-29007-4115	ENCODING ALTIMETER



521-29007-4133	ENCODING ALTIMETER
521-29007-4209	ENCODING ALTIMETER
521-29007-719	ENCODING ALTIMETER
521-29007-720	ENCODING ALTIMETER
422-18152-129	SDC MODULE
422-18152-132	SDC MODULE
422-18152-320	SDC MODULE
422-18152-817	SDC MODULE
422-18152-820	SDC MODULE
422-18152-822	SDC MODULE
422-18152-837	SDC MODULE
422-18152-846	SDC MODULE
422-18152-906	SDC MODULE
422-18152-930	SDC MODULE
422-23080-118	SDC MODULE
422-23080-133	SDC MODULE
422-30510-112	SDC/SAT/TAS COMPUTER
422-30510-141	SDC/SAT/TAS COMPUTER
422-30510-143	SDC/SAT/TAS COMPUTER
422-30510-223	SDC MODULE
422-30510-226	SDC MODULE
422-30510-254	SDC MODULE
523-29702-003	ENCODING ALTIMETER
523-29702-011	ENCODING ALTIMETER
523-29702-013	ENCODING ALTIMETER
523-29702-014	ENCODING ALTIMETER
523-29702-055	ENCODING ALTIMETER
523-29702-085	ENCODING ALTIMETER
523-29702-126	ENCODING ALTIMETER
523-29702-133	ENCODING ALTIMETER
523-29702-152	ENCODING ALTIMETER
523-29702-161	ENCODING ALTIMETER
523-29702-532	ENCODING ALTIMETER
523-29702-553	ENCODING ALTIMETER
523-29702-605	ENCODING ALTIMETER
540-22722-019	ALTITUDE ALERTER
540-22722-021	ALTITUDE ALERTER
540-22722-034	ALTITUDE ALERTER
540-23989-006	ALTITUDE ALERTER
540-25100-002	ALTITUDE ALERTER
540-25100-003	ALTITUDE ALERTER
540-45100-E2113	ALTITUDE ALERTER
563-266	OIL TEMP & PRESS. IND.
570-23932-023	PNEUMATIC ALTIMETER
570-23932-031	PNEUMATIC ALTIMETER
570-23932-301	PNEUMATIC ALTIMETER
570-23932-532	ALTIMETER
570-24929-051	ALTIMETER
570-24929-919	ENCODING ALTIMETER



570-24929-930	ENCODING ALTIMETER
571-29020-012	ALTIMETER
622-6520-007	CONTROL COM
622-6521-012	CONTROL NAV
772-5431-001	FLIGHT DIR IND
622-3109-009	AUTOPILOT PANEL
622-3702-015	BEARING DISTANCE INDICATOR
622-4449-053	FLIGHT GUIDANCE PANEL
JG298A4	EPR INDICATOR
28007-262	ENCODING ALTIMETER
28702-014	ENCODING ALTIMETER
28702-054	ENCODING ALTIMETER
28702-063	ENCODING ALTIMETER
28702-516	ENCODING ALTIMETER
28702-574	ENCODING ALTIMETER
29007-206	ENCODING ALTIMETER
29007-213	ENCODING ALTIMETER
29007-4113	ENCODING ALTIMETER
29007-4324	ENCODING ALTIMETER
29007-4819	ENCODING ALTIMETER
29007-718	ENCODING ALTIMETER
29007-814	ENCODING ALTIMETER
29702-025	ENCODING ALTIMETER
29702-075	ENCODING ALTIMETER
29702-101	ENCODING ALTIMETER
29702-134	ENCODING ALTIMETER
29702-135	ENCODING ALTIMETER
29702-562	ENCODING ALTIMETER
29702-616	ENCODING ALTIMETER
29702-655	ENCODING ALTIMETER
29702-664	ENCODING ALTIMETER
29702-802	ENCODING ALTIMETER
35250-401	MAXIMUM ALLOWABLE AIRSPEED
35250-403	MAXIMUM ALLOWABLE AIRSPEED
35250-452	MAXIMUM ALLOWABLE AIRSPEED
3571251-9111	MEAS GAS TEMP IND
36154-1AF25B1	RAD MAG COMP IND
36154-1AJ25B1	RAD MAG COMP IND
38399-490	AIRSPEED INDICATOR
4016341-903	BAROMETRIC ALTITUDE IND.
4018368-905	MODE SELECTOR
4018368-915	MODE SELECTOR
518-28007-030	ENCODING ALTIMETER
518-28007-206	ENCODING ALTIMETER
518-28007-217	ENCODING ALTIMETER
518-28007-315	ENCODING ALTIMETER
4018639-928	AUTOPILOT CONTROL
AM275C	ALTITUDE ALERTER
BH185R-280A	ITT INDICATOR



JG873B1	SERVO TAS IND
SLZ9066	IVSI
SLZ9248	IVSI
WL102AMS4	STANDBY INDICATOR
WL1107AMMS3	SERVO ALTIMETER
WL1350AMMS5	COUNTER/POINTER ALTIMETER
WL1403AMMS4	SERVO ALTIMETER
WL1404AMMS7	SERVO ALTIMETER
WL1407AMMS1	SERVO ALTIMETER
49707-004	SERVO-PNEU ALT.
49707-103	SERVO-PNEU ALT.
49707-123	SERVO-PNEU ALT.
501-1228-05	EMERGENCY POWER SPLY
501-1712-04	EMERGENCY POWER SUPPLY
501-1719-01	EMERGENCY POWER SUPPLY
5035P-P23	ENCODING ALTIMETER
519-28702-902	ENCODING ALTIMETER
519-28702-001	ENCODING ALTIMETER
519-28702-522	ENCODING ALTIMETER
519-28702-955	ENCODING ALTIMETER
519-28704-003	ENCODING ALTIMETER
522-2447-255	CONTROL UNIT
522-2638-001	COURSE INDICATOR
522-2638-002	COURSE INDICATOR
522-3122-006	FLIGHT DIRECTOR IND.
5934AM-1	PRESSURE ALTIMETER
5934AM-3	PRESSURE ALTIMETER
6121A	MANIFOLD PRESSURE GAGE
065-00053-0000	ALTITUDE SELECTOR/ALERTER
066-3034-02	VOR/LOC IND.
066-3062-03	ENCODING ALTIMETER
101420-01224	PRESSURE REPORTING ALTIMETER
101435-01267	PRESSURE REPORTING ALTIMETER
101435-11719	PRESSURE REPORTING ALTIMETER
101450-01279	PRESSURE REPORTING ALTIMETER
101617-01349	REPORTING ALTIMETER
101635	REPORTING ALTIMETER
101735-011003	ALTIMETER
101735-01456	ALTIMETER
101735-11726	ALTIMETER
101750-111056	ALTIMETER
152B208F	THERMOCOUPLE TEMP IND
522-3867-003	FLIGHT DIRECTOR IND.
522-4430-005	FLIGHT DIRECTOR IND.
522-4529-001	FLIGHT DIRECTOR IND.
55050-0103	CABIN ALT/DIFF. PRES. INDICATOR
55050-0131	CABIN ALT/DIFF PRES IND.
5506-S5	ENCODING ALTIMETER
5506L-S12	ALTITUDE ALERTER



5506L-S2	ALTITUDE ALERTER
5506L-SG5	ALTITUDE ALERTER
563-080	DC AMMETER INDICATOR
563-087	PITCH TRIM INDICATOR
622-0171-001	RADIO ALTITUDE INDICATOR
622-0171-002	RADIO ALTITUDE INDICATOR
622-1204-010	RADIO ALTITUDE IND.
622-1352-001	FLIGHT DIRECTOR IND.
622-2506-007	RADIO MAGNETIC INDICATOR
622-2937-009	RADIO ALTITUDE IND.
570-24929-016	ENCODING ALTIMETER
570-24929-024	ENCODING ALTIMETER
570-24929-103	ENCODING ALTIMETER
570-24929-212	ENCODING ALTIMETER
570-24929-311	ENCODING ALTIMETER
570-24929-401	ENCODING ALTIMETER
570-536	A.C. VOLTS/FREQUENCY INDICATOR
152BL702	THERMOCOUPLE TEMPERATURE IND
152BL708B	THERMOCOUPLE TEMPERATURE INDICATOR
15900-901	CABIN ALT/RATE/DIFF IND.
16007-171	ENCODING ALTIMETER
1784460-657	GYROSYN COMPASS IND
20130-11288	MAX ALLOWABLE AIRSPEED
20130-11289	MAX ALLOWABLE AIRSPEED
24929-930	ENCODING ALTIMETER
25005-212	PNEUMATIC ENCODING ALTIMETER
25100-032	ALTITUDE ALERTER
22702-043	ENCODING ALTIMETER
233T4222-23	INTER/JACK PANEL ASSY.
622-2938-002	RADIO ALTITUDE IND.
622-4151-002	COURSE INDICATOR
622-4151-017	COURSE INDICATOR
622-4160-017	DIGITAL RADIO ALTITUDE INDICATOR
622-4176-012	HSI
622-4808-004	ATTITUDE DIRECTOR IND.
720-264	FLAP POSITION IND.
720-319	TRIM INDICATOR
622-5367-001	RADIO ALTITUDE IND.
64111-992-1	ALTIMETER
64141-582-1	ALTIMETER
65-52802-1	AUTO PILOT SWITCHING ACCY.
7000466-986	ATT. DIR. INDICATOR
7000836-908	ADI
7000836-916	ATTITUDE REFERENCE INDICATOR
7000836-920	ATTITUDE DIRECTOR INDICATOR
7000836-926	ATTITUDE DIRECTOR IND.
7000B	VIS/IVSI
7001179-904	HORIZONTAL SITUATION INDICATOR
7001179-954	HSI



23932-006	ALTIMETER
23932-011	ALTIMETER
23989-011	ALTITUDE ALERTER
23989-311	ALTITUDE ALERTER
23989-502	ALTITUDE ALERTER
24929-004	ENCODING ALTIMETER
24929-211	ENCODING ALTIMETER
24929-412	ENCODING ALTIMETER
28704-A1001	ENCODING ALTIMETER
28704-E2101	ENCODING ALTIMETER
29007-002	ENCODING ALTIMETER
29007-095	ENCODING ALTIMETER
29007-103	ENCODING ALTIMETER
4018639-911	AUTOPILOT CONTROL
27-19144-5	ALCOHOL WATER INJECTION QTY. IND.
276AS3	MAX/ALLOW AIRSPEED
28007-178	ENCODING ALTIMETER
28007-207	ENCODING ALTIMETER
7003897-901	A/P CONTROLLER
7003897-908	A/P CONTROLLER
7003938-908	MS-400 MODE SELECTOR
772-5005-004	FLIGHT DIRECTOR INDICATOR
772-5370-005	COURSE INDICATOR
787-6173-005	FLIGHT DIRECTOR IND.
787-6173-211	FLIGHT DIRECTOR IND.
792-6091-012	HSI
792-6091-019	HSI
792-6221-011	REMOTE HDG/CRS SEL
792-6348-003	AUTO PILOT CONTROLLER
792-6357-006	ATTITUDE DIRECTOR IND.
8020	ALTIMETER
8048/1	2-INCH ALTIMETER
8059-2B-45NVG	AIRSPEED
8140B-30	ENCODING ALTIMETER
820-602	INDICATOR
8235	MAX ALLOWABLE AIRSPEED
066-3024-13	PICTORIAL NAVIGATION INDICATOR
066-3024-50	PICTORIAL NAVIGATION INDICATOR
23080-013	SDC MODULE
16007-131	ENCODING ALTIMETER
30510-275	SDCM/SAT/TAS COMPUTER
16650-1172	ALTIMETER
30980-102	SAT/TAS COMPUTER
30980-116	SAT/TAS COMPUTER
30980-161	SAT/TAS COMPUTER
18152-102	SDC MODULE
18152-107	SDC MODULE
18152-304	SDC MODULE
18152-305	SDC MODULE



18152-312	SDC MODULE
25005-112	PNEUMATIC ENCODING ALTIMETER
25005-222	PNEUMATIC ENCODING ALTIMETER
25005-322	PNEUMATIC ENCODING ALTIMETER
25850-245	MAAS/MACH INDICATOR
25850-270	MAAS/MACH INDICATOR
25850-272	MAAS/MACH INDICATOR
25850-328	MAAS/MACH INDICATOR
20040-11171	AIRSPEED INDICATOR
20040-11218	AIRSPEED INDICATOR
27-19116-003	DC AMMETER INDICATOR
422-18152-131	SDC MODULE
422-18152-303	SDC MODULE
422-18152-311	SDC MODULE
422-18152-319	SDC MODULE
422-18152-807	SDC MODULE
422-18152-832	SDC MODULE
422-18152-932	SDC MODULE
422-18152-934	SDC MODULE
422-18152-944	SDC MODULE
422-18152-945	SDC MODULE
422-23080-021	SDC MODULE
422-23080-024	SDC MODULE
422-23080-038	SDC MODULE
422-23080-041	SDC MODULE
422-30510-123	SDC/SAT/TAS COMPUTER
422-30510-148	SDC/SAT/TAS COMPUTER
422-30510-155	SDC/SAT/TAS COMPUTER
570-23932-211	PNEUMATIC ALTIMETER
570-23932-212	PNEUMATIC ALTIMETER
570-23932-314	PNEUMATIC ALTIMETER
570-24929-932	ENCODING ALTIMETER
571-25005-311	PNEUMATIC ENCODING ALTIMETER
575-25850-264	MAAS/MACH INDICATOR
575-25850-270	MAAS/MACH INDICATOR
575-25850-936	AIRSPEED
575-35250-302	MAAS/DIGITAL MACH INDICATOR
575-35250-351	MAAS/DIGITAL MACH INDICATOR
575-35250-401	MAAS/DIGITAL MACH AIRSPEED
575-35250-552	MAAS/DIGITAL MACH INDICATOR
422-30510-156	SDC/SAT/TAS COMPUTER
422-30510-217	SDC MODULE
422-30510-220	SDC MODULE
422-30510-256	SDC MODULE
5035PB-P159	ENCODING ALTIMETER
64050-860-1	AIRSPEED INDICATOR
518-16007-235	ENCODING ALTIMETER
518-16007-243	ENCODING ALTIMETER
518-16007-261	ENCODING ALTIMETER



518-16007-331	ENCODING ALTIMETER
518-16007-343	ENCODING ALTIMETER
518-16007-513	ENCODING ALTIMETER
518-16007-711	ENCODING ALTIMETER
518-16007-B213	ENCODING ALTIMETER
518-16007-B47	ENCODING ALTIMETER
519-22702-011	ENCODING ALTIMETER
519-22702-121	ENCODING ALTIMETER
520-5160-004	COURSE SELECTOR INDICATOR
520-5160-008	COURSE SELECTOR INDICATOR
520-5160-009	COURSE SELECTOR INDICATOR
521-29007-001	ENCODING ALTIMETER
521-29007-011	ENCODING ALTIMETER
521-29007-022	ENCODING ALTIMETER
521-29007-211	ENCODING ALTIMETER
521-29007-4016	ENCODING ALTIMETER
521-29007-4020	ENCODING ALTIMETER
521-29007-4107	ENCODING ALTIMETER
521-29007-4126	ENCODING ALTIMETER
521-29007-4204	ENCODING ALTIMETER
521-29007-4212	ENCODING ALTIMETER
521-29007-4225	ENCODING ALTIMETER
521-29007-4236	ENCODING ALTIMETER
521-29007-706	ENCODING ALTIMETER
521-29007-809	ENCODING ALTIMETER
522-2447-556	RADIO SET CONTROL
522-2448-035	CONTROL UNIT
563-193	IND. DAUL PROP AMP
622-3702-013	BEARING DISTANCE INDICATOR
523-29702-015	ENCODING ALTIMETER
523-29702-016	ENCODING ALTIMETER
523-29702-023	ENCODING ALTIMETER
523-29702-076	ENCODING ALTIMETER
523-29702-104	ENCODING ALTIMETER
523-29702-116	ENCODING ALTIMETER
523-29702-151	ENCODING ALTIMETER
523-29702-156	ENCODING ALTIMETER
523-29702-526	ENCODING ALTIMETER
523-29702-536	ENCODING ALTIMETER
523-29702-655	ENCODING ALTIMETER
523-29702-675	ENCODING ALTIMETER
523-29702-951	ENCODING ALTIMETER
540-22722-003	ALTITUDE ALERTER
540-25100-014	ALTITUDE ALERTER
540-25100-023	ALTITUDE ALERTER
570-23932-014	PNEUMATIC ALTIMETER
622-6522-006	CONTROL ADF
5934-1D	PRESSURE ALTIMETER
5934-3D	PRESSURE ALTIMETER



5934M-1D	PRESSURE ALTIMETER
5934A-1D	PRESSURE ALTIMETER
5934A-3D	PRESSURE ALTIMETER
5934P-3D	PRESSURE ALTIMETER
820-578	AOA IND
JG298A3	PRESS RATIO IND
172937-001	SWITCH
175096-001	ROTARY SELECTOR SWITCH
065-00053-0009	ALTITUDE SELECTOR/ALERter
066-03062-0000	ENCODING ALTIMETER
066-3062-10	ENCODING ALTIMETER
101420-01205	PRESSURE REPORTING ALTIMETER
101450-11953	ALTITUDE REPORTING ALTIMETER IND.
101720-011000	ALTIMETER
101720-11385	ALTIMETER
101720-11386	ALTIMETER
101730-01357	ALTIMETER
101735-01495	ALTIMETER
101735-01695	ALTIMETER
101750-111031	ALTIMETER
102550	REMOTE ATT IND
10450-11150	PRESSURE ALTIMETER
152BL801E	THERMOCOUPLE TEMPERATURE INDICATOR
152BL803	THERMOCOUPLE TEMPERATURE INDICATOR
16007-163	ENCODING ALTIMETER
16007-187	ENCODING ALTIMETER
16007-250	ENCODING ALTIMETER
16007-312	ENCODING ALTIMETER
16007-313	ENCODING ALTIMETER
16007-314	ENCODING ALTIMETER
1625-1	WINDSHIELD TEMP CTRL
20040-11229	AIRSPED INDICATOR
201530-11373	MAX ALLOWABLE AIRSPEED
24929-934	ENCODING ALTIMETER
22702-002	ENCODING ALTIMETER
22702-033	ENCODING ALTIMETER
22702-541	ENCODING ALTIMETER
22702-542	ENCODING ALTIMETER
233T3239-17	CARGO HEAT PANEL
233T3239-8	CARGO HEAT PANEL
233T4222-27	INTER/JACK PANEL ASSY.
233T4222-300	INTER/JACK PANEL ASSY.
233T4222-8	INTER/JACK PANEL ASSY.
23932-001	ALTIMETER
23932-002	ALTIMETER
23932-403	ALTIMETER
23932-412	ALTIMETER
24929-001	ENCODING ALTIMETER
24929-005	ENCODING ALTIMETER



24929-008	ENCODING ALTIMETER
24929-015	ENCODING ALTIMETER
24929-021	ENCODING ALTIMETER
24929-031	ENCODING ALTIMETER
28702-956	ENCODING ALTIMETER
28702-957	ENCODING ALTIMETER
29007-001	ENCODING ALTIMETER
29007-021	ENCODING ALTIMETER
4018639-914	AUTOPILOT CONTROL
4018639-920	AUTOPILOT CONTROL
276AS4	MAX/ALLOW AIRSPEED
28007-318	ENCODING ALTIMETER
28702-012	ENCODING ALTIMETER
28702-501	ENCODING ALTIMETER
28702-553	ENCODING ALTIMETER
SLZ9200A	IVSI
SLZ9688A	IVSI
WL101AMS5	ALTIMETER/AIRSPEED IND.
WL1350AMMS1	COUNTER/POINTER ALTIMETER
WL1407AMMS2	SERVO ALTIMETER
WL1604AM1	COUNTER POINTER ALTIMETER
29007-204	ENCODING ALTIMETER
29007-208	ENCODING ALTIMETER
29007-218	ENCODING ALTIMETER
29007-4114	ENCODING ALTIMETER
29007-4126	ENCODING ALTIMETER
29007-4221	ENCODING ALTIMETER
29007-4302	ENCODING ALTIMETER
29007-4806	ENCODING ALTIMETER
29007-711	ENCODING ALTIMETER
29007-719	ENCODING ALTIMETER
29007-820	ENCODING ALTIMETER
29702-082	ENCODING ALTIMETER
29702-122	ENCODING ALTIMETER
29702-182	ENCODING ALTIMETER
29702-563	ENCODING ALTIMETER
29702-611	ENCODING ALTIMETER
29702-614	ENCODING ALTIMETER
29702-622	ENCODING ALTIMETER
29702-653	ENCODING ALTIMETER
29702-665	ENCODING ALTIMETER
29702-672	ENCODING ALTIMETER
29704-B4001	ENCODING ALTIMETER
30260-3126	VERTICAL VELOCITY INDICATOR
31400-013	PNEUMATIC ALTIMETER
31400-116	PNEUMATIC ALTIMETER
3252013-1201	ENCODING ALTIMETER
36155-1AF25A2	RAD MAG COMP IND
36162-1AJ25A1	RAD MAG COMP IND



39600-584	ALTIMETER CODER
4018368-912	MODE SELECTOR
518-28007-021	ENCODING ALTIMETER
518-28007-023	ENCODING ALTIMETER
518-28007-028	ENCODING ALTIMETER
518-28007-174	ENCODING ALTIMETER
518-28007-205	ENCODING ALTIMETER
518-28007-213	ENCODING ALTIMETER
518-28007-236	ENCODING ALTIMETER
4018639-930	AUTOPILOT CONTROL
4018639-933	AUTOPILOT CONTROL
4029529-903	HSI
44929-935	ENCODING ALTIMETER
45100-E2111	ALTITUDE ALERTER
49707-122	SERVO-PNEU ALT.
501-1075-01	EMERGENCY POWER SUPPLY
501-1075-06	EMERGENCY POWER SUPPLY
501-1075-10	EMERGENCY POWER SUPPLY
501-1228-04	EMERGENCY POWER SUPPLY
5035P-P22	ENCODING ALTIMETER
5035P2-P44	ENCODING ALTIMETER
518-28007-008	ENCODING ALTIMETER
519-28702-586	ENCODING ALTIMETER
519-28702-012	ENCODING ALTIMETER
519-28702-055	ENCODING ALTIMETER
519-28702-062	ENCODING ALTIMETER
519-28702-063	ENCODING ALTIMETER
519-28702-566	ENCODING ALTIMETER
519-28702-572	ENCODING ALTIMETER
519-28702-907	ENCODING ALTIMETER
519-28704-D1001	ENCODING ALTIMETER
522-2377-003	DISTANCE -HEADING IND
522-2447-253	CONTROL UNIT
522-2638-005	COURSE INDICATOR
522-2638-010	COURSE INDICATOR
522-2782-004	COURSE INDICATOR
5934PM-3	PRESSURE ALTIMETER
522-3877-001	FLIGHT DIRECTOR IND.
522-4363-004	RADIO ALTITUDE INDICATOR
563-069	HYDRAULIC PRESSURE INDICATOR
563-085	ALCOHOL WATER INJECTION QTY. IND.
570-24929-006	ENCODING ALTIMETER
622-0837-001	FLIGHT DIRECTOR INDICATOR
622-1205-004	RADIO ALTITUDE IND.
622-1352-002	FLIGHT DIRECTOR IND.
570-24929-101	ENCODING ALTIMETER
570-24929-102	ENCODING ALTIMETER
570-24929-412	ENCODING ALTIMETER
570-31400-004	PNEUMATIC ALTIMETER



622-4160-002	DIGITAL RADIO ALTITUDE INDICATOR
622-4160-013	DIGITAL RADIO ALTITUDE INDICATOR
622-4176-007	HSI
720-187	TRIM INDICATOR
622-6522-001	CONTROL ADF
7000466-916	ATT. DIR. INDICATOR
7000469-917	HSI
7000469-922	HSI
7000605-906	MOEDE SELECTOR
7000605-911	MODE SELECTOR
7000836-909	ADI
7000836-923	ATTITUDE DIRECTOR IND.
7000836-927	ATTITUDE DIRECTOR INDICATOR
7001179-903	HORIZONTAL SITUATION INDICATOR
7001179-911	HORIZONTAL SITUATION INDICATOR
7001182-905	ATTITUDE DIRECTOR IND.
7003897-902	A/P CONTROLLER
7003938-912	MS-400 MODE SELECTOR
772-5005-006	FLIGHT DIRECTOR INDICATOR
772-5006-001	FLIGHT DIRECTOR IND
772-5299-001	FLIGHT DIRECTOR IND.
772-5370-003	COURSE INDICATOR
777-1224-003	FLIGHT DIRECTOR IND.
787-6173-001	FLIGHT DIRECTOR IND.
787-6173-002	FLIGHT DIRECTOR IND.
787-6173-008	FLIGHT DIRECTOR IND.
787-6173-206	FLIGHT DIRECTOR IND.
792-6091-021	HSI
792-6221-006	REMOTE HDG/CRS SEL
792-6348-103	A/P CONTROLLER
792-6355-003	FLIGHT DIRECTOR INDICATOR
792-6357-008	ATTITUDE DIRECTOR IND.
8059-2B-35NVG	AIRSPEED
8140B-20MB-LX	ENCODING ALTIMETER
8140B-S35LW-28V	ENCODING ALTIMETER
8230	MAX ALLOWABLE AIRSPEED I
066-3020-02	FLIGHT COMMAND IND.
066-3024-11	PICTORIAL NAVIGATION INDICATOR
AM275	ALTITUDE ALERTER
B0200-81122	AIRSPEEDDATA
B45152-10-003	ENCODER ALTIMETER
64050-862-1	AIRSPEED INDICATOR
64050-868-1	AIRSPEED INDICATOR
20040-11219	AIRSPEED INDICATOR
23080-038	SDC MODULE
3A43.32.20F.28.1.CL	2-INCH ALTIMETER
3A43.62.51F.28.1.GM	2-INCH ALTIMETER
25005-311	PNEUMATIC ENCODING ALTIMETER
25850-202	MAAS/MACH INDICATOR



25850-215	MAAS/MACH INDICATOR
25850-269	MAAS/MACH INDICATOR
25850-365	MAAS/MACH INDICATOR
422-18152-901	SDC MODULE
422-18152-904	SDC MODULE
422-18152-905	SDC MODULE
422-18152-907	SDC MODULE
422-18152-927	SDC MODULE
422-18152-929	SDC MODULE
422-18152-943	SDC MODULE
422-23080-037	SDC MODULE
422-23080-110	SDC MODULE
422-30510-118	SDC/SAT/TAS COMPUTER
422-30510-126	SDC/SAT/TAS COMPUTER
422-30510-135	SDC/SAT/TAS COMPUTER
422-30510-137	SDC/SAT/TAS COMPUTER
422-30510-205	SDC MODULE
422-30510-257	SDC MODULE
422-30510-269	SDC MODULE
285T0022-43	AUDIO SEL PANEL
5035P2-P16	ENCODING ALTIMETER
29007-4223	ALTIMETER
30510-105	SDCM/SAT/TAS COMPUTER
30510-123	SDCM/SAT/TAS COMPUTER
30510-133	SDCM/SAT/TAS COMPUTER
30980-106	SAT/TAS COMPUTER
30980-136	SAT/TAS COMPUTER
30980-332	SAT/TAS COMPUTER
30980-354	SAT/TAS COMPUTER
30980-363	SAT/TAS COMPUTER
31500-443	MAX ALLOWABLE IND.
422-18152-140	SDC MODULE
422-18152-218	SDC MODULE
422-18152-307	SDC MODULE
422-18152-316	SDC MODULE
422-18152-336	SDC MODULE
422-18152-825	SDC MODULE
422-18152-839	SDC MODULE
422-18152-847	SDC MODULE
16007-1311	ENCODING ALTIMETER
18152-307	SDC MODULE
18152-316	SDC MODULE
18152-317	SDC MODULE
521-29007-4214	ENCODING ALTIMETER
521-29007-4221	ENCODING ALTIMETER
521-29007-4224	ALTIMETER
521-29007-713	ENCODING ALTIMETER
521-29007-801	ENCODING ALTIMETER
521-29007-810	ENCODING ALTIMETER



522-1400-000	SERVO AMPLIFIER
523-29702-565	ENCODING ALTIMETER
523-29702-574	ENCODING ALTIMETER
523-29702-576	ENCODING ALTIMETER
523-29702-626	ENCODING ALTIMETER
523-29702-676	ENCODING ALTIMETER
523-29702-805	ENCODING ALTIMETER
527-48707-204	ALTIMETER
540-22722-018	ALTITUDE ALERTER
540-24982-971	ALTITUDE ALERTER/PRESELECT
540-25100-202	ALTITUDE ALERTER
570-23932-006	PNEUMATIC ALTIMETER
570-23932-033	PNEUMATIC ALTIMETER
570-23932-313	PNEUMATIC ALTIMETER
570-23932-413	PNEUMATIC ALTIMETER
570-24929-931	ENCODING ALTIMETER
575-25850-310	MAAS/MACH INDICATOR
575-29846-208	MAX ALLOW/MACH AIRSPEED IND
622-2265-026	FLIGHT GUIDANCE PANEL
622-2265-044	FLIGHT GUIDANCE PANEL
5934AM-1D	PRESSURE ALTIMETER
5934PM-1D	PRESSURE ALTIMETER
622-6520-004	CONTROL COM
622-6522-017	CONTROL ADF
622-6523-208	CONTROL TRANS
64050-866-1	A/S INDICATOR
518-16007-342	ENCODING ALTIMETER
518-16007-346	ENCODING ALTIMETER
518-16007-408	ENCODING ALTIMETER
518-16007-707	ENCODING ALTIMETER
518-16007-720	ENCODING ALTIMETER
522-3617-500	RADIO SET CONTROL
523-29702-101	ENCODING ALTIMETER
523-29702-114	ENCODING ALTIMETER
523-29702-115	ENCODING ALTIMETER
523-29702-125	ENCODING ALTIMETER
523-29702-132	ENCODING ALTIMETER
523-29702-501	ENCODING ALTIMETER
523-29702-505	ENCODING ALTIMETER
523-29702-511	ENCODING ALTIMETER
523-29702-554	ENCODING ALTIMETER
518-16007-762	ENCODING ALTIMETER
518-16007-803	ENCODING ALTIMETER
518-16007-810	ENCODING ALTIMETER
518-16007-B46	ENCODING ALTIMETER
518-28007-431	ENCODING ALTIMETER
518-28007-926	ENCODING ALTIMETER
519-22702-015	ENCODING ALTIMETER
519-22702-041	ENCODING ALTIMETER



519-22702-542	ENCODING ALTIMETER
521-29007-002	ENCODING ALTIMETER
521-29007-213	ENCODING ALTIMETER
521-29007-223	ENCODING ALTIMETER
521-29007-4011	ENCODING ALTIMETER
521-29007-4120	ENCODING ALTIMETER
521-29007-4129	ENCODING ALTIMETER
065-0046-05	ALTITUDE SELECTOR
066-03042-0003	RMI
066-03046-0002	PICTORIAL NAVIGATION INDICATOR
066-3024-10	PICTORIAL NAV IND.
066-3034-04	NAVIGATION IND.
101627-11377	REPORTING ALTIMETER
101720-111005	ALTIMETER
101735-011004	ALTIMETER
527-48707-202	ALTIMETER
152BL801D	THERMOCOUPLE TEMPERATURE INDICATOR
16007-333	ENCODING ALTIMETER
16007-337	ENCODING ALTIMETER
16007-983	ENCODING ALTIMETER
16007-B43	ENCODING ALTIMETER
1611AM3	COUNTER/POINTER ALT.
25005-001	PNEUMATIC ENCODING ALTIMETER
25100-134	ALTITUDE ALERTER
22702-021	ENCODING ALTIMETER
22702-121	ENCODING ALTIMETER
22722-020	ALTITUDE ALERTER
233T3239-11	CARGO HEAT PANEL
233T3239-300	CARGO HEAT PANEL
23932-022	ALTIMETER
23932-053	ALTIMETER
23932-314	ALTIMETER
23989-006	ALTITUDE ALERTER
23989-512	ALTITUDE ALERTER
24929-018	ENCODING ALTIMETER
24929-106	ENCODING ALTIMETER
24929-212	ENCODING ALTIMETER
24929-301	ENCODING ALTIMETER
24929-405	ENCODING ALTIMETER
24929-919	ENCODING ALTIMETER
2591411-907	ATTITUDE DIRECTOR IND.
28702-586	ENCODING ALTIMETER
28702-802	ENCODING ALTIMETER
28704-001	ENCODING ALTIMETER
4018639-924	AUTOPILOT CONTROL
26465-911	MAAS/MACH INDICATOR
26465-960	MAAS/MACH INDICATOR
27-19145-3	CABIN AIR TEMPERATURE INDICATOR
27-19145-5	CABIN AIR TEMPERATURE INDICATOR



27-19157-5	RPM INDICATOR
270-2436-020	CONTROL UNIT
270-2436-090	CONTROL UNIT
28007-007	ENCODING ALTIMETER
28007-008	ENCODING ALTIMETER
28007-030	ENCODING ALTIMETER
28007-171	ENCODING ALTIMETER
JG298A5	EPR INDICATOR
4002531-905	ADI
4016341-902	BAROMETRIC ALTITUDE IND.
4016341-907	BAROMETRIC ALTITUDE IND.
4018368-922	MODE SELECTOR
4018368-923	MODE SELECTOR
4018639-902	AUTOPILOT CONTROL
518-28007-019	ENCODING ALTIMETER
518-28007-271	ENCODING ALTIMETER
518-28007-313	ENCODING ALTIMETER
4018639-926	AUTOPILOT CONTROL
45100-C2010	ALTITUDE ALERTER
45100-D2010	ALERTER
501-1228-06	EMERGENCY POWER SPLY
501-1719-02	EMERGENCY POWER SUPPLY
5021-3001	T.O.T. INDICATOR
5035PB-P57	ENCODING ALTIMETER
51-4226-1	BATTERY TEMP IND
51-4226-A3	BATTERY TEMP IND
519-28702-803	ENCODING ALTIMETER
519-28702-904	ENCODING ALTIMETER
519-28702-014	ENCODING ALTIMETER
519-28702-023	ENCODING ALTIMETER
519-28702-084	ENCODING ALTIMETER
519-28702-504	ENCODING ALTIMETER
522-4114-002	RADIO ALTITUDE INDICATOR
5506-S53	ENCODING ALTIMETER
5506L-SG12	ALTITUDE ALERTER
5506L-SG2	ALTITUDE ALERTER
563-062	DC AMMETER INDICATOR
570-24929-005	ENCODING ALTIMETER
622-0555-001	RADIO MAGNETIC IND.
622-0555-003	RADIO MAGNETIC IND.
622-0945-006	FLIGHT MODE SELECTOR
622-1352-003	FLIGHT DIRECTOR INDICATOR
570-24929-028	ENCODING ALTIMETER
570-24929-313	ENCODING ALTIMETER
570-31400-118	PNEUMATIC ALTIMETER
622-4151-014	COURSE INIDCIATOR
622-4160-001	DIGITAL RADIO ALTITUDE INDICATOR
622-4160-012	DIGITAL RADIO ALTITUDE INDICATOR
622-4160-014	DIGITAL RADIO ALTITUDE INDICATOR



622-5486-011	FLIGHT MODE SELECTOR
64111-960-1	ALTIMETER
64141-362-1	ALTIMETER
7000466-905	ATT. DIR. INDICATOR
7000466-951	ATT. DIR. INDICATOR
7000469-926	HSI
7000836-903	ADI
7000836-917	ATTITUDE DIRECTOR INDICATOR
7001179-952	HSI
7001182-914	ATTITUDE DIRECTOR INDICATOR
7002493-912	HSI
7003897-909	A/P CONTROLLER
7003897-916	A/P CONTROLLER
7003897-926	A/P CONTROLLER
7003938-903	MS-400 MODE SELECTOR
787-6173-214	FLIGHT DIRECTOR IND.
792-6091-014	HSI
792-6091-015	HSI
792-6355-001	FLIGHT DIRECTOR INDICATOR
8047/20A	2-INCH ALTIMETER
8140B-30MB	ENCODING ALTIMETER
B0200-81117	AIRSPPEEDDATA
B0200-81121	AIRSPPEEDDATA
SEDL-OC2L	TORQUE W/BUG IND
SLZ9200A-1	IVSI
WL1103AMMS2	SERVO ALTIMETER
WL1381AMMS1	COUNTER/POINTER ALTIMETER
WL1801AM2	ALTIMETER
18152-301	SDC MODULE
20040-11216	AIRSPPEED INDICATOR
066-03064-0001	ENCODING ALTIMETER
066-3020-07	FLIGHT COMMAND IND.
066-3024-08	PICTORIAL NAVIGATION INDICATOR
066-3024-49	PICTORIAL NAVIGATION INDICATOR
15900-113	CABIN ALTITUDE, RATE & DPI
28007-174	ENCODING ALTIMETER
28007-214	ENCODING ALTIMETER
28007-314	ENCODING ALTIMETER
28702-002	ENCODING ALTIMETER
28702-033	ENCODING ALTIMETER
28702-072	ENCODING ALTIMETER
28702-521	ENCODING ALTIMETER
28702-561	ENCODING ALTIMETER
28702-565	ENCODING ALTIMETER
29007-4021	ENCODING ALTIMETER
29007-4023	ENCODING ALTIMETER
29007-4120	ENCODING ALTIMETE
29007-4122	ENCODING ALTIMETER
29007-4124	ENCODING ALTIMETER



29007-4128	ENCODING ALTIMETER
29007-4202	ENCODING ALTIMETER
29007-4301	ENCODING ALTIMETER
29007-4321	ENCODING ALTIMETER
29007-702	ENCODING ALTIMETER
29007-713	ENCODING ALTIMETER
29007-716	ENCODING ALTIMETER
29702-033	ENCODING ALTIMETER
29702-062	ENCODING ALTIMETER
29702-104	ENCODING ALTIMETER
29702-121	ENCODING ALTIMETER
29702-124	ENCODING ALTIMETER
519-28702-514	ENCODING ALTIMETER
519-28702-551	ENCODING ALTIMETER
519-28702-576	ENCODING ALTIMETER
519-28702-581	ENCODING ALTIMETER
519-28704-012	ENCODING ALTIMETER
519-28704-A1001	ENCODING ALTIMETER
520-3137-317	RMI
522-0974-003	DISTANCE-HEADING IND
522-3122-010	FLIGHT DIRECTOR IND.
522-3122-012	FLIGHT DIRECTOR IND.
522-3122-013	FLIGHT DIRECTOR IND.
522-3206-004	FLIGHT DIRECTOR IND.
5934D-1	PRESSURE ALTIMETER
5934PA-1	PRESSURE ALTIMETER
5934PAM-3	PRESSURE ALTIMETER
5934PD-1	PRESSURE ALTIMETER
5934PD-3	PRESSURE ALTIMETER
522-3206-007	FLIGHT DIRECTOR IND.
522-3752-001	FLIGHT DIRECTOR IND.
522-3752-002	FLIGHT DIRECTOR IND.
29702-515	ENCODING ALTIMETER
29702-553	ENCODING ALTIMETER
29702-626	ENCODING ALTIMETER
29702-654	ENCODING ALTIMETER
29702-666	ENCODING ALTIMETER
29702-686	ENCODING ALTIMETER
29704-001	ENCODING ALTIMETER
3117LB22C	RMI
31400-011	PNEUMATIC ALTIMETER
31400-118	PNEUMATIC ALTIMETER
39380-003	AIR DATA UNIT
3A43.32.20F.28.4.EE	2-INCH ALTIMETER
4002531-901	ADI
2591411-264	ATTITUDE DIRECTOR INDICATOR
27-19118-005	TRI-UNIT INDICATOR
27-19121-003	HYDRAULIC PRESSURE INDICATOR
27-19137-001	AIRSPED INDICATOR



27-19138-001	ALTIMETER, PRESSURE
29007-4217	ENCODING ALTIMETER
30980-104	SAT/TAS COMPUTER
30980-120	SAT/TAS COMPUTER
30980-126	SAT/TAS COMPUTER
30980-163	SAT/TAS COMPUTER
30980-165	SAT/TAS COMPUTER
523-29702-026	ENCODING ALTIMETER
523-29702-121	ENCODING ALTIMETER
523-29702-171	ENCODING ALTIMETER
523-29702-176	ENCODING ALTIMETER
523-29702-535	ENCODING ALTIMETER
523-29702-601	ENCODING ALTIMETER
523-29702-635	ENCODING ALTIMETER
523-29702-636	ENCODING ALTIMETER
523-29702-653	ENCODING ALTIMETER
523-29702-673	ENCODING ALTIMETER
523-29702-906	ENCODING ALTIMETER
540-22722-022	ALTITUDE ALERTER
540-23989-511	ALTITUDE ALERTER
540-24982-001	ALTITUDE ALERTER/PRESELECT
570-23932-204	PNEUMATIC ALTIMETER
570-23932-312	PNEUMATIC ALTIMETER
570-23932-901	PNEUMATIC ALTIMETER
570-24929-532	ENCODING ALTIMETER
571-25005-002	PNEUMATIC ENCODING ALTIMETER
571-25005-211	PNEUMATIC ENCODING ALTIMETER
571-25005-212	PNEUMATIC ENCODING ALTIMETER
3A43.62.51F.05.1.GM	2-INCH ALTIMETER
518-16007-135	ENCODING ALTIMETER
518-16007-167	ENCODING ALTIMETER
518-16007-169	ENCODING ALTIMETER
518-16007-219	ENCODING ALTIMETER
518-16007-231	ENCODING ALTIMETER
518-16007-236	ENCODING ALTIMETER
518-16007-251	ENCODING ALTIMETER
518-16007-264	ENCODING ALTIMETER
518-16007-401	ENCODING ALTIMETER
518-16007-406	ENCODING ALTIMETER
518-16007-503	ENCODING ALTIMETER
518-16007-506	ENCODING ALTIMETER
518-16007-709	ENCODING ALTIMETER
518-16007-719	ENCODING ALTIMETER
518-16007-801	ENCODING ALTIMETER
518-16007-819	ENCODING ALTIMETER
518-16007-821	ENCODING ALTIMETER
518-16007-B211	ENCODING ALTIMETER
519-22702-003	ENCODING ALTIMETER
519-22702-032	ENCODING ALTIMETER



519-22702-301	ENCODING ALTIMETER
519-22702-541	ENCODING ALTIMETER
521-29007-003	ENCODING ALTIMETER
521-29007-015	RAD ALT ALTIMETER
521-29007-023	ENCODING ALTIMETER
521-29007-024	ENCODING ALTIMETER
521-29007-224	ENCODING ALTIMETER
521-29007-4003	ENCODING ALTIMETER
521-29007-4007	ENCODING ALTIMETER
521-29007-4008	ENCODING ALTIMETER
521-29007-4028	ALTIMETER
521-29007-4116	ENCODING ALTIMETER
521-29007-4216	ENCODING ALTIMETER
422-18152-104	SDC MODULE
422-18152-117	SDC MODULE
422-18152-137	SDC MODULE
422-18152-325	SDC MODULE
422-18152-337	SDC MODULE
422-18152-804	SDC MODULE
422-18152-808	SDC MODULE
521-29007-4218	ALTIMETER
521-29007-4301	ENCODING ALTIMETER
521-29007-4321	ENCODING ALTIMETER
521-29007-4719	ENCODING ALTIMETER
521-29007-4820	ENCODING ALTIMETER
521-29007-703	ENCODING ALTIMETER
521-29007-811	ENCODING ALTIMETER
521-29007-817	ENCODING ALTIMETER
521-29007-903	ENCODING ALTIMETER
422-18152-916	SDC MODULE
422-18152-922	SDC MODULE
422-18152-933	SDC MODULE
422-18152-941	SDC MODULE
422-18152-948	SDC MODULE
422-23080-007	SDC MODULE
422-23080-011	SDC MODULE
422-23080-019	SDC MODULE
422-23080-111	SDC MODULE
422-23080-139	SDC MODULE
422-30510-206	SDC MODULE
422-30510-208	SDC MODULE
422-30510-247	SDC MODULE
422-30510-259	SDC MODULE
422-30510-270	SDC MODULE
25850-271	MAAS/MACH INDICATOR
25850-304	MAAS/MACH INIDICATOR
25850-335	MAAS/MACH INDICATOR
622-6520-008	CONTROL COM
622-6521-014	CONTROL NAV



622-6523-005	CONTROL TRANS
6315	MANIF/FUEL PRES GAGE
7000466-913	ATT. DIR. INDICATOR
7018341-901	MODE SELECTOR
822-1120-001	CONTROL COM
822-1120-003	CONTROL COM
822-1120-008	CONTROL COM
575-25850-202	MAAS/MACH INDICATOR
575-25850-210	MAAS/MACH INDICATOR
575-25850-730	AIRSPEED
575-35250-203	MAAS/DIGITAL MACH INDICATOR
575-35250-402	MAAS/DIGITAL MACH INDICATOR
575-35250-451	MAAS/DIGITAL MACH INDICATOR
575-35250-503	MAAS/DIGITAL MACH INDICATOR
575-35900-402	MAX ALLOWABLE/MACH AIRSPEED IND.
214C50-68	ALTITUDE PRESSURE SWITCH
22702-014	ENCODING ALTIMETER
22702-022	ENCODING ALTIMETER
22702-031	ENCODING ALTIMETER
22702-511	ENCODING ALTIMETER
22722-022	ALTITUDE ALERTER
233T3239-14	CARGO HEAT PANEL
233T3239-5	CARGO HEAT PANEL
233T4222-36	INTER JACK/PANEL ASSY.
23932-024	ALTIMETER
23932-202	ALTIMETER
23932-302	ALTIMETER
23932-312	ALTIMETER
23932-313	ALTIMETER
23932-401	ALTIMETER
23932-414	ALTIMETER
24929-017	ENCODING ALTIMETER
24929-101	ENCODING ALTIMETER
24929-213	ENCODING ALTIMETER
24929-403	ENCODING ALTIMETER
24929-501	ENCODING ALTIMETER
24929-519	ENCODING ALTIMETER
24929-531	ENCODING ALTIMETER
24929-923	ENCODING ALTIMETER
28702-952	ENCODING ALTIMETER
29007-020	ENCODING ALTIMETER
4018639-908	AUTOPILOT CONTROL
4018639-912	AUTOPILOT CONTROL
4018639-919	AUTOPILOT CONTROL
27-19157-3	PERCENT RPM IND.
270-2196-020	AIRSPEED SENSOR
28007-205	ENCODING ALTIMETER
28007-266	ENCODING ALTIMETER
28007-268	ENCODING ALTIMETER



28007-301	ENCODING ALTIMETER
28007-311	ENCODING ALTIMETER
28007-315	ENCODING ALTIMETER
28007-923	ENCODING ALTIMETER
28702-006	ENCODING ALTIMETER
28702-015	ENCODING ALTIMETER
28702-032	ENCODING ALTIMETER
28702-052	ENCODING ALTIMETER
28702-502	ENCODING ALTIMETER
28702-505	ENCODING ALTIMETER
28702-514	ENCODING ALTIMETER
522-3206-009	FLIGHT DIRECTOR IND.
522-3487-003	FLIGHT DIRECTOR IND.
522-4354-002	RADIO ALTITUDE INDICATOR
522-4529-002	FLIGHT DIRECTOR IND.
5504-SG	ENCODING ALTIMETER
55050-3110	CABIN ALT/DIFF. PRES. INDICATOR
5506-S5-Y4	ENCODING ALTIMETER
5506-SG-Y	ENCODING ALTIMETER
563-151	CABIN AIR TEMPERATURE INDICATOR
570-24929-011	ENCODING ALTIMETER
622-0224-002	ATTITUDE DIRECTOR IND
622-0555-006	RADIO MAGNETIC IND.
622-0855-002	FLIGHT DIRECTOR INDICATOR
622-0944-003	FLIGHT MODE SELECTOR
622-1352-008	FLIGHT DIRECTOR INDICATOR
622-2938-001	RADIO ALTITUDE IND.
570-24929-214	ENCODING ALTIMETER
570-24929-302	ENCODING ALTIMETER
570-31400-002	PNEUMATIC ALTIMETER
570-31400-104	PNEUMATIC ALTIMETER
570-31400-114	PNEUMATIC ALTIMETER
622-4176-001	HSI
622-4176-004	HSI
622-4423-001	ATTITUDE DIRECTOR IND.
622-4808-001	ATTITUDE DIRECTOR IND.
7130B	VSI/IVSI
7140B	VSI/IVSI
64111-951-1	ALTIMETER
7000469-911	HSI
7000605-907	MODE SELECTOR
7000839-905	RADIO ALTIMETER INDICATOR
7001179-913	HORIZONTAL SITUATION INDICATOR
7001179-915	HORIZONTAL SITUATION INDICATOR
7001179-963	HSI
7001182-901	ATTITUDE DIRECTOR IND.
7001182-912	ATTITUDE DIRECTOR INDICATOR
7001182-913	ATTITUDE DIRECTOR INDICATOR
7001182-915	ATTITUDE DIRECTOR INDICATOR



7002493-904	HSI
7003897-906	A/P CONTROLLER
7003897-914	A/P CONTROLLER
7003897-920	A/P CONTROLLER
792-6357-007	ATTITUDE DIRECTOR IND.
8000	AIRSPED INDICATOR
8047-700-3	2-INCH ALTIMETER
8140B-S20LW	ENCODING ALTIMETER
820-599	INDICATOR
820-670	TRI-UNIT IND.
9813-25-21	DUAL TORQUE INDICATOR
A218-862600-00	ENGINE FIRE SHUT-OFF SWITCH
28702-524	ENCODING ALTIMETER
29007-205	ENCODING ALTIMETER
29007-4106	ENCODING ALTIMETER
29007-4109	ENCODING ALTIMETER
29007-4229	ENCODING ALTIMETER
29007-4233	ENCODING ALTIMETER
29007-4322	ENCODING ALTIMETER
29007-705	ENCODING ALTIMETER
29007-815	ENCODING ALTIMETER
29007-816	ENCODING ALTIMETER
29702-015	ENCODING ALTIMETER
29702-064	ENCODING ALTIMETER
29702-074	ENCODING ALTIMETER
29702-085	ENCODING ALTIMETER
29702-115	ENCODING ALTIMETER
29702-125	ENCODING ALTIMETER
29702-163	ENCODING ALTIMETER
29702-506	ENCODING ALTIMETER
29702-514	V
29702-531	ENCODING ALTIMETER
29702-581	ENCODING ALTIMETER
29702-663	ENCODING ALTIMETER
29702-805	ENCODING ALTIMETER
29702-806	ENCODING ALTIMETER
29702-903	ENCODING ALTIMETER
29702-905	ENCODING ALTIMETER
2D540(50B700)	STANDBY ALTIMETER
3117LB62C	RMI
3137LB63C	RMI
31400-001	PNEUMATIC ALTIMETER
31400-107	PNEUMATIC ALTIMETER
35250-252	MAXIMUM ALLOWABLE AIRSPEED
35900-701	MAX ALLOWABLE A/S
3A43.42.51F.05.1.GM	2-INCH ALITMETER
4018368-906	MODE SELECTOR
4018368-919	MS-500 MODE SELECTOR
518-28007-175	ENCODING ALTIMETER



518-28007-232	ENCODING ALTIMETER
518-28007-343	ENCODING ALTIMETER
40400-111	PNEUMATIC ALTIMETER
065-00053-0003	ALTITUDE SELECTOR/ALERter
065-00053-0007	ALTITUDE SELECTOR/ALERter
065-0046-99	ALTITUDE SELECTOR
065-0053-04	ALTITUDE SELECTOR/ALERter
065-0053-07	ALTITUDE SELECTOR/ALERter
066-03042-0001	RMI
066-03042-0002	RMI
066-03062-0012	ENCODING ALTIMETER
066-3031-01	RADAR ALTIMETER INDICATOR
10035-11424	PRESSURE ALTIMETER
101435-01211	PRESSURE REPORTING ALTIMETER
101627-01344	REPORTING ALTIMETER
101635-11381	REPORTING ALTIMETER
101720-01354	ALTIMETER
101735-111006	ALTIMETER
101735-11728	ALTIMETER
49707-121	SERVO-PNEU ALT.
49707-302	SERVO-PNEU ALT.
501-1075-09	EMERGENCY POWER SUPPLY
501-1075-11	EMERGENCY POWER SUPPLY
501-1712-02	EMERGENCY POWER SUPPLY
51010-1113	CABIN PRESS INDICATOR
519-28702-005	ENCODING ALTIMETER
519-28702-051	ENCODING ALTIMETER
519-28702-536	ENCODING ALTIMETER
519-28704-E2101	ENCODING ALTIMETER
522-1771-003	DISTANCE-HEADING IND
522-2447-205	CONTROL UNIT
522-2447-256	CONTROL UNIT
522-2447-259	CONTROL UNIT
522-2638-003	COURSE INDICATOR
522-2638-006	COURSE INDICATOR
522-2644-011	SLAVING ACCESSORY
522-3122-008	FLIGHT DIRECTOR IND.
102220-11886	REPORTING ALTIMETER
10450-11525	COUNTER-DRUM-POINTER ALTIMETER
1301-1001	ALTIMETER
152BL702A	THERMOCOUPLE TEMPERATURE INDICATOR
162BL711	ELECTRICAL RESISTANCE THERMOMETER
18152-941	SDC MODULE
20130-11249	MAX ALLOWABLE AIRSPEED
20130-11278	MAX ALLOWABLE AIRSPEED
25005-032	PNEUMATIC ENCODING ALTIMETER
A81-91	INTERCOM SET CONTROLS
18152-311	SDC MODULE
18152-315	SDC MODULE



23080-037	SDC MODULE
25005-211	PNEUMATIC ENCODING ALTIMETER
25020-1160	AIRSPED INDICATOR
25850-329	MAAS/MACH INDICATOR
114-380049-5	IND, DUAL PROP AMP
20040-11172	AIRSPED INDICATOR
16007-134	ENCODING ALTIMETER
163BL506	TEMP INDICATOR
066-03020-0003	FLIGHT COMMAND IND.
SLZ9845A	IVSI
WCS8194374-805	MAXIMUM ALLOWABLE AIRSPEED/MACH IND
WL1101AMMS4	SERVO ALTIMETER
WL1103AMMS1	SERVO ALTIMETER
WL1103AMMS3	SERVO ALTIMETER
WL1404AMMS6	SERVO ALTIMETER
3A43.52.48F.05.1.GT	2-INCH ALTIMETER
3A43.52.50F.05.1.CB	2-INCH ALTIMETER
523-29702-051	ENCODING ALTIMETER
523-29702-135	ENCODING ALTIMETER
523-29702-155	ENCODING ALTIMETER
523-29702-163	ENCODING ALTIMETER
523-29702-183	ENCODING ALTIMETER
523-29702-502	ENCODING ALTIMETER
523-29702-534	ENCODING ALTIMETER
523-29702-564	ENCODING ALTIMETER
523-29702-573	ENCODING ALTIMETER
523-29702-622	ENCODING ALTIMETER
523-29702-652	ENCODING ALTIMETER
523-29702-663	ENCODING ALTIMETER
422-18152-309	SDC MODULE
422-18152-844	SDC MODULE
422-18152-919	SDC MODULE
422-18152-923	SDC MODULE
422-23080-004	SDC MODULE
422-23080-027	SDC MODULE
422-23080-035	SDC MODULE
422-23080-040	SDC MODULE
422-23080-138	SDC MODULE
422-30510-106	SDC/SAT/TAS COMPUTER
422-30510-108	SDC/SAT/TAS COMPUTER
422-30510-140	SDC/SAT/ATS COMPUTER
422-30510-146	SDC/SAT/TAS COMPUTER
422-30510-153	SDC/SAT/TAS COMPUTER
422-30510-159	SDC/SAT/TAS COMPUTER
422-30510-180	SDC/SAT/TAS COMPUTER
422-30510-224	SDC MODULE
6212	FUEL PRESSURE GAGE
622-0837-003	FLIGHT DIRECTOR IND.
622-0856-001	FLIGHT DIRECTOR INDICATOR



622-3702-009	BEARING DISTANCE INDICATOR
523-29702-666	ENCODING ALTIMETER
523-29702-681	ENCODING ALTIMETER
540-22722-934	ALTITUDE ALERTER
540-23989-005	ALTITUDE ALERTER
540-23989-012	ALTITUDE ALERTER
540-24982-002	ALTITUDE ALERTER/PRESELECT
570-23932-201	PNEUMATIC ALTIMETER
570-23932-304	PNEUMATIC ALTIMETER
570-23932-311	PNEUMATIC ALTIMETER
570-23932-404	PNEUMATIC ALTIMETER
570-23932-414	PNEUMATIC ALTIMETER
570-23932-902	PNEUMATIC ALTIMETER
570-23932-951	PNEUMATIC ALTIMETER
570-24929-2002	ENCODING ALTIMETER
570-24929-935	ALTIMETER
570-24929-951	ENCODING ALTIMETER
570-44929-412	ALTIMETER
571-25005-031	PNEUMATIC ENCODING ALTIMETER
571-25005-502	PNEUMATIC ENCODING ALTIMETER
575-25850-236	MAAS/MACH INDICATOR
518-16007-172	ENCODING ALTIMETER
518-16007-232	ENCODING ALTIMETER
518-16007-262	ENCODING ALTIMETER
518-16007-334	ENCODING ALTIMETER
518-16007-335	ENCODING ALTIMETER
518-16007-337	ENCODING ALTIMETER
518-16007-419	ENCODING ALTIMETER
518-16007-502	ENCODING ALTIMETER
518-16007-718	ENCODING ALTIMETER
518-16007-B215	ENCODING ALTIMETER
519-22702-016	ENCODING ALTIMETER
519-22702-331	ENCODING ALTIMETER
519-22702-512	ENCODING ALTIMETER
519-28704-A2001	ENCODING ALTIMETER
520-5160-001	COURSE SELECTOR INDICATOR
520-5160-010	COURSE SELECTOR INDICATOR
575-25850-243	MAAS/MACH INDICATOR
575-25850-364	MAAS/MACH INDICATOR
575-25850-371	MAAS/MACH INDICATOR
575-26465-811	MAAS/MACH INDICATOR
575-29846-206	MAX ALLOW/MACH AIRSPEED IND
575-35900-601	MAX ALLOWABLE/MACH AIRSPEED IND.
521-29007-205	ENCODING ALTIMETER
521-29007-4018	ENCODING ALTIMETER
521-29007-4122	ENCODING ALTIMETER
521-29007-4128	ENCODING ALTIMETER
521-29007-4208	ENCODING ALTIMETER
521-29007-4213	ENCODING ALTIMETER



521-29007-4304	ENCODING ALTIMETER
521-29007-4706	ENCODING ALTIMETER
521-29007-902	ENCODING ALTIMETER
27-19116-005	VOLT/AMMETER
27-19119-003	FLAP POSITION INDICATOR
27-19158-007	PERCENT TORQUE INDICATOR
27-19161-001	FUEL PRESSURE L/R INDICATOR
27-19171-001	ANGLE OF ATTACK INDICATOR
30510-130	SDCM/SAT/TAS COMPUTER
30980-168	SAT/TAS COMPUTER
30980-335	SAT/TAS COMPUTER
7018341-905	MODE SELECTOR
622-6520-003	CONTROL COM
622-6521-013	CONTROL NAV
3A43.22.20F.05.4.EW	2 INCH ALTIMETER
SEL0C19EJ	ITT INDICATOR
101627-01375	REPORTING ALTIMETER
29702-683	ENCODING ALTIMETER
521-29007-711	ENCODING ALTIMETER
422-18152-816	SDC MODULE
23932-033	ALTIMETER
24929-007	ENCODING ALTIMETER
28007-236	ENCODING ALTIMETER
422-18152-928	SDC MODULE
622-0836-001	FLIGHT DIRECTOR INDICATOR
540-22722-020	ALTITUDE ALERTER
23932-014	ALTIMETER
523-29702-616	ENCODING ALTIMETER
7000469-903	HSI
35250-251	MAXIMUM ALLOWABLE AIRSPEED
540-25100-133	ALTITUDE ALERTER
622-0836-002	FLIGHT DIRECTOR INDICATOR
152BL803B	THERMOCOUPLE TEMPERATURE INDICATOR
066-3046-07	PICTORIAL NAVIGATION IND
622-4808-009	ATTITUDE DIRECTOR IND.
527-48707-101	ALTIMETER
527-48707-102	ALTIMETER
527-48707-103	ALTIMETER
527-48707-104	ALTIMETER
422-23080-106	SDC MODULE
622-6523-205	CONTROL TRANS
522-4529-004	FLIGHT DIRECTOR IND.
B0200-82106	AIRSPEEDDATA
562-843	TORQUE INDICATOR
422-30510-167	SDC/SAT/TAS COMPUTER
066-3062-02	ENCODING ALTIMETER
521-29007-901	ENCODING ALTIMETER
7002493-901	HSI
422-18152-122	SDC MODULE



422-30510-241	SDC MODULE
36154-1AJ25A1	RAD MAG COMP IND
7000836-925	ATTITUDE DIRECTOR IND.
519-28702-025	ENCODING ALTIMETER
518-28007-203	ENCODING ALTIMETER
29702-536	ENCODING ALTIMETER
777-1224-002	FLIGHT DIRECTOR IND.
2592920-445	HSI
523-29702-803	ENCODING ALTIMETER
28704-D2001	ENCODING ALTIMETER
18152-111	SDC MODULE
29702-681	ENCODING ALTIMETER
5934AD-3	PRESSURE ALTIMETER
4018368-920	MS-500 MODE SELECTOR
521-29007-208	ENCODING ALTIMETER
575-25850-365	MAAS/MACH INDICATOR
31400-103	PNEUMATIC ALTIMETER
066-3046-10	PICTORIAL NAVIGATION INDICATOR
066-03020-0011	FLIGHT COMMAND IND.
528-30	NAVIGATION LIGHT
575-25850-215	INDICATOR
24929-030	ENCODING ALTIMETER
521-29007-204	ENCODING ALTIMETER
570-24929-007	ENCODING ALTIMETER
30980-147	SAT/TAS COMPUTER
29702-173	ENCODING ALTIMETER
16007-338	ENCODING ALTIMETER
105AMS1	ALTIMETER/A/S IND.
570-24929-029	ENCODING ALTIMETER
29007-4101	ENCODING ALTIMETER
518-28007-227	ENCODING ALTIMETER
3252013-1101	ENCODING ALTIMETER
30510-108	SDCM SAT/TAS COMPUTER
772-5006-010	FLIGHT DIRECTOR IND
28702-053	ENCODING ALTIMETER
7000469-914	HSI
622-1205-005	RADIO ALTITUDE IND.
101720-01383	ALTIMETER
422-30510-139	SDC/SAT/ATS COMPUTER
422-23080-140	SDC MODULE
22722-013	ALTITUDE ALERTER
7000466-926	ATT. DIR. INDICATOR
422-30510-116	SDC/SAT/TAS COMPUTER
5506L-SG512	ALTITUDE ALERTER
25005-111	PNEUMATIC ENCODING ALTIMETER
622-1352-006	FLIGHT DIRECTOR INDICATOR
570-31400-015	PNEUMATIC ALTIMETER
575-29846-201	MAX ALLOW/MACH AIRSPEED IND
29007-819	ENCODING ALTIMETER



24929-532	ENCODING ALTIMETER
518-28007-264	ENCODING ALTIMETER
422-23080-029	SDC MODULE
28702-073	ENCODING ALTIMETER
422-18152-128	SDC MODULE
28007-172	ENCODING ALTIMETER
7000	VSI/IVSI
622-3594-016	FLIGHT DIRECTOR IND.
521-29007-4207	ENCODING ALTIMETER
518-28007-233	ENCODING ALTIMETER
523-29702-172	ENCODING ALTIMETER
201530-11344	MAX ALLOWABLE AIRSPEED
29702-904	ENCODING ALTIMETER
DGL-OC119D	OUTSIDE AIR TEMP IND.
622-4808-010	ATTITUDE DIRECTOR IND.
575-35250-202	MAAS/DIGITAL MACH INDICATOR
521-29007-4098	ENCODING ALTIMETER
518-28007-763	ENCODING ALTIMETER
523-29702-174	ENCODING ALTIMETER
124.115-1	DUAL TEMP/PRESS IND
521-29007-701	ENCODING ALTIMETER
521-29007-4022	ENCODING ALTIMETER
422-30510-166	SDC/SAT/TAS COMPUTER
521-29007-4114	ENCODING ALTIMETER
622-2506-006	RMI
523-29702-514	ENCODING ALTIMETER
29702-804	ENCODING ALTIMETER
29702-112	ENCODING ALTIMETER
WL1101AMMS7	SERVO ALTIMETER
570-31400-117	PNEUMATIC ALTIMETER
7003897-923	A/P CONTROLLER
787-6173-217	FLIGHT DIRECTOR IND.
523-29702-661	ENCODING ALTIMETER
28007-216	ENCODING ALTIMETER
522-2638-007	COURSE INDICATOR
501-1075-03	EMERGENCY POWER SUPPLY
521-29007-214	ENCODING ALTIMETER
29702-671	ENCODING ALTIMETER
SEL-O19BC	TOT INDICATOR
570-24929-414	ENCODING ALTIMETER
523-29702-523	ENCODING ALTIMETER
422-18152-148	SDC MODULE
16450-1147	STANDBY ALTIMETER
622-0856-002	FLIGHT DIRECTOR INDICATOR
27-19158-009	TORQUE INDICATOR
7003897-924	A/P CONTROLLER
4018639-909	AUTOPILOT CONTROL
518-16007-1311	ENCODING ALTIMETER
16007-332	ENCODING ALTIMETER



521-29007-105	ENCODING ALTIMETER
563-074	OXYGEN CYLINDER INDICATOR
7000469-901	HSI
55050-0103-9	CABIN ALT/DIFF. PRES. INDICATOR
SEL-OC19ET	EGT INDICATOR
23932-031	ALTIMETER
25850-243	MAAS/MACH INDICATOR
622-4176-013	HSI
29702-623	ENCODING ALTIMETER
8047-700-7	2-INCH ALTIMETER
B0200-81127	AIRSPPEEDATA
20020-11327	AIRSPPEED INDICATOR
519-22702-532	ENCODING ALTIMETER
WL1103AMMS13	SERVO ALTIMETER
519-28702-959	ENCODING ALTIMETER
16007-62	ENCODING ALTIMETER
622-0224-005	ATTITUDE DIRECTOR IND.
575-26465-8140	MACH AIRSPEED
29007-201	ENCODING ALTIMETER
29702-176	ENCODING ALTIMETER
29007-4096	ENCODING ALTIMETER
518-16007-721	ENCODING ALTIMETER
519-28702-956	ENCODING ALTIMETER
152BL802A	THERMOCOUPLE TEMPERATURE INDICATOR
522-2447-273	CONTROL UNIT
29007-808	ENCODING ALTIMETER
422-18152-801	SDC MODULE
7018341-801	MODE SELECTOR
7002493-911	HSI
23080-001	SDC MODULE
523-29702-581	ENCODING ALTIMETER
28702-532	ENCODING ALTIMETER
28702-075	ENCODING ALTIMETER
101750-011028	ALTIMETER
519-22702-511	ENCODING ALTIMETER
25100-034	ALTITUDE ALERTER
522-2447-267	CONTROL UNIT
787-6173-215	FLIGHT DIRECTOR IND.
27-19193-13	AIRSPPEED INDICATOR
570-23932-022	PNEUMATIC ALTIMETER
233T3239-10	CARGO HEAT PANEL
622-4938-025	RMI-30
24929-022	ENCODING ALTIMETER
820-576	TEMP CONTROL IND
518-28007-261	ENCODING ALTIMETER
27-19118-7	TRI-UNIT IND.
422-18152-936	SDC MODULE
5934P-3	PRESSURE ALTIMETER
29007-4112	ENCODING ALTIMETER



16007-138	ENCODING ALTIMETER
101450-01274	PRESSURE REPORTING ALTIMETER
7000836-921	ATTITUDE DIRECTOR INDICATOR
523-29702-604	ENCODING ALTIMETER
3117LB23C	RMI
25005-412	ENCODING ALTIMETER
540-23989-003	ALTITUDE ALERTER
48707-204	ALTIMETER
066-03046-0005	PICTORIAL NAVIGATION INDICATOR
622-0835-001	FLIGHT DIRECTOR INDICATOR
5506-S5-4	ENCODING ALTIMETER
519-22702-013	ENCODING ALTIMETER
WL1381AMMS3	COUNTER/POINTER ALTIMETER
518-16007-161	ENCODING ALTIMETER
422-18152-841	SDC MODULE
25850-302	MAAS/MACH INDICATOR
7000466-961	ATT. DIR. INDICATOR
622-6521-009	CONTROL NAV
29007-096	ENCODING ALTIMETER
WL1350AMMS6	COUNTER/POINTER ALTIMETERS
7000466-957	ATTITUDE DIRECTOR INDICATOR
101420-01250	PRESSURE REPORTING ALTIMETER
24929-302	ENCODING ALTIMETER
521-29007-4015	ENCODING ALTIMETER
518-16007-504	ENCODING ALTIMETER
3117LB63C	RMI
066-03046-0011	PICTORIAL NAVIGATION INDICATOR
622-0224-003	ATTITUDE DIRECTOR IND.
29702-512	ENCODING ALTIMETER
7000466-920	ATT. DIR. INDICATOR
28702-013	ENCODING ALTIMETER
519-28702-053	ENCODING ALTIMETER
519-22702-052	ENCODING ALTIMETER
422-30510-133	SDC/SAT/TAS COMPUTER
22722-018	ALTITUDE ALERTER
519-22702-533	ENCODING ALTIMETER
28702-535	ENCODING ALTIMETER
28702-901	ENCODING ALTIMETER
WL101AMS6	ALTIMETER/AIRSPEED IND.
26465-933	MAAS/MACH INDICATOR
7001179-966	HSI
501-1075-15	EMERGENCY POWER SUPPLY
28702-573	ENCODING ALTIMETER
29007-707	ENCODING ALTIMETER
519-28704-D4001	ENCODING ALTIMETER
521-29007-4205	ENCODING ALTIMETER
270-2436-080	CONTROL UNIT
066-3024-43	PICTORIAL NAV IND.
540-25100-034	ALTITUDE ALERTER



792-6348-004	614E-5A A/P CONTROLLER
522-2447-264	CONTROL UNIT
3A43.32.50F.05.1.EG	2-INCH ALTIMETER
521-29007-4130	ENCODING ALTIMETER
2D540(50A700)	STANDBY ALTIMETER
527-48707-212	ALTIMETER
570-23932-202	PNEUMATIC ALTIMETER
27-19193-1	AIRSPEED INDICATOR
422-18152-114	SDC MODULE
30980-360	SAT/TAS COMPUTER
622-0950-001	FLIGHT MODE SELECTOR
065-0053-02	ALTITUDE SELECTOR/ALERter
29702-032	ENCODING ALTIMETER
522-3618-003	FLIGHT DIRECTOR IND.
518-28007-001	ENCODING ALTIMETER
25850-229	MAAS/MACH INDICATOR
570-31400-008	PNEUMATIC ALTIMETER
622-6522-007	CONTROL ADF
518-28007-924	ENCODING ALTIMETER
519-28702-521	ENCODING ALTIMETER
523-29702-122	ENCODING ALTIMETER
622-0141-015	AUTOPILOT PANEL
570-23932-004	PNEUMATIC ALTIMETER
29702-505	ENCODING ALTIMETER
519-28702-515	ENCODING ALTIMETER
570-24929-403	ENCODING ALTIMETER
28702-954	ENCODING ALTIMETER
SEDL-OC4BC	OIL TEMP./PRESS. INDICATOR
28702-585	ENCODING ALTIMETER
422-23080-009	SDC MODULE
518-28007-342	ENCODING ALTIMETER
570-31400-017	PNEUMATIC ALTIMETER
WL1101AMMS3	SERVO ALTIMETER
422-30510-209	SDC MODULE
521-29007-210	ENCODING ALTIMETER
792-6357-002	ATTITUDE DIRECTOR IND.
29007-812	ENCODING ALTIMETER
622-0855-001	FLIGHT DIRECTOR INDICATOR
522-2447-059	CONTROL UNIT
9813-25-17	DUAL TORQUE INDICATOR
SEL019BU	TOT INDICATOR
29702-116	ENCODING ALTIMETER
2591411-908	ATTITUDE DIRECTOR IND.
422-18152-329	SDC MODULE
2592920-901	RADIO DEVIATION IND
522-2447-248	CONTROL UNIT
777-1224-001	FLIGHT DIRECTOR IND.
36154-1AF25A1	RAD MAG COMP IND
90-384026-29	ITT GAUGE



792-6348-104	A/P CONTROLLER
519-28702-071	ENCODING ALTIMETER
066-03062-0009	ENCODING ALTIMETER
518-28007-210	ENCODING ALTIMETER
18152-323	SDC MODULE
501-1228-03	EMERG POWER SPLY
7000839-904	RADIO ALTIMETER INDICATOR
422-18152-931	SDC MODULE
792-6091-005	HSI
30980-108	SAT/TAS COMPUTER
422-23080-105	SDC MODULE
518-16007-311	ENCODING ALTIMETER
575-35250-201	MAAS/DIGITAL MACH INDICATOR
519-28702-086	ENCODING ALTIMETER
422-23080-135	SDC MODULE
16450-1141	STANDBY ALTIMETER
5934PAD-3	PRESSURE ALTIMETER
422-23080-016	SDC MODULE
523-29702-533	ENCODING ALTIMETER
15900-913	CABIN ALT/RATE/DIFF IND.
23932-212	ALTIMETER
622-1204-005	RADIO ALTITUDE IND.
35900-401	MAX ALLOWABLE A/S
26240-1129	AIRSPED INDICATOR
8047/10-2	ALTIMETER
501-1228-02	EMERGENCY POWER SPLY
422-30510-227	SDC MODULE
518-28007-005	ENCODING ALTIMETER
25100-024	ALTITUDE ALERTER
422-23080-136	SDC MODULE
22722-034	ALTITUDE ALERTER
23080-028	SDC MODULE
622-4151-013	COURSE INDICATOR
523-29702-582	ENCODING ALTIMETER
5934-3	PRESSURE ALTIMETER
422-30510-216	SDC MODULE
A35-MA	PRESSURE ALTIMETER
29007-217	ENCODING ALTIMETER
522-3618-001	FLIGHT DIRECTOR IND.
622-4160-003	DIGITAL RADIO ALTITUDE INDICATOR
523-29702-056	ENCODING ALTIMETER
16007-B47	ENCODING ALTIMETER
518-16007-705	ENCODING ALTIMETER
7003897-912	A/P CONTROLLER
29007-4121	ENCODING ALTIMETER
29702-003	ENCODING ALTIMETER
7003938-916	MS-400 MODE SELECTOR
30260-1117	IVSI
2591411-904	ATTITUDE DIRECTOR IND.



787-6173-003	FLIGHT DIRECTOR IND.
RC-60-V-10	VERTICAL SPEED INDICATOR
RC-60-V-10A	VERTICAL SPEED INDICATOR
RC-60-VIL-1	VERTICAL SPEED INDICATOR
2591411-044	ATT. REF. INDICATOR
523-29702-182	ENCODING ALTIMETER
523-29702-625	ENCODING ALTIMETER
570-24929-052	ALTIMETER
066-03062-0010	ENCODING ALTIMETER
570-24929-934	ENCODING ALTIMETER
7001179-955	HSI
540-23989-001	ALTITUDE ALERTER
522-4114-006	RADIO ALTITUDE INDICATOR
422-30510-147	SDC/SAT/TAS COMPUTER
29007-715	ENCODING ALTIMETER
233T4222-15	INTER/JACK PANEL ASSY.
7000836-911	ADI
25100-200	ALTITUDE ALERTER
7003938-911	MS-400 MODE SELECTOR
522-2447-235	CONTROL UNIT
29007-903	ENCODING ALTIMETER
521-29007-4123	ENCODING ALTIMETER
422-18152-935	SDC MODULE
24929-002	ENCODING ALTIMETER
787-6385-002	COURSE INDICATOR
29007-098	ENCODING ALTIMETER
16007-B48	ENCODING ALTIMETER
29846-308	MAX ALLOWABLE AIRSPEED/MACH IND.
B0200-81928	AIRSPEEDDATA
29702-153	ENCODING ALTIMETER
29702-151	ENCODING ALTIMETER
8047-700-53	2-INCH ALTIMETER
WL1605AM3	COUNTER POINTER ALTIMETER
28007-863	ENCODING ALTIMETER
792-6221-004	REMOTE HDG/CRS SEL
29702-504	ENCODING ALTIMETER
25850-309	MAAS/MACH INDICATOR
152BL801	THERMOCOUPLE TEMPERATURE INDICATOR
SRL-C2G	INDICATOR-TORQUE, LIGHTED
101-384205-3	INDICATOR-TORQUE, LIGHTED
109-384011-3	INDICATOR-TORQUE, LIGHTED
90-384041-3	INDICATOR-TORQUE, LIGHTED
422-18152-828	SDC MODULE
JG873A5	MASTER TAS IND
519-28702-952	ENCODING ALTIMETER
5506-S53-Y	ENCODING ALTIMETER
31400-003	PNEUMATIC ALTIMETER
522-2447-271	CONTROL UNIT
523-29702-005	ENCODING ALTIMETER



519-28704-301	ENCODING ALTIMETER
792-6091-007	HSI
522-2447-057	CONTROL UNIT
24929-J2002	ENCODING ALTIMETER
29007-4209	ENCODING ALTIMETER
29702-675	ENCODING ALTIMETER
422-18152-145	SDC MODULE
4018639-923	AUTOPILOT CONTROL
521-29007-4101	ENCODING ALTIMETER
28702-906	ENCODING ALTIMETER
518-16007-168	ENCODING ALTIMETER
571-25005-051	PNEUMATIC ENCODING ALTIMETER
28007-429	ENCODING ALTIMETER
622-3702-014	BEARING DISTANCE IND.
521-29007-4700	ENCODING ALTIMETER
101635-01379	REPORTING ALTIMETER
7000605-901	MODE SELECTOR
522-2638-009	COURSE INDICATOR
518-28007-906	ENCODING ALTIMETER
7001179-910	HORIZONTAL SITUATION INDICATOR
23932-311	ALTIMETER
422-18152-326	SDC MODULE
29702-511	ENCODING ALTIMETER
622-1205-006	RADIO ALTITUDE IND.
521-29007-012	RAD ALT ALTIMETER
3A43.32.20F.28.4.CG	2-INCH ALTIMETER
518-28007-029	ENCODING ALTIMETER
24030-371	MAX/ALLOW AIRSPEED
23932-211	ALTIMETER
066-3024-35	PICTORIAL NAVIGATION INDICATOR
WL102AMS2	STANDBY INDICATOR
540-22722-014	ALTITUDE ALERTER
212-075-067-109	ITT IND
5934M-1	PRESSURE ALTIMETER
SEL-OC29DG	RPM/NL INDICATOR
28702-031	ENCODING ALTIMETER
23080-017	SDC MODULE
8140B-S20LW-MB	ENCODING ALTIMETER
25100-400	ALTITUDE ALERTER
622-3702-002	BEARING DISTANCE INDICATOR
30510-132	SDCM/SAT/TAS COMPUTER
422-30510-243	SDC MODULE
30980-117	SAT/TAS COMPUTER
29007-4227	ENCODING ALTIMETER
29702-525	ENCODING ALTIMETER
422-18152-139	SDC MODULE
23932-008	ALTIMETER
521-29007-4229	ENCODING ALTIMETER
570-24929-053	ENCODING ALTIMETER



066-3062-00	ENCODING ALTIMETER
7001182-906	ATTITUDE DIRECTOR IND.
622-4808-012	ATTITUDE DIRECTOR IND.
SLZ9635	IVSI
518-16007-704	ENCODING ALTIMETER
28007-005	ENCODING ALTIMETER
101617-1340	REPORTING ALTIMETER
31400-108	PNEUMATIC ALTIMETER
820-598	STAB TEMP INDICATOR
24929-404	ENCODING ALTIMETER
570-24929-405	ENCODING ALTIMETER
563-031	OIL TEMP/PRES IND
9813-25-16	DUAL TORQUE INDICATOR
18152-114	SDC MODULE
WL1350AMMS4	COUNTER/POINTER ALTIMETER
WL1604AM2	COUNTER POINTER ALTIMETER
4018368-925	MODE SELECTOR
520-5160-011	COURSE SELECTOR INDICATOR
422-30510-239	SDC MODULE
28007-317	ENCODING ALTIMETER
40400-105	PNEUMATIC ALTIMETER
066-03062-0001	ENCODING ALTIMETER
28007-433	ENCODING ALTIMETER
25005-221	PNEUMATIC ENCODING ALTIMETER
285T0022-44	AUDIO CONTROL PANEL
5506-S	ENCODING ALTIMETER
152BL703	THERMOCOUPLE TEMPERATURE INDICATOR
5934PM-3D	PRESSURE ALTIMETER
23989-001	ALTITUDE ALERTER
519-28702-562	ENCODING ALTIMETER
5934PA-1D	PRESSURE ALTIMETER
5934PA-3D	PRESSURE ALTIMETER
5934PAM-1D	PRESSURE ALTIMETER
5934AD-1D	PRESSURE ALTIMETER
787-6173-207	FLIGHT DIRECTOR IND.
622-4176-002	HSI
521-29007-202	ENCODING ALTIMETER
22722-054	ALTITUDE ALERTER
28007-347	ENCODING ALTIMETER
29007-202	ENCODING ALTIMETER
622-3594-001	FLIGHT DIRECTOR IND.
066-3062-0008	SERVOED ENCODING ALTIMETER
29007-4004	ENCODING ALTIMETER
5506-SG	ENCODING ALTIMETER
519-22702-521	ENCODING ALTIMETER
JG872A5	MASTER SAT IND
519-28702-022	ENCODING ALTIMETER
7003938-901	MS-400 MODE SELECTOR
23080-035	SDC MODULE



523-29702-902	ENCODING ALTIMETER
066-3031-02	RADAR ALTIMETER INDICATOR
28702-566	ENCODING ALTIMETER
522-3206-006	FLIGHT DIRECTOR IND.
422-18152-947	SDC MODULE
570-23932-002	ALTIMETER
521-29007-215	ENCODING ALTIMETER
065-00053-0005	ALTITUDE SELECTOR/ALERter
28007-021	ENCODING ALTIMETER
23080-018	SDC MODULE
518-28007-316	ENCODING ALTIMETER
B0063-81107	ALTIMETER
23932-201	ALTIMETER
518-16007-176	ENCODING ALTIMETER
422-18152-826	SDC MODULE
7001182-903	ATTITUDE DIRECTOR IND.
521-29007-4105	ENCODING ALTIMETER
066-03046-0007	PICTORIAL NAVIGATION INDICATOR
570-31400-032	PNEUMATIC ALTIMETER
27-19158-7	PERCENT TORQUE
570-23932-032	PNEUMATIC ALTIMETER
570-24929-922	ENCODING ALTIMETER
224-901-002	ITT INDICATOR
55035-1152	CABIN ALT./DIFF. IND.
30980-352	SAT/TAS COMPUTER
29702-552	ENCODING ALTIMETER
22702-533	ENCODING ALTIMETER
422-30510-204	SDC MODULE
622-6522-003	CONTROL ADF
540-45100-D4010	ALTITUDE ALERter
29007-017	ENCODING ALTIMETER
24929-313	ENCODING ALTIMETER
521-29007-4323	ENCODING ALTIMETER
20040-11230	AIRSPED INDICATOR
23932-301	ALTIMETER
777-1026-001	HSI
422-30510-218	SDC MODULE
622-4924-001	REMOTE HDG/CRS SEL
45100-C4010	ALTITUDE ALERter
16007-335	ENCODING ALTIMETER
28702-959	ENCODING ALTIMETER
4027170-905	HSI
29007-097	ENCODING ALTIMETER
570-24929-531	ENCODING ALTIMETER
39948-E2803	MAX ALLOWABLE A/S
518-16007-62	ENCODING ALTIMETER
23932-404	ALTIMETER
8048	2-INCH ALTIMETER
30980-326	SAT/TAS COMPUTER



35900-702	MAX ALLOWABLE A/S
8047/20B	2-INCH ALTIMETER
777-1026-005	HSI
570-24929-933	ENCODING ALTIMETER
1680-4U-A2	CABIN RATE OF CLIMB IND.
422-18152-324	SDC MODULE
522-2447-052	CONTROL UNIT
622-1204-006	RADIO ALTITUDE IND.
571-25005-312	PNEUMATIC ENCODING ALTIMETER
570-31400-034	PNEUMATIC ALTIMETER
570-24929-404	ENCODING ALTIMETER
570-24929-312	ENCODING ALTIMETER
521-29007-4231	ENCODING ALTIMETER
101435-01212	PRESSURE REPORTING ALTIMETER
501-1075-14	EMERGENCY POWER SUPPLY
066-3044-02	RADAR ALTIMETER INDICATOR
25005-031	PNEUMATIC ENCODING ALTIMETER
24929-202	ENCODING ALTIMETER
29007-714	ENCODING ALTIMETER
422-23080-117	SDC MODULE
622-0142-004	REMOTE HEADING AND COURSE SELECTOR
521-29007-4012	ENCODING ALTIMETER
28704-D4001	ENCODING ALTIMETER
518-16007-242	ENCODING ALTIMETER
28702-061	ENCODING ALTIMETER
518-28007-219	ENCODING ALTIMETER
23932-413	ALTIMETER
522-2447-251	CONTROL UNIT
570-24929-017	ENCODING ALTIMETER
24929-303	ENCODING ALTIMETER
523-29702-958	ENCODING ALTIMETER
622-0224-006	ATTITUDE DIRECTOR IND.
7000605-910	MODE SELECTOR
31400-014	PNEUMATIC ALTIMETER
24929-312	ENCODING ALTIMETER
422-18152-317	SDC MODULE
622-0555-004	RADIO MAGNETIC IND.
10450-11139	PRESSURE ALTIMETER
5506-S3-Y	ENCODING ALTIMETER
521-29007-106	ENCODING ALTIMETER
622-6523-007	CONTROL TRANS
622-4160-008	DIGITAL RADIO ALTITUDE INDICATOR
35250-502	MAXIMUM ALLOWABLE AIRSPEED
622-2506-014	RADIO MAGNETIC INDICATOR
521-29007-4118	ENCODING ALTIMETER
28007-230	ENCODING ALTIMETER
35250-551	MAXIMUM ALLOWABLE AIRSPEED
29702-636	ENCODING ALTIMETER
24929-402	ENCODING ALTIMETER



521-29007-103	ENCODING ALTIMETER
570-24929-502	ENCODING ALTIMETER
422-18152-133	SDC MODULE
521-29007-4210	ENCODING ALTIMETER
5506-SG3	ENCODING ALTIMETER
422-18152-838	SDC MODULE
622-5486-001	FLIGHT MODE SELECTOR
571-25005-322	PNEUMATIC ENCODING ALTIMETER
065-00053-0002	ALTITUDE SELECTOR/ALERTER
518-28007-224	ENCODING ALTIMETER
540-25100-132	ALTITUDE ALERTER
5934-1	PRESSURE ALTIMETER
28007-004	ENCODING ALTIMETER
7000605-908	MODE SELECTOR
518-28007-921	ENCODING ALTIMETER
066-3062-12	ENCODING ALTIMETER
28007-223	ENCODING ALTIMETER
5506-S3-Y4	ENCODING ALTIMETER
29007-4236	ENCODING ALTIMETER
B4018710026	CABIN CLIMB IND
29702-624	ENCODING ALTIMETER
29007-4018	ENCODING ALTIMETER
521-29007-007	ENCODING ALTIMETER
518-16007-345	ENCODING ALTIMETER
563-061	OIL TEMP/PRES IND
066-3020-13	FLIGHT COMMAND IND.
422-30510-233	SDC MODULE
28007-316	ENCODING ALTIMETER
622-4808-005	ATTITUDE DIRECTOR IND.
671CPX-10-031	SENSITIVE ALTIMETER
4018285-903	ALT. ALERT CONTROLLER
521-29007-904	ENCODING ALTIMETER
1680-4U-A3	CABIN RATE OF CLIMB INDICATOR
4029529-901	HSI
16007-402	ENCODING ALTIMETER
521-29007-4006	ENCODING ALTIMETER
575-25850-332	MAAS/MACH INDICATOR
45100-E2113	ALTITUDE ALERTER
570-24929-924	ENCODING ALTIMETER
066-03046-0003	PICTORIAL NAVIGATION INDICATOR
B0200-81120	AIRSPPEEDATA
23932-021	ALTIMETER
A9-23	SWITCH ASSEMBLY
066-03031-0001	RADAR ALTIMETER INDICATOR
29702-612	ENCODING ALTIMETER
518-16007-177	ENCODING ALTIMETER
27-19161-1	FUEL PRESSURE L/R INDICATOR
575-25850-265	MAAS/MACH AIRSPEED
5035P2-P76	ENCODING ALTIMETER



422-18152-331	SDC MODULE
519-28704-002	ENCODING ALTIMETER
30980-107	SAT/TAS COMPUTER
7000466-909	ATT. DIR. INDICATOR
422-30510-175	SDC/SAT/TAS COMPUTER
787-6173-218	FLIGHT DIRECTOR IND.
25850-264	MAAS/MACH INDICATOR
4018639-905	AUTOPILOT CONTROL
422-30510-246	SDC MODULE
571-25005-111	PNEUMATIC ENCODING ALTIMETER
7002493-903	HSI
18152-122	SDC MODULE
501-1075-05	EMERGENCY POWER SUPPLY
066-3024-00	PICTORIAL NAV IND.
28702-083	ENCODING ALTIMETER
101635-11382	REPORTING ALTIMETER
28702-523	ENCODING ALTIMETER
422-30510-248	SDC MODULE
29702-181	ENCODING ALTIMETER
519-28702-554	ENCODING ALTIMETER
570-24929-023	ENCODING ALTIMETER
521-29007-712	ENCODING ALTIMETER
519-28702-511	ENCODING ALTIMETER
30980-347	SAT/TAS COMPUTER
522-4114-008	RADIO ALTITUDE INDICATOR
523-29702-086	ENCODING ALTIMETER
101627-11378	REPORTING ALTIMETER
7000839-922	RADIO ALTIMETER INDICATOR
622-3702-011	BEARING DISTANCE INDICATOR
28007-232	ENCODING ALTIMETER
WL102AMS5	STANDBY INDICATOR
28702-034	ENCODING ALTIMETER
4018368-902	MODE SELECTOR
29007-4123	ENCODING ALTIMETER
422-18152-210	SDC MODULE
29007-004	ENCODING ALTIMETER
523-29702-186	ENCODING ALTIMETER
575-25850-229	MAAS/MACH INDICATOR
622-3594-005	FLIGHT DIRECTOR IND.
28007-346	ENCODING ALTIMETER
29702-014	ENCODING ALTIMETER
622-3702-016	BEARING DISTANCE INDICATOR
114-380017-3	CABIN ALT./DIFF. IND.
521-29007-4093	ALTIMETER
622-4938-007	RMI-30
422-18152-136	SDC MODULE
7160B	VSI/IVSI
25005-051	PNEUMATIC ENCODING ALTIMETER
523-29702-683	ENCODING ALTIMETER



518-16007-514	ENCODING ALTIMETER
22702-503	ENCODING ALTIMETER
23932-034	ALTIMETER
JG872A1	MASTER SAT IND
563-011	DC VOLTMETER INDICATOR
518-16007-173	ENCODING ALTIMETER
622-3594-012	FLIGHT DIRECTOR IND.
30980-125	SAT/TAS COMPUTER
29007-4213	ENCODING ALTIMETER
24929-406	ENCODING ALTIMETER
3571251-9131	INTER TURB TEMP IND
8047	2-INCH ALTIMETER
5035PB-P166	ENCODING ALTIMETER
518-16007-171	ENCODING ALTIMETER
7001179-962	HSI
28704-013	ENCODING ALTIMETER
540-22722-015	ALTITUDE ALERTER
792-6091-010	HSI
422-18152-920	SDC MODULE
622-0555-002	RADIO MAGNETIC IND.
24929-929	ENCODING ALTIMETER
822-1120-005	CONTROL COM
27-19178-1	OIL TEMPERATURE PRESSURE INDICATOR
521-29007-095	ENCODING ALTIMETER
519-28702-064	ENCODING ALTIMETER
29702-113	ENCODING ALTIMETER
422-18152-330	SDC MODULE
4018639-913	AUTOPILOT CONTROL
519-28704-D2001	ENCODING ALTIMETER
519-28704-013	ENCODING ALTIMETER
422-30510-130	SDC/SAT/TAS COMPUTER
101617-11373	REPORTING ALTIMETER
24929-024	ENCODING ALTIMETER
35250-503	MAXIMUM ALLOWABLE AIRSPEED
422-18152-332	SDC MODULE
114-380004-5	ITT INDICATOR
622-4160-011	DIGITAL RADIO ALTITUDE INDICATOR
28007-261	ENCODING ALTIMETER
422-30510-157	SDC/SAT/TAS COMPUTER
114-380035-1	VERTICAL SPEED INDICATOR
518-16007-407	ENCODING ALTIMETER
25100-124	ALTITUDE ALERTER
521-29007-4819	ENCODING ALTIMETER
422-18152-321	SDC MODULE
622-3109-011	AUTO PILOT CONTROL PANEL
522-4430-001	FLIGHT DIRECTOR IND.
521-29007-4223	ALTIMETER
1611AM1	STANDBY COUNTER/POINTER ALTIMETER
777-1026-006	HSI



622-1352-005	FLIGHT DIRECTOR INDICATOR
30510-326	SDCM/SAT/TAS COMPUTER
5506L-S52	ALTITUDE ALERTER
7001179-908	HORIZONTAL SITUATION INDICATOR
276AS5	MAX/ALLOW AIRSPEED
28702-907	ENCODING ALTIMETER
9813-25-13	DUAL TORQUE INDICATOR
WL1101AMMS2	SERVO ALTIMETER
25100-004	ALTITUDE ALERTER
5506L-S1	ALTITUDE ALERTER
28702-086	ENCODING ALTIMETER
523-29702-525	ENCODING ALTIMETER
522-3122-009	FLIGHT DIRECTOR IND.
7000466-955	ATT. DIR. INDICATOR
29007-019	ENCODING ALTIMETER
622-2506-008	RADIO MAGNETIC INDICATOR
16007-B44	ENCODING ALTIMETER
7000836-910	ADI
066-3046-01	PICTORIAL NAVIGATION IND
29704-H4001	ENCODING ALTIMETER
SEL-OC29DH	PROP RPM INDICATOR
29702-054	ENCODING ALTIMETER
422-30510-266	SDC MODULE
29702-566	ENCODING ALTIMETER
5934PAM-1	PRESSURE ALTIMETER
521-29007-203	ENCODING ALTIMETER
8047/20DH	2-INCH ALTIMETER
518-16007-519	ENCODING ALTIMETER
519-28702-564	ENCODING ALTIMETER
571-25005-112	PNEUMATIC ENCODING ALTIMETER
18152-303	SDC MODULE
066-3020-06	FLIGHT COMMAND IND.
519-22702-513	ENCODING ALTIMETER
24929-103	ENCODING ALTIMETER
522-2447-025	CONTROL UNIT
28702-804	ENCODING ALTIMETER
WL1407AMMS4	SERVO ALTIMETER
30980-137	SAT/TAS COMPUTER
521-29007-4094	ALTIMETER
521-29007-101	ENCODING ALTIMETER
065-0053-05	ALTITUDE SELECTOR/ALERter
570-31400-016	PNEUMATIC ALTIMETER
29702-615	ENCODING ALTIMETER
WL1105AMMS2	SERVO ALTIMETER
540-22722-013	ALTITUDE ALERTER
7003897-922	A/P CONTROLLER
787-6173-015	FLIGHT DIRECTOR IND.
570-24929-211	ENCODING ALTIMETER
772-5006-012	FLIGHT DIRECTOR IND



622-3702-004	BEARING DISTANCE INDICATOR
29702-652	ENCODING ALTIMETER
29007-809	ENCODING ALTIMETER
519-28702-951	ENCODING ALTIMETER
066-03064-0003	ENCODING ALTIMETER
523-29702-665	ENCODING ALTIMETER
521-29007-806	ENCODING ALTIMETER
622-0141-013	AUTOPILOT PANEL
523-29702-002	ENCODING ALTIMETER
422-18152-814	SDC MODULE
570-31400-108	PNEUMATIC ALTIMETER
29007-104	ENCODING ALTIMETER
102200-11850	REPORTING ALTIMETER
7000469-918	HSI
29007-4002	ENCODING ALTIMETER
521-29007-708	ENCODING ALTIMETER
422-30510-171	SDC/SAT/TAS COMPUTER
523-29702-586	ENCODING ALTIMETER
519-28702-563	ENCODING ALTIMETER
519-28702-033	ENCODING ALTIMETER
7001179-960	HSI
36154-1AJ33B1	RAD MAG COMP IND
20018-11233	AIRSPED INDICATOR
SEL019BC	TOT INDICATOR
29702-073	ENCODING ALTIMETER
23932-902	ALTIMETER
23080-039	SDC MODULE
519-22702-503	ENCODING ALTIMETER
29007-4201	ENCODING ALTIMETER
521-29007-717	ENCODING ALTIMETER
18152-104	SDC MODULE
066-03064-0000	ENCODING ALTIMETER
518-16007-B212	ENCODING ALTIMETER
570-24929-030	ENCODING ALTIMETER
622-6523-001	CONTROL TRANS
575-25850-240	MAAS/MACH INDICATOR
29702-584	ENCODING ALTIMETER
8047-700-53MB	2-INCH ALTIMETER
28702-522	ENCODING ALTIMETER
563-060	FUEL PRESSURE IND
20040-11222	AIRSPED INDICATOR
563-203	OIL TEMP/PRES IND
23932-013	ALTIMETER
422-23080-120	SDC MODULE
518-16007-802	ENCODING ALTIMETER
792-6348-002	AUTO PILOT CONTROLLER
16007-173	ENCODING ALTIMETER
25850-345	MAAS/MACH INDICATOR
30510-247	SDCM/SAT/TAS COMPUTER



30980-160	SAT/TAS COMPUTER
523-29702-113	ENCODING ALTIMETER
422-18152-942	SDC MODULE
563-084	ALCOHOL WATER INJECTION QTY. IND.
792-6091-017	HSI
25005-022	PNEUMATIC ENCODING ALTIMETER
30980-127	SAT/TAS COMPUTER
28704-B4001	ENCODING ALTIMETER
29007-804	ENCODING ALTIMETER
22702-512	ENCODING ALTIMETER
29702-572	ENCODING ALTIMETER
4018639-903	AUTOPILOT CONTROL
519-28702-906	ENCODING ALTIMETER
518-28007-209	ENCODING ALTIMETER
570-31400-103	PNEUMATIC ALTIMETER
522-4430-002	FLIGHT DIRECTOR IND.
519-28702-553	ENCODING ALTIMETER
422-30510-268	SDC MODULE
518-16007-187	ENCODING ALTIMETER
28007-217	ENCODING ALTIMETER
29007-904	ENCODING ALTIMETER
622-2265-013	FLIGHT GUIDANCE PANEL
523-29702-555	ENCODING ALTIMETER
522325	ITT INDICATOR
521-29007-4203	ENCODING ALTIMETER
25850-730	MAAS/MACH INDICATOR
422-23080-123	SDC MODULE
114-380004-9	ITT INDICATOR
101-384154-3	ITT INDICATOR
50-389102-25	ITT INDICATOR
90-384026-11	ITT INDICATOR
3337L-B-6-1-C	RMI
61111-14	PERCENT RPM IND.
28007-271	ENCODING ALTIMETER
523-29702-901	ENCODING ALTIMETER
101635-01358	REPORTING ALTIMETER
3A43.32.35F.05.1.AL	2-INCH ALTIMETER
422-18152-327	SDC MODULE
570-24929-J2002	ENCODING ALTIMETER
518-16007-233	ENCODING ALTIMETER
30510-102	SDCM/SAT/TAS COMPUTER
065-0046-02	ALTITUDE SELECTOR
422-18152-806	SDC MODULE
777-1026-004	HSI
521-29007-707	ENCODING ALTIMETER
521-29007-102	ENCODING ALTIMETER
101635-01359	REPORTING ALTIMETER
285T0022-37	AUDIO SELECTOR PANEL
5506-SG5-Y4	ENCODING ALTIMETER



519-28702-502	ENCODING ALTIMETER
521-29007-4134	ENCODING ALTIMETER
518-16007-178	ENCODING ALTIMETER
101735-11807	ALTIMETER
521-29007-096	ENCODING ALTIMETER
570-23932-024	PNEUMATIC ALTIMETER
501-1712-01	EMERGENCY POWER SUPPLY
29702-131	ENCODING ALTIMETER
29846-208	MAX ALLOWABLE AIRSPEED/MACH IND.
2591411-44	ATT, REF, INDICATOR
101635-11839	ENCODING ALTIMETER
28702-022	ENCODING ALTIMETER
24929-203	ENCODING ALTIMETER
622-6522-008	CONTROL ADF
SLZ9504A	IVSI
422-18152-958	SDC MODULE
24982-002	ALTITUDE ALERTER
519-28702-006	ENCODING ALTIMETER
30980-338	SAT/TAS COMPUTER
29007-817	ENCODING ALTIMETER
5506-SG53	ENCODING ALTIMETER
29702-156	ENCODING ALTIMETER
622-4176-009	HSI
422-18152-103	SDC MODULE
7003938-910	MS-400 MODE SELECTOR
422-18152-833	SDC MODULE
29007-4303	ENCODING ALTIMETER
30510-154	SDCM/SAT/TAS COMPUTER
24982-971	ALTITUDE ALERTER
28704-011	ENCODING ALTIMETER
422-30510-104	SDC/SAT/TAS COMPUTER
5934AD-1	PRESSURE ALTIMETER
523-29702-955	ENCODING ALTIMETER
28007-176	ENCODING ALTIMETER
15900-912	CABIN ALT/RATE/DIFF I ND.
570-24929-920	ENCODING ALTIMETER
622-1205-001	RADIO ALTITUDE IND.
16007-172	ENCODING ALTIMETER
16007-132	ENCODING ALTIMETER
4027170-902	HSI
29007-803	ENCODING ALTIMETER
29702-901	ENCODING ALTIMETER
4018639-910	AUTOPILOT CONTROL
27-19145-1	CABIN AIR TEMPERATURE INDICATOR
4018639-932	AUTOPILOT CONTROL
29702-902	ENCODING ALTIMETER
521-29007-802	ENCODING ALTIMETER
521-29007-4201	ENCODING ALTIMETER
270-2196-010	AIRSPEED SENSOR



29702-126	ENCODING ALTIMETER
521-29007-216	ENCODING ALTIMETER
7003897-905	A/P CONTROLLER
523-29702-662	ENCODING ALTIMETER
422-30510-252	SDC MODULE
30510-116	SDCM/SAT/TAS COMPUTER
16007-176	ENCODING ALTIMETER
2591411-903	ATTITUDE DIRECTOR IND.
30980-139	SAT/TAS COMPUTER
522-3206-008	FLIGHT DIRECTOR IND.
WL101AMS1	ALTIMETER/AIRSPED IND.
571-25005-042	PNEUMATIC ENCODING ALTIMETER
101450-01236	PRESSURE REPORTING ALTIMETER
25005-011	PNEUMATIC ENCODING ALTIMETER
5035P-P25	ENCODING ALTIMETER
29702-554	ENCODING ALTIMETER
521-29007-820	ENCODING ALTIMETER
422-18152-101	SDC MODULE
18152-319	SDC MODULE
422-23080-115	SDC MODULE
518-28007-318	ENCODING ALTIMETER
570-23932-412	ALTIMETER
38399-480	AIRSPED INDICATOR
29704-4001	ENCODING ALTIMETER
22702-015	ENCODING ALTIMETER
521-29007-814	ENCODING ALTIMETER
571-25005-021	PNEUMATIC ENCODING ALTIMETER
3252013-1501	ENCODING ALTIMETER
570-24929-923	ENCODING ALTIMETER
066-3031-00	RADAR ALTIMETER IND.
671CPL-10-051	SENSITIVE ALTIMETER
25850-372	MAAS/MACH INDICATOR
7000466-903	ATT. DIR. INDICATOR
422-18152-830	SDC MODULE
64141-580-1	ALTIMETER
28007-201	ENCODING ALTIMETER
7001182-918	ATTITUDE DIRECTOR INDICATOR
521-29007-4119	ENCODING ALTIMETER
522-1771-013	DISTANCE-HEADING IND
292-00	ANTI COLLISION LIGHT
B45152-10-002	ENCODER ALTIMETER
23932-203	ALTIMETER
30260-0122	VERTICAL SPEED IND
27-19313-001	EGT INDICATOR
523-29702-165	ENCODING ALTIMETER
5506-S-Y	ENCODING ALTIMETER
518-16007-403	ENCODING ALTIMETER
27-19118-009	TRI-UNIT IND.
563-007	PITCH TRIM INDICATOR



575-35250-251	MAAS/DIGITAL MACH INDICATOR
3137LB21C	RMI
2591411-906	ATTITUDE DIRECTOR IND.
27-19139-001	RATE OF CLIMB
7140	VSI/IVSI
571-25005-201	PNEUMATIC ENCODING ALTIMETER
575-25850-956	AIRSPPEED
521-29007-4113	ENCODING ALTIMETER
55035-1148	CABIN ALT./DIFF. IND.
422-30510-202	SDC MODULE
787-6173-018	FLIGHT DIRECTOR IND.
29007-4214	ENCODING ALTIMETER
44707-B2261	DUAL MODE ALTIMETER
422-23080-121	SDC MODULE
29702-111	ENCODING ALTIMETER
621-39380-103	AIR DATA UNIT
28007-001	ENCODING ALTIMETER
28702-001	ENCODING ALTIMETER
622-4176-003	HSI
523-29702-105	ENCODING ALTIMETER
7040B	VSI/IVSI
29846-201	MAX ALLOWABLE AIRSPEED/MACH IND.
518-16007-175	ENCODING ALTIMETER
29846-301	MAX ALLOWABLE AIRSPEED/MACH IND.
540-23989-002	ALTITUDE ALERTER
B0200-81113	AIRSPPEEDDATA
521-29007-014	ALTIMETER
523-29702-025	ENCODING ALTIMETER
101735-01500	ALTIMETER
8047/10B	2-INCH ALTIMETER
29702-656	ENCODING ALTIMETER
28007-218	ENCODING ALTIMETER
25005-041	PNEUMATIC ENCODING ALTIMETER
4018285-904	ALT. ALERT CONTROLLER
2592920-444	RADIO DEVIATION IND.
518-28007-237	ENCODING ALTIMETER
15900-105	CABIN ALT./RATE/DIFF IND.
521-29007-020	ENCODING ALTIMETER
16007-168	ENCODING ALTIMETER
518-16007-405	ENCODING ALTIMETER
519-28702-525	ENCODING ALTIMETER
521-29007-4001	ENCODING ALTIMETER
4029529-904	HSI
792-6221-001	REMOTE HDG/CRS SEL
523-29702-953	ENCODING ALTIMETER
519-28702-032	ENCODING ALTIMETER
527-48707-211	ALTIMETER
28007-763	ENCODING ALTIMETER
422-18152-345	SDC MODULE



570-31400-011	PNEUMATIC ALTIMETER
522-3908-003	FLIGHT DIRECTOR IND.
4016341-901	BAROMETRIC ALTITUDE IND.
9813-25-19	DUAL TORQUE INDICATOR
27-19123-5	OXYGEN CYLINDER PRESSURE INDICATOR
422-23080-008	SDC MODULE
523-29702-106	ENCODING ALTIMETER
622-4160-006	DIGITAL RADIO ALTITUDE INDICATOR
570-24929-054	ALTIMETER
422-23080-001	SDC MODULE
16007-B212	ENCODING ALTIMETER
27-19149-003	EGT/THERMOCOUPLE INDICATOR
7000605-904	MODE SELCTOR
35900-412	MAX ALLOABLE A/S
521-29007-4222	ENCODING ALTIMETER
101730-01419	ALTIMETER
7000466-906	ATT. DIR. INDICATOR
29702-503	ENCODING ALTIMETER
BAS35035552-108	MAXIMUM ALLOWABLE AIRSPEED
29007-003	ENCODING ALTIMETER
622-4151-003	COURSE INDICATOR
523-29702-606	ENCODING ALTIMETER
18152-324	SDC MODULE
520-5160-006	COURSE SELECTOR IND.
522-4114-004	RADIO ALTITUDE INDICATOR
422-18152-940	SDC MODULE
25100-031	ALTITUDE ALERTER
422-30510-258	SDC MODULE
D3137LB21C	RMI
28702-051	ENCODING ALTIMETER
422-23080-039	SDC MODULE
518-16007-710	ENCODING ALTIMETER
622-4938-005	RMI-30
622-2506-003	RADIO MAGNETIC IND.
518-16007-712	ENCODING ALTIMETER
27-19193-7	AIRSPEED INDICATOR
622-2506-013	RADIO MAGNETIC INDICATOR
622-0945-003	FLIGHT MODE SELECTOR
622-4298-001	HSI
35250-202	MAXIMUM ALLOWABLE AIRSPEED
101735-011001	ALTIMETER
792-6355-002	FLIGHT DIRECTOR INDICATOR
23932-204	ALTIMETER
16007-702	ENCODING ALTIMETER
422-18152-815	SDC MODULE
518-28007-230	ENCODING ALTIMETER
066-03064-0004	ENCODING ALTIMETER
519-28702-531	ENCODING ALTIMETER
422-30510-161	SDC/SAT/TAS COMPUTER



7003897-915	A/P CONTROLLER
570-23932-021	PNEUMATIC ALTIMETER
523-29702-603	ENCODING ALTIMETER
518-16007-763	ENCODING ALTIMETER
233T3239-303	CARGO HEAT PANEL
787-6173-216	FLIGHT DIRECTOR IND.
27-19149-3	EGT /THERMOCOUPLE INDICATOR
422-18152-338	SDC MODULE
501-1712-03	EMERGENCY POWER SUPPLY
523-29702-561	ENCODING ALTIMETER
29702-583	ENCODING ALTIMETER
29007-022	ENCODING ALTIMETER
29702-603	ENCODING ALTIMETER
101617-01339	REPORTING ALTIMETER
575-25850-345	MAAS/MACH INDICATOR
575-25850-334	MAAS/MACH INDICATOR
622-6521-016	CONTROL NAV
29007-4232	ENCODING ALTIMETER
28702-035	ENCODING ALTIMETER
7000836-905	ADI
7002493-905	HSI
522-3206-005	FLIGHT DIRECTOR IND.
29007-901	ENCODING ALTIMETER
066-3046-03	PICTORIAL NAVIGATION INDICATOR
540-25100-001	ALTITUDE ALERTER
622-4808-011	ATTITUDE DIRECTOR IND.
066-03046-0006	PICTORIAL NAVIGATION INDICATOR
49707-001	SERVO-PNEU ALT.
201530-11347	AIRSPPEED
563-073	CABIN AIR TEMPERATURE INDICATOR
27-19124-3	DEICE PRESSURE INDICATOR
622-4507-002	ATTITUDE DIRECTION INDICATOR
20130-11277	MAX ALLOWABLE AIRSPEED
521-29007-4235	ALTIMETER
6112	MANIFOLD PRESSURE GAGE
422-30510-164	SDC/SAT/TAS COMPUTER
518-16007-336	ENCODING ALTIMETER
671CPL-10-031	SENSITIVE ALTIMETER
518-16007-241	ENCODING ALTIMETER
066-3024-33	PICTORIAL NAVIGATION INDICATOR
20130-11294	MAX ALLOWABLE AIRSPEED
518-28007-218	ENCODING ALTIMETER
22722-014	ALTITUDE ALERTER
29007-4230	ENCODING ALTIMETER
9813-25-05	DUAL TORQUE INDICATOR
WL1101AMMS1	SERVO ALTIMETER
22702-123	ENCODING ALTIMETER
422-18152-112	SDC MODULE
422-30510-229	SDC MODULE



WL1381AMMS2	COUNTER/POINTER ALTIMETER
28007-011	ENCODING ALTIMETER
29702-564	ENCODING ALTIMETER
523-29702-685	ENCODING ALTIMETER
27-19118-5	TRI-UNIT IND.
622-6523-207	CONTROL TRANS
37230-003	MAXIMUM ALLOWABLE AIRSPEED/MACH IND
SLZ9157-3	IVSI
519-28702-583	ENCODING ALTIMETER
523-29702-651	ENCODING ALTIMETER
519-22702-123	ENCODING ALTIMETER
522-3122-011	FLIGHT DIRECTOR IND.
25005-321	PNEUMATIC ENCODING ALTIMETER
523-29702-572	ENCODING ALTIMETER
575-25850-343	MAAS/MACH INDICATOR
18152-306	SDC MODULE
787-6173-014	FLIGHT DIRECTOR IND.
22702-531	ENCODING ALTIMETER
066-03046-0012	PICTORIAL NAVIGATION INDICATOR
422-18152-306	SDC MODULE
518-28007-176	ENCODING ALTIMETER
563-071	DEICE PRESSURE INDICATOR
28702-958	ENCODING ALTIMETER
772-5005-001	FLIGHT DIRECTOR INDICATOR
30980-355	SAT/TAS COMPUTER
28702-803	ENCODING ALTIMETER
101420-11226	PRESS. REPT. ALTIMETER
523-29702-552	ENCODING ALTIMETER
22702-012	ENCODING ALTIMETER
066-3020-08	FLIGHT COMMAND IND.
WL1150AMMS2	SERVO ALTIMETER
22702-532	ENCODING ALTIMETER
571-25005-102	PNEUMATIC ENCODING ALTIMETER
22722-935	ALTITUDE ALERTER
422-23080-127	SDC MODULE
23080-140	SDC MODULE
540-45100-D1010	ALTITUDE ALERTER
575-35900-401	MAX ALLOWABLE/MACH AIRSPEED IND.
570-31400-107	PNEUMATIC ALTIMETER
066-3031-03	RADAR ALTIMETER INDICATOR
518-28007-214	ENCODING ALTIMETER
28702-555	ENCODING ALTIMETER
28007-229	ENCODING ALTIMETER
31400-008	PNEUMATIC ALTIMETER
28007-028	ENCODING ALTIMETER
5035P-P76	ENCODING ALTIMETER
622-6521-001	CONTROL NAV
25100-014	ALTITUDE ALERTER
792-6357-011	ATTITUDE DIRECTOR IND.



622-2937-002	RADIO ALTITUDE IND.
422-23080-109	SDC MODULE
51-4226-A2	BATTERY TEMP INDICATOR
065-0053-03	ALTITUDE SELECTOR/ALERter
523-29702-674	ENCODING ALTIMETER
519-28702-074	ENCODING ALTIMETER
518-28007-011	ENCODING ALTIMETER
18152-308	SDC MODULE
RD-AM8304	COCKPIT SPEAKER
520-5160-002	COURSE SELECTOR INDICATOR
20140-01210	MAX ALLOWABLE AIRSPEED
7000466-908	ATTITUDE DIRECTOR INDICATOR
5506-SG5-4	ENCODING ALTIMETER
518-28007-178	ENCODING ALTIMETER
4018639-901	AUTOPILOT CONTROL
28702-062	ENCODING ALTIMETER
29702-023	ENCODING ALTIMETER
152BL802C	THERMOCOUPLE TEMPERATURE INDICATOR
18152-309	SDC MODULE
25100-132	ALTITUDE ALERter
29007-011	ENCODING ALTIMETER
29007-4216	ENCODING ALTIMETER
4002531-904	ADI
15900-904	CABIN ALT/RATE/DIFF IND.
29702-016	ENCODING ALTIMETER
521-29007-4217	ALTIMETER
29007-4022	ENCODING ALTIMETER
422-18152-340	SDC MODULE
066-03062-0008	ENCODING ALTIMETER
23080-015	SDC MODULE
31500-530	MAX ALLOWABLE IND.
WL1407AMMS3	SERVO ALTIMETER
540-22722-017	ALTITUDE ALERter
29702-022	ENCODING ALTIMETER
29702-606	ENCODING ALTIMETER
7000466-925	ATT. DIR. INDICATOR
523-29702-066	ENCODING ALTIMETER
7002493-908	HSI
101750-011029	ALTIMETER
521-29007-803	ENCODING ALTIMETER
7000466-946	ATT. DIR. INDICATOR
6333	MANIF/FUEL PRESSURE GAGE
519-28702-011	ENCODING ALTIMETER
066-3046-11	PICTORIAL NAVIGATION INDICATOR
30980-356	SAT/TAS COMPUTER
622-2313-068	FLIGHT GUIDANCE PANEL
30-1521-6	REAR-POSITION NAVIGATION LIGHT
422-23080-042	SDC MODULE
25005-002	PNEUMATIC ENCODING ALTIMETER



422-30510-263	SDC MODULE
28702-056	ENCODING ALTIMETER
622-6521-011	CONTROL NAV
622-4176-005	HSI
29702-534	ENCODING ALTIMETER
066-03042-0004	RMI
WL1107AMMS1	SERVO ALTIMETER
518-16007-244	ENCODING ALTIMETER
29007-207	ENCODING ALTIMETER
SEL-OC19F	EGT INDICATOR
066-3062-09	ENCODING ALTIMETER
29702-002	ENCODING ALTIMETER
233T3239-301	CARGO HEAT PANEL
422-30510-255	SDC MODULE
622-6522-015	CONTROL ADF
518-28007-003	ENCODING ALTIMETER
523-29702-036	ENCODING ALTIMETER
28007-173	ENCODING ALTIMETER
101435-01230	PRESSURE REPORTING ALTIMETER
521-29007-4127	ENCODING ALTIMETER
570-24929-411	ENCODING ALTIMETER
4018368-907	MODE SELECTOR
422-18152-118	SDC MODULE
27-19193-17	AIRSPED INDICATOR
787-6173-007	FLIGHT DIRECTOR IND.
575-37277-525	MACH AIRSPED INDICATOR
101730-01356	ALTIMETER
772-5370-001	COURSE INDICATOR
065-0046-04	ALTITUDE SELECTOR
523-29702-571	ENCODING ALTIMETER
523-29702-083	ENCODING ALTIMETER
519-28702-561	ENCODING ALTIMETER
422-30510-271	SDC MODULE
23932-411	ALTIMETER
518-16007-250	ENCODING ALTIMETER
792-6356-002	COURSE INDICATOR
25100-013	ALTITUDE ALERTER
5506-SG3-4	ENCODING ALTIMETER
519-22702-531	ENCODING ALTIMETER
501-1075-12	EMERGENCY POWER SUPPLY
28007-263	ENCODING ALTIMETER
7001179-902	HORIZONTAL SITUATION INDICATOR
482-0061-030	RADIO MAGNETIC INDICATOR
16007-165	ENCODING ALTIMETER
5934P-1	PRESSURE ALTIMETER
28702-066	ENCODING ALTIMETER
24929-053	ENCODING ALTIMETER
570-23932-001	ALTIMETER
792-6355-004	FLIGHT DIRECTOR INDICATOR



49707-101	SERVO-PNEU ALT.
35900-602	MAX ALLOWABLE A/S
422-18152-910	SDC MODULE
16007-763	ENCODING ALTIMETER
7000469-921	HSI
29007-4211	ENCODING ALTIMETER
30510-151	SDCM/SAT/TAS COMPUTER
29007-4110	ENCODING ALTIMETER
8040B	ENCODING ALTIMETER
7001179-956	HSI
521-29007-201	ENCODING ALTIMETER
101420-01256	PRESSURE REPORTING ALTIMETER
518-28007-004	ENCODING ALTIMETER
25850-265	MAAS/MACH AIRSPEED
521-29007-4206	ENCODING ALTIMETER
622-3594-007	FLIGHT DIRECTOR IND.
SEL-OC19EJ	ITT INDICATOR
20040-11221	AIRSPEED INDICATOR
6313	MANIF/FUEL PRES GAGE
152BL708A	THERMOCOUPLE TEMPERATURE INDICATOR
5506-S3	ENCODING ALTIMETER
523-29702-513	ENCODING ALTIMETER
28702-801	ENCODING ALTIMETER
518-28007-228	ENCODING ALTIMETER
7000836-904	ADI
563-039	ANGLE OF ATTACK IND.
622-2313-093	FLIGHT GUIDANCE PANEL
622-2313-076	FLIGHT GUIDANCE PANEL
212-070-238-1	ALTIMETER
EA-5176-11-SAC	AIRSPEED IND
25850-340	MAAS/MACH INDICATOR
29702-076	ENCODING ALTIMETER
519-22702-321	ENCODING ALTIMETER
622-0141-010	AUTOPILOT PANEL
066-03020-0000	FLIGHT COMMAND IND.
066-03020-0004	FLIGHT COMMAND IND.
066-03020-0013	FLIGHT COMMAND IND.
066-03020-0015	FLIGHT COMMAND IND.
066-03020-0017	FLIGHT COMMAND IND.
066-03020-0001	FLIGHT COMMAND IND.
066-03020-0014	FLIGHT COMMAND IND.
066-03020-0016	FLIGHT COMMAND IND.
066-03020-0018	FLIGHT COMMAND IND.
066-3020-00	FLIGHT COMMAND IND.
066-3020-04	FLIGHT COMMAND IND.
066-3020-17	FLIGHT COMMAND IND.
066-3020-01	FLIGHT COMMAND IND.
066-3020-14	FLIGHT COMMAND IND.
066-3020-16	FLIGHT COMMAND IND.



066-3020-18	FLIGHT COMMAND IND.
422-18152-201	SDC MODULE
422-18152-202	SDC MODULE
575-35900-503	MAX ALLOW AIRSPEED
29702-035	ENCODING ALTIMETER
622-0141-001	AUTOPILOT PANEL
622-0141-002	AUTOPILOT PANEL
622-0141-003	AUTOPILOT PANEL
622-0141-005	AUTOPILOT PANEL
622-0141-006	AUTOPILOT PANEL
622-0141-007	AUTOPILOT PANEL
622-0141-008	AUTOPILOT PANEL
622-0141-009	AUTOPILOT PANEL
622-0141-011	AUTOPILOT PANEL
622-0141-012	AUTOPILOT PANEL
622-0141-014	AUTOPILOT PANEL
622-0141-016	AUTOPILOT PANEL
622-0141-018	AUTOPILOT PANEL
622-0141-019	AUTOPILOT PANEL
622-0141-020	AUTOPILOT PANEL
622-0141-021	AUTOPILOT PANEL
622-0141-022	AUTOPILOT PANEL
622-0141-023	AUTOPILOT PANEL
622-0141-025	AUTOPILOT PANEL
622-0141-024	AUTOPILOT CONTROL
622-0141-026	AUTOPILOT PANEL
622-0141-027	AUTOPILOT PANEL
26700-410	MAX. ALLOW. AIRSPEED
622-0141-028	AUTOPILOT PANEL
622-0141-029	AUTOPILOT PANEL
622-0141-030	AUTOPILOT PANEL
622-3109-001	AUTOPILOT PANEL
622-3109-002	AUTOPILOT PANEL
622-3109-003	AUTOPILOT PANEL
622-3109-004	AUTOPILOT PANEL
622-3109-005	AUTOPILOT PANEL
622-3109-006	AUTOPILOT PANEL
622-3109-007	AUTOPILOT PANEL
622-3109-008	AUTOPILOT PANEL
622-3109-010	AUTOPILOT PANEL
622-3109-012	AUTOPILOT PANEL
622-3109-013	AUTOPILOT PANEL
622-3109-014	AUTOPILOT PANEL
622-3109-015	AUTOPILOT PANEL
622-3109-016	AUTOPILOT PANEL
622-3109-017	AUTOPILOT PANEL
622-3109-018	AUTOPILOT PANEL
622-3109-019	AUTOPILOT PANEL
622-3109-020	AUTOPILOT PANEL



622-3109-023	AUTOPILOT PANEL
622-3109-021	AUTOPILOT PANEL
622-3109-022	AUTOPILOT PANEL
622-3109-024	AUTOPILOT PANEL
622-3109-025	AUTOPILOT PANEL
622-3109-026	AUTOPILOT PANEL
622-3109-027	AUTOPILOT PANEL
622-3109-028	AUTOPILOT PANEL
622-3109-029	AUTOPILOT PANEL
622-3109-030	AUTOPILOT PANEL
622-3901-001	AUTOPILOT PANEL
522-2448-055	COMM/NAV CONTROL
B0063-81104	ALTIMETER
B0063-81110	ALTIMETER
532-26700-410	MAX ALLOW AIRSPEED
5035P2-P18	ENCODING ALTIMETER
25100-121	ALTITUDE ALERTER
25100-122	ALTITUDE ALERTER
25100-123	ALTITUDE ALERTER
28702-908	ENCODING ALTIMETER
B0063-81114	ALTIMETER
26700-312	MAX. ALLOW. AIRSPEED
26700-401	MAX. ALLOW. AIRSPEED
26700-402	MAX. ALLOW. AIRSPEED
26700-404	MAX. ALLOW. AIRSPEED
26700-403	MAX. ALLOW. AIRSPEED
26700-406	MAX. ALLOW. AIRSPEED
26700-301	MAX. ALLOW. AIRSPEED
26700-302	MAX. ALLOW. AIRSPEED
26700-306	MAX. ALLOW. AIRSPEED
26700-309	MAX. ALLOW. AIRSPEED
26700-310	MAX. ALLOW. AIRSPEED
26700-311	MAX. ALLOW. AIRSPEED
26700-411	MAX. ALLOW. AIRSPEED
26700-412	MAX. ALLOW. AIRSPEED
26700-409	MAX. ALLOW. AIRSPEED
522-4194-001	FLIGHT DIRECTOR IND.
532-26700-301	MAX ALLOW AIRSPEED
532-26700-302	MAX ALLOW AIRSPEED
532-26700-303	MAX ALLOW AIRSPEED
532-26700-304	MAX ALLOW AIRSPEED
532-26700-305	MAX ALLOW AIRSPEED
532-26700-306	MAX ALLOW AIRSPEED
532-26700-309	MAX ALLOW AIRSPEED
532-26700-310	MAX ALLOW AIRSPEED
532-26700-311	MAX ALLOW AIRSPEED
532-26700-312	MAX ALLOW AIRSPEED
532-26700-401	MAX ALLOW AIRSPEED
532-26700-402	MAX ALLOW AIRSPEED



532-26700-404	MAX ALLOW AIRSPEED
532-26700-403	MAX ALLOW AIRSPEED
28702-909	ENCODING ALTIMETER
522-4063-001	FLIGHT DIRECTOR IND.
522-4063-003	FLIGHT DIRECTOR IND.
532-26700-405	MAX ALLOW AIRSPEED
532-26700-406	MAX ALLOW AIRSPEED
532-26700-409	MAX ALLOW AIRSPEED
532-26700-411	MAX ALLOW AIRSPEED
532-26700-412	MAX ALLOW AIRSPEED
5035P2-P17	ENCODING ALTIMETER
5035P2-P20	ENCODING ALTIMETER
28702-910	ENCODING ALTIMETER
28702-911	ENCODING ALTIMETER
622-2265-027	FLIGHT GUIDANCE PANEL
622-2265-025	FLIGHT GUIDANCE PANEL
622-2265-029	FLIGHT GUIDANCE PANEL
622-2265-030	FLIGHT GUIDANCE PANEL
622-2265-032	FLIGHT GUIDANCE PANEL
622-2265-033	FLIGHT GUIDANCE PANEL
622-2265-034	FLIGHT GUIDANCE PANEL
622-2265-035	FLIGHT GUIDANCE PANEL
622-2265-036	FLIGHT GUIDANCE PANEL
622-2265-031	FLIGHT GUIDANCE PANEL
622-2265-037	FLIGHT GUIDANCE PANEL
622-2265-038	FLIGHT GUIDANCE PANEL
622-2265-039	FLIGHT GUIDANCE PANEL
622-2265-040	FLIGHT GUIDANCE PANEL
622-2265-042	FLIGHT GUIDANCE PANEL
622-2265-043	FLIGHT GUIDANCE PANEL
622-2313-083	FLIGHT GUIDANCE PANEL
622-2313-084	FLIGHT GUIDANCE PANEL
622-2313-086	FLIGHT GUIDANCE PANEL
622-2313-088	FLIGHT GUIDANCE PANEL
SEL-OC19EJ-1	ITT INDICATOR
622-2265-045	FLIGHT GUIDANCE PANEL
622-2265-046	FLIGHT GUIDANCE PANEL
622-2265-047	FLIGHT GUIDANCE PANEL
622-2265-049	FLIGHT GUIDANCE PANEL
622-2265-050	FLIGHT GUIDANCE PANEL
622-2265-051	FLIGHT GUIDANCE PANEL
622-2265-052	FLIGHT GUIDANCE PANEL
622-2265-055	FLIGHT GUIDANCE PANEL
622-2265-056	FLIGHT GUIDANCE PANEL
622-4449-002	FLIGHT GUIDANCE PANEL
622-4449-003	FLIGHT GUIDANCE PANEL
622-4449-004	FLIGHT GUIDANCE PANEL
622-4449-005	FLIGHT GUIDANCE PANEL
622-4449-006	FLIGHT GUIDANCE PANEL



622-4449-007	FLIGHT GUIDANCE PANEL
622-4449-008	FLIGHT GUIDANCE PANEL
622-4449-010	FLIGHT GUIDANCE PANEL
622-4449-011	FLIGHT GUIDANCE PANEL
622-4449-013	FLIGHT GUIDANCE PANEL
622-4449-014	FLIGHT GUIDANCE PANEL
622-4449-015	FLIGHT GUIDANCE PANEL
622-4449-017	FLIGHT GUIDANCE PANEL
622-4449-018	FLIGHT GUIDANCE PANEL
622-4449-019	FLIGHT GUIDANCE PANEL
622-4449-020	FLIGHT GUIDANCE PANEL
622-4449-021	FLIGHT GUIDANCE PANEL
622-4449-022	FLIGHT GUIDANCE PANEL
622-4449-023	FLIGHT GUIDANCE PANEL
622-4449-024	FLIGHT GUIDANCE PANEL
622-4449-025	FLIGHT GUIDANCE PANEL
622-4449-026	FLIGHT GUIDANCE PANEL
622-4449-027	FLIGHT GUIDANCE PANEL
622-4449-029	FLIGHT GUIDANCE PANEL
622-4449-030	FLIGHT GUIDANCE PANEL
622-4449-033	FLIGHT GUIDANCE PANEL
622-4449-034	FLIGHT GUIDANCE PANEL
622-4449-035	FLIGHT GUIDANCE PANEL
622-4449-038	FLIGHT GUIDANCE PANEL
622-4449-039	FLIGHT GUIDANCE PANEL
622-4449-040	FLIGHT GUIDANCE PANEL
622-4449-041	FLIGHT GUIDANCE PANEL
622-4449-042	FLIGHT GUIDANCE PANEL
622-4449-037	FLIGHT GUIDANCE PANEL
622-4449-043	FLIGHT GUIDANCE PANEL
622-4449-045	FLIGHT GUIDANCE PANEL
622-4449-046	FLIGHT GUIDANCE PANEL
622-4449-048	FLIGHT GUIDANCE PANEL
622-4449-049	FLIGHT GUIDANCE PANEL
622-4449-050	FLIGHT GUIDANCE PANEL
622-4449-051	FLIGHT GUIDANCE PANEL
622-4449-052	FLIGHT GUIDANCE PANEL
522-2447-562	NAV/COM CONTROL
622-4449-056	FLIGHT GUIDANCE PANEL
622-4449-057	FLIGHT GUIDANCE PANEL
622-4449-058	FLIGHT GUIDANCE PANEL
622-4449-060	FLIGHT GUIDANCE PANEL
622-4449-055	FLIGHT GUIDANCE PANEL
622-3897-001	FLIGHT GUIDANCE PANEL
622-3898-001	FLIGHT GUIDANCE PANEL
622-3898-002	FLIGHT GUIDANCE PANEL
622-2265-059	FLIGHT GUIDANCE PANEL
622-4449-012	FLIGHT GUIDANCE PANEL
622-4449-036	FLIGHT GUIDANCE PANEL



482-0061-020	RADIO MAGNETIC INDICATOR
622-2313-033	FLIGHT GUIDANCE PANEL
622-2313-073	FLIGHT GUIDANCE PANEL
622-2313-074	FLIGHT GUIDANCE PANEL
622-2313-075	FLIGHT GUIDANCE PANEL
622-2313-077	FLIGHT GUIDANCE PANEL
622-2313-079	FLIGHT GUIDANCE PANEL
622-2313-080	FLIGHT GUIDANCE PANEL
622-2313-081	FLIGHT GUIDANCE PANEL
622-2313-002	FLIGHT GUIDANCE PANEL
622-2313-003	FLIGHT GUIDE PANEL
622-2313-004	FLIGHT GUIDE PANEL
622-2313-005	FLIGHT GUIDE PANEL
622-2313-006	FLIGHT GUIDE PANEL
622-2313-007	FLIGHT GUIDANCE PANEL
622-2313-008	FLIGHT GUIDANCE PANEL
622-2313-009	FLIGHT GUIDANCE PANEL
622-2313-010	FLIGHT GUIDANCE PANEL
622-2313-012	FLIGHT GUIDANCE PANEL
622-2313-013	FLIGHT GUIDANCE PANEL
622-2313-014	FLIGHT GUIDANCE PANEL
622-2313-015	FLIGHT GUIDANCE PANEL
622-2313-016	FLIGHT GUIDANCE PANEL
622-2313-017	FLIGHT GUIDANCE PANEL
622-2313-018	FLIGHT GUIDANCE PANEL
622-2313-020	FLIGHT GUIDANCE PANEL
622-2313-021	FLIGHT GUIDANCE PANEL
622-2313-022	FLIGHT GUIDANCE PANEL
622-2313-023	FLIGHT GUIDANCE PANEL
622-2313-024	FLIGHT GUIDANCE PANEL
563-305	IND, DUAL PROP AMP
SEL-OC19EP	ITT INDICATOR
622-2313-025	FLIGHT GUIDANCE PANEL
622-2313-027	FLIGHT GUIDANCE PANEL
622-2313-029	FLIGHT GUIDANCE PANEL
622-2313-031	FLIGHT GUIDANCE PANEL
622-2313-032	FLIGHT GUIDANCE PANEL
622-2313-034	FLIGHT GUIDANCE PANEL
622-2313-035	FLIGHT GUIDANCE PANEL
622-2313-036	FLIGHT GUIDANCE PANEL
622-2313-037	FLIGHT GUIDANCE PANEL
622-2313-038	FLIGHT GUIDANCE PANEL
622-2313-039	FLIGHT GUIDANCE PANEL
622-2313-040	FLIGHT GUIDANCE PANEL
622-2313-041	FLIGHT GUIDANCE PANEL
622-2313-042	FLIGHT GUIDANCE PANEL
622-2313-043	FLIGHT GUIDANCE PANEL
622-2313-044	FLIGHT GUIDANCE PANEL
622-2313-045	FLIGHT GUIDANCE PANEL



622-2313-046	FLIGHT GUIDANCE PANEL
622-2313-047	FLIGHT GUIDANCE PANEL
622-2313-048	FLIGHT GUIDANCE PANEL
622-2313-049	FLIGHT GUIDANCE PANEL
622-2313-050	FLIGHT GUIDANCE PANEL
622-2313-051	FLIGHT GUIDANCE PANEL
622-2313-052	FLIGHT GUIDANCE PANEL
622-2313-055	FLIGHT GUIDANCE PANEL
622-2313-056	FLIGHT GUIDANCE PANEL
622-2313-057	FLIGHT GUIDANCE PANEL
622-2313-058	FLIGHT GUIDANCE PANEL
622-2313-059	FLIGHT GUIDANCE PANEL
622-2313-060	FLIGHT GUIDANCE PANEL
622-2313-061	FLIGHT GUIDANCE PANEL
622-2313-062	FLIGHT GUIDANCE PANEL
622-2313-063	FLIGHT GUIDANCE PANEL
622-2313-064	FLIGHT GUIDANCE PANEL
622-2313-065	FLIGHT GUIDANCE PANEL
622-2313-066	FLIGHT GUIDANCE PANEL
622-2313-067	FLIGHT GUIDANCE PANEL
622-2313-069	FLIGHT GUIDANCE PANEL
114-380049-3	IND, DUAL PROP AMP
622-2313-095	FLIGHT GUIDANCE PANEL
622-2313-096	FLIGHT GUIDANCE PANEL
622-2313-098	FLIGHT GUIDANCE PANEL
622-2313-100	FLIGHT GUIDANCE PANEL
622-2313-097	FLIGHT GUIDANCE PANEL
622-2313-101	FLIGHT GUIDANCE PANEL
622-2265-002	FLIGHT GUIDANCE PANEL
622-2265-003	FLIGHT GUIDANCE PANEL
622-2265-004	FLIGHT GUIDANCE PANEL
622-2265-005	FLIGHT GUIDANCE PANEL
622-2265-007	FLIGHT GUIDANCE PANEL
622-2265-008	FLIGHT GUIDANCE PANEL
622-2265-009	FLIGHT GUIDANCE PANEL
622-2265-010	FLIGHT GUIDANCE PANEL
622-2265-011	FLIGHT GUIDANCE PANEL
622-2265-012	FLIGHT GUIDANCE PANEL
622-2265-014	FLIGHT GUIDANCE PANEL
622-2265-015	FLIGHT GUIDANCE PANEL
622-2265-017	FLIGHT GUIDANCE PANEL
622-2265-018	FLIGHT GUIDANCE PANEL
622-2265-019	FLIGHT GUIDANCE PANEL
622-2265-021	FLIGHT GUIDANCE PANEL
622-2265-022	FLIGHT GUIDANCE PANEL
622-2265-023	FLIGHT GUIDANCE PANEL
114-380049-7	IND, DUAL PROP AMP
522-2447-505	RADIO SET CONTROL
522-2447-515	RADIO SET CONTROL



622-2265-006	FLIGHT GUIDANCE PANEL
622-4449-047	FLIGHT GUIDANCE PANEL
522-2447-557	RADIO SET CONTROL
522-2447-563	RADIO SET CONTROL
522-2447-570	RADIO SET CONTROL
522-3614-506	RADIO CONTROL SET
522-3616-501	RADIO CONTROL SET
522-3616-503	RADIO CONTROL SET
522-3616-504	RADIO CONTROL SET
522-2599-500	NAV COMM CONTROL SET
522-2599-501	RADIO CONTROL SET
522-2599-502	RADIO CONTROL SET
522-2599-504	RADIO CONTROL SET
522-2447-560	RADIO CONTROL SET
522-2599-503	RADIO SET CONTROL
522-2448-075	CONTROL UNIT
B4018710032	CABIN RATE OF CLIMB INDICATOR
521942	ITT INDICATOR
521944	ITT INDICATOR
90-384026-3	ITT INDICATOR
MML-OC19AN	ITT
MML-OC29D	ITT, N2
48707-001	ALTIMETER
48707-002	ALTIMETER
48707-003	ALTIMETER
48707-004	ALTIMETER
48707-101	ALTIMETER
48707-102	ALTIMETER
48707-103	ALTIMETER
48707-104	ALTIMETER
48707-201	ALTIMETER
48707-202	ALTIMETER
48707-203	ALTIMETER
285T0022-31	AUDIO SELECTOR PANEL
285T0022-35	AUDIO SELECTOR PANEL
285T0022-38	AUDIO SELECTOR PANEL
285T0022-41	AUDIO SELECTOR PANEL
285T0022-42	AUDIO SELECTOR PANEL
285T0022-45	AUDIO SELECTOR PANEL
285T0022-46	AUDIO SELECTOR PANEL
527-48707-001	ALTIMETER
527-48707-002	ALTIMETER
527-48707-003	ALTIMETER
522-2448-005	CONTROL UNIT
522-2448-205	CONTROL UNIT
522-2448-015	CONTROL UNIT
522-2448-215	CONTROL UNIT
522-2448-025	CONTROL UNIT
522-2448-225	CONTROL UNIT



522-2448-235	CONTROL UNIT
522-2448-045	CONTROL UNIT
522-2448-245	CONTROL UNIT
522-2448-056	CONTROL UNIT
522-2448-256	CONTROL UNIT
522-2448-057	CONTROL UNIT
522-2448-058	CONTROL UNIT
522-2448-258	CONTROL UNIT
522-2448-059	CONTROL UNIT
522-2448-259	CONTROL UNIT
522-2448-060	CONTROL UNIT
522-2448-260	CONTROL UNIT
522-2448-063	CONTROL UNIT
522-2448-263	CONTROL UNIT
522-2448-065	CONTROL UNIT
522-2448-265	CONTROL UNIT
522-2448-066	CONTROL UNIT
522-2448-266	CONTROL UNIT
522-2448-067	CONTROL UNIT
522-2448-267	CONTROL UNIT
522-2448-069	CONTROL UNIT
522-2448-269	CONTROL UNIT
522-2448-072	CONTROL UNIT
522-2448-272	CONTROL UNIT
522-2448-073	CONTROL UNIT
522-2448-061	CONTROL UNIT
522-2448-261	CONTROL UNIT
522-2448-074	CONTROL UNIT
522-2448-276	CONTROL UNIT
563-306	OIL TEMP & PRESS. IND.
114-380009-7	OIL TEMP GAUGE
26135-1142	AIRSPEED INDICATOR
5950	PRESSURE ALTIMETER
5950M	PRESSURE ALTIMETER
5950D	PRESSURE ALTIMETER
5950P	PRESSURE ALTIMETER
5950PM	PRESSURE ALTIMETER
5934-3M	PRESSURE ALTIMETER
5934D-3M	PRESSURE ALTIMETER
5934A-3M	PRESSURE ALTIMETER
5934DA-3M	PRESSURE ALTIMETER
5934P-3M	PRESSURE ALTIMETER
5934PD-3M	PRESSURE ALTIMETER
5934PA-3M	PRESSURE ALTIMETER
5934PDA-3M	PRESSURE ALTIMETER
5934-3B	PRESSURE ALTIMETER
5934A-3B	PRESSURE ALTIMETER
5934-3BD	PRESSURE ALTIMETER
5934PAM-3D	PRESSURE ALTIMETER



5934D-1D	PRESSURE ALTIMETER
5934D-3D	PRESSURE ALTIMETER
5934PD-1D	PRESSURE ALTIMETER
5934PD-3D	PRESSURE ALTIMETER
5934PAD-1D	PRESSURE ALTIMETER
5934PAD-3D	PRESSURE ALTIMETER
5934AD-3D	PRESSURE ALTIMETER
622-8740-208	CONTROL TRANS
622-8740-209	CONTROL TRANS
622-8740-210	CONTROL TRANS
622-8740-211	CONTROL TRANS
622-8740-212	CONTROL TRANS
622-8740-213	CONTROL TRANS
622-8740-214	CONTROL TRANS
622-8740-215	CONTROL TRANS
622-8740-216	CONTROL TRANS
622-8740-305	CONTROL TRANS
622-8740-306	CONTROL TRANS
622-8740-307	CONTROL TRANS
622-8740-308	CONTROL TRANS
622-8740-313	CONTROL TRANS
622-8740-314	CONTROL TRANS
622-8740-315	CONTROL TRANS
622-8740-316	CONTROL TRANS
622-8740-801	CONTROL TRANS
622-8740-802	CONTROL TRANS
622-6520-002	CONTROL COM
622-6520-006	CONTROL COM
622-6520-009	CONTROL COM
622-6520-010	CONTROL COM
622-6520-011	CONTROL COM
622-6520-012	CONTROL COM
622-6520-013	CONTROL COM
622-6520-014	CONTROL COM
622-6520-015	CONTROL COM
622-6520-801	CONTROL COM
622-6520-802	CONTROL COM
622-8737-001	CONTROL COM
622-8737-002	CONTROL COM
622-8737-003	CONTROL COM
622-8737-004	CONTROL COM
622-8737-005	CONTROL COM
622-8737-006	CONTROL COM
622-8737-007	CONTROL COM
622-8737-008	CONTROL COM
622-8737-009	CONTROL COM
622-8737-010	CONTROL COM
622-8737-011	CONTROL COM
563-213	OIL TEMP/PRES IND



27-19178-5	OIL TEMP/PRESS IND
27-19160-3	OIL TEMP/PRESS IND
622-8737-012	CONTROL COM
622-8737-013	CONTROL COM
622-8737-014	CONTROL COM
622-8737-015	CONTROL COM
622-8737-016	CONTROL COM
622-8737-801	CONTROL COM
622-8737-802	CONTROL COM
822-1120-002	CONTROL COM
822-1120-010	CONTROL COM
822-1120-011	CONTROL COM
822-1120-012	CONTROL COM
822-1120-013	CONTROL COM
822-1120-014	CONTROL COM
822-1120-015	CONTROL COM
822-1120-016	CONTROL COM
622-6521-002	CONTROL NAV
622-6521-003	CONTROL NAV
622-6521-004	CONTROL NAV
622-6521-006	CONTROL NAV
622-6521-008	CONTROL NAV
622-6521-010	CONTROL NAV
622-6521-026	CONTROL NAV
622-6521-027	CONTROL NAV
622-8739-001	CONTROL ADF
622-8739-002	CONTROL ADF
622-8739-003	CONTROL ADF
622-8739-004	CONTROL ADF
622-8739-005	CONTROL ADF
622-8739-006	CONTROL ADF
622-8739-007	CONTROL ADF
622-8739-008	CONTROL ADF
622-8739-009	CONTROL ADF
622-8739-010	CONTROL ADF
622-8739-011	CONTROL ADF
622-8739-012	CONTROL ADF
622-8739-013	CONTROL ADF
622-8739-014	CONTROL ADF
622-8739-015	CONTROL ADF
622-8739-016	CONTROL ADF
622-8739-017	CONTROL ADF
622-8739-018	CONTROL ADF
622-8739-019	CONTROL ADF
622-8739-020	CONTROL ADF
622-8739-021	CONTROL ADF
622-8739-022	CONTROL ADF
622-8739-023	CONTROL ADF
622-8739-024	CONTROL ADF



622-6521-028	CONTROL NAV
622-6521-029	CONTROL NAV
622-6521-030	CONTROL NAV
622-6521-031	CONTROL NAV
622-6521-032	CONTROL NAV
622-6521-801	CONTROL NAV
622-6521-802	CONTROL NAV
622-6521-803	CONTROL NAV
622-6521-804	CONTROL NAV
622-8738-001	CONTROL NAV
622-8739-025	CONTROL ADF
622-8739-026	CONTROL ADF
622-8739-027	CONTROL ADF
622-8739-028	CONTROL ADF
622-8738-002	CONTROL NAV
622-8738-003	CONTROL NAV
622-8738-004	CONTROL NAV
622-8738-005	CONTROL NAV
622-8738-006	CONTROL NAV
622-8738-007	CONTROL NAV
622-8738-008	CONTROL NAV
622-8738-009	CONTROL NAV
622-8738-010	CONTROL NAV
622-8738-011	CONTROL NAV
622-8738-012	CONTROL NAV
622-8738-013	CONTROL NAV
622-8738-014	CONTROL NAV
622-8738-015	CONTROL NAV
622-8738-016	CONTROL NAV
622-8738-025	CONTROL NAV
622-8738-026	CONTROL NAV
622-8738-027	CONTROL NAV
622-8738-028	CONTROL NAV
622-8738-029	CONTROL NAV
622-8738-030	CONTROL NAV
622-8738-031	CONTROL NAV
622-8739-029	CONTROL ADF
622-8739-030	CONTROL ADF
622-8739-031	CONTROL ADF
622-8739-032	CONTROL ADF
622-8739-801	CONTROL ADF
622-8739-802	CONTROL ADF
622-8739-803	CONTROL ADF
622-8739-804	CONTROL ADF
622-6523-002	CONTROL TRANS
622-6523-003	CONTROL TRANS
622-6523-004	CONTROL TRANS
622-6523-006	CONTROL TRANS
622-6523-009	CONTROL TRANS



622-6523-010	CONTROL TRANS
622-6523-011	CONTROL TRANS
622-6523-012	CONTROL TRANS
622-6523-013	CONTROL TRANS
622-6523-014	CONTROL TRANS
622-6523-015	CONTROL TRANS
622-6523-016	CONTROL TRANS
622-6523-201	CONTROL TRANS
622-8738-032	CONTROL NAV
622-8738-801	CONTROL NAV
622-8738-802	CONTROL NAV
622-8738-803	CONTROL NAV
622-8738-804	CONTROL NAV
622-6522-009	CONTROL ADF
622-6522-010	CONTROL ADF
622-6522-011	CONTROL ADF
622-6522-012	CONTROL ADF
622-6522-014	CONTROL ADF
622-6522-018	CONTROL ADF
622-6522-019	CONTROL ADF
622-6522-020	CONTROL ADF
622-6522-021	CONTROL ADF
622-6522-022	CONTROL ADF
622-6522-023	CONTROL ADF
622-6522-024	CONTROL ADF
622-6522-025	CONTROL ADF
622-6522-026	CONTROL ADF
622-6522-027	CONTROL ADF
622-6522-028	CONTROL ADF
622-6522-029	CONTROL ADF
622-6523-203	CONTROL TRANS
622-6523-202	CONTROL TRANS
622-6523-206	CONTROL TRANS
622-6523-209	CONTROL TRANS
622-6523-210	CONTROL TRANS
622-6523-211	CONTROL TRANS
622-6523-212	CONTROL TRANS
622-6523-214	CONTROL TRANS
622-6523-215	CONTROL TRANS
622-6523-216	CONTROL TRANS
622-6523-305	CONTROL TRANS
622-6523-306	CONTROL TRANS
622-6523-307	CONTROL TRANS
622-6523-308	CONTROL TRANS
622-6523-313	CONTROL TRANS
622-6523-314	CONTROL TRANS
622-6523-315	CONTROL TRANS
622-6523-316	CONTROL TRANS
622-6523-801	CONTROL TRANS



527-48707-004	ALTIMETER
622-6522-030	CONTROL ADF
622-6522-031	CONTROL ADF
655-6522-032	CONTROL COMM
622-6522-032	CONTROL ADF
622-6522-801	CONTROL ADF
622-6522-802	CONTROL ADF
622-6522-803	CONTROL ADF
622-6522-804	CONTROL ADF
622-6523-802	CONTROL TRANS
622-8740-001	CONTROL TRANS
622-8740-002	CONTROL TRANS
622-8740-003	CONTROL TRANS
622-8740-004	CONTROL TRANS
622-8740-005	CONTROL TRANS
622-8740-006	CONTROL TRANS
622-8740-007	CONTROL TRANS
622-8740-008	CONTROL TRANS
622-8740-009	CONTROL TRANS
622-8740-010	CONTROL TRANS
622-8740-011	CONTROL TRANS
622-8740-012	CONTROL TRANS
622-8740-013	CONTROL TRANS
622-8740-014	CONTROL TRANS
622-8740-015	CONTROL TRANS
622-8740-016	CONTROL TRANS
622-8740-201	CONTROL TRANS
622-8740-202	CONTROL TRANS
622-8740-203	CONTROL TRANS
622-8740-204	CONTROL TRANS
622-8740-205	CONTROL TRANS
622-8740-206	CONTROL TRANS
622-8740-207	CONTROL TRANS
S222T100-203	COCKPIT SPEAKER
622-7209-005	CONVERTER RADIO ALTIMETER
JG298A6	EPR INDICATOR
JG298A7	EPR INDICATOR
JG298A8	EPR INDICATOR
622-9851-001	CONTROL NAV
622-9851-002	CONTROL NAV
622-9851-008	CONTROL NAV
822-1121-003	CONTROL NAV
822-1121-004	CONTROL NAV
B0063-81101	COUNTER POINTER DRUM ALTIMETER
B0063-81109	COUNTER POINTER DRUM ALTIMETER
B0063-81113	COUNTER POINTER DRUM ALTIMETER
B0063-82103	COUNTER POINTER DRUM ALTIMETER
B0063-82109	COUNTER POINTER DRUM ALTIMETER
163BL507	TEMP IND



163BL507H	TEMP IND
163BL508	TEMP IND
163BL511	TEMP IND
163BL511A	TEMP IND
562-938	VOLTAGE INDICATOR
7018341-802	MODE SELECTOR
7018341-811	MODE SELECTOR
7018341-812	MODE SELECTOR
7018341-813	MODE SELECTOR
7018341-814	MODE SELECTOR
7018341-902	MODE SELECTOR
7018341-903	MODE SELECTOR
7018341-904	MODE SELECTOR
7018341-906	MODE SELECTOR
7018341-908	MODE SELECTOR
820-574	WING TEMP. IND.
820-577	FLAP INDICATOR
820-582	STAB TEMP IND.
820-583	TEMP. CONT. INDICATOR
575-26107-211	AIRSPEED IND
575-26107-290	AIRSPEED IND
575-26107-291	AIRSPEED IND
575-26107-311	AIRSPEED IND
575-26107-390	AIRSPEED IND
575-26107-391	AIRSPEED IND
575-26107-611	AIRSPEED IND
575-26107-690	AIRSPEED IND
26107-211	AIRSPEED IND
26107-290	AIRSPEED IND
26107-291	AIRSPEED IND
26107-311	AIRSPEED IND
26107-390	AIRSPEED IND
26107-611	AIRSPEED IND
26107-690	AIRSPEED IND
26107-691	AIRSPEED IND
26107-711	AIRSPEED IND
26107-791	AIRSPEED IND
26107-2108	AIRSPEED IND
575-26107-691	AIRSPEED IND
575-26107-711	AIRSPEED IND
575-26107-790	AIRSPEED IND
575-26107-791	AIRSPEED IND
575-26107-2108	AIRSPEED IND
3883615-515	AIRSPEED INDICATOR
622-9851-007	CONTROL NAV
822-1121-005	CONTROL NAV
822-1121-006	CONTROL NAV
822-1121-007	CONTROL NAV
822-1121-008	CONTROL NAV



RC-30-VIL-2	VERTICAL VELOCITY INDICATOR
RC-30-VIL-4	VERTICAL VELOCITY INDICATOR